MPS Logic:
2019-11-12-a

Contents

1 Ignored when A-Line Kicker Is Not Enabled, A-Line SL10 Is Closed, TD11 Is In, YAG01 Is In, or YAG02 Is In **20**
1.1 Flowswitch: COLL BSYA 2060 (PC20) . . . 20
1.2 Flowswitch: COLL BSYA 2410 (COLL24H) . . . 20
1.3 Flowswitch: COLL BSYA 2410 (COLL24V) . . . 20
1.4 Flowswitch: COLL BSYA 2410 (PC24) . . . 20
1.5 Flowswitch: COLL BSYA 2600 (PC26) . . . 21
1.6 Flowswitch: COLL BSYA 2990 (PC29) . . . 21
1.7 Flowswitch: COLL BSYA 3710 (C37) . . . 21
1.8 Flowswitch: COLL BSYA 4120 (3C1A) . . . 21
1.9 PIC Raw Charge Thresholds: BSYA 2061 . . . 22
1.10 PIC Raw Charge Thresholds: BSYA 2120 . . . 22
1.11 PIC Raw Charge Thresholds: BSYA 2220 . . . 22
1.12 PIC Raw Charge Thresholds: BSYA 2321 . . . 23
1.13 PIC Raw Charge Thresholds: BSYA 2411 . . . 23
1.14 PIC Raw Charge Thresholds: BSYA 2472 . . . 23
1.15 PIC Raw Charge Thresholds: BSYA 2473 . . . 24
1.16 PIC Raw Charge Thresholds: BSYA 2474 . . . 24
1.17 PIC Raw Charge Thresholds: BSYA 2475 . . . 24
1.18 PIC Raw Charge Thresholds: BSYA 2520 . . . 25
1.19 PIC Raw Charge Thresholds: BSYA 2601 . . . 25
1.20 PIC Raw Charge Thresholds: BSYA 2861 . . . 25
1.21 PIC Raw Charge Thresholds: BSYA 2990 . . . 26
1.22 PIC Raw Charge Thresholds: BSYA 3320 . . . 26
1.23 PIC Raw Charge Thresholds: BSYA 3720 . . . 26
1.24 PIC Raw Charge Thresholds: BSYA 3721 . . . 27
1.25 PIC Raw Charge Thresholds: BSYA 3890 . . . 27
1.26 PIC Trigger Missed (LN42) . . . 27
1.27 Stopper BSYA 2275 (ST22) Position . . . 28
1.28 Stopper BSYA 2930 (ST29) Position . . . 28
1.29 Temperature RTD Summary: A-line Past SL10 . . . 28
1.30 Vac Valve BSYA 4005 (IV40) . . . 28
1.31 Vac Valve: VVFS BSYA 2855 (FV28) . . . 29
1.32 Vac Valve: VVPG BSYA 2635 (IV26) . . . 29
1.33 Vac Valve: VVPG ESA0 4195 POSITION (IV41) . . . 29

2 Ignored when A-Line Kicker Is Not Enabled, TD11 Is In, YAG01 Is In, or YAG02 Is In **30**
2.1 A-Line SL10 Position . . . 30
2.2 Flowswitch: BPM BSYA 1020 (BPM10) . . . 30
2.3 Flowswitch: BPM BSYA 1240 (BPM12) . . . 31

2.4 Flowswitch: COLL BSYA 1015 (PC10) . . . 31
2.5 Flowswitch: COLL BSYA 1230 (PC12) . . . 31
2.6 Flowswitch: COLL BSYA 1490 (PC14) . . . 31
2.7 Flowswitch: COLL BSYA 1700 (PC17) . . . 32
2.8 PIC Raw Charge Thresholds: BSYA 1016 . . . 32
2.9 PIC Raw Charge Thresholds: BSYA 1021 . . . 32
2.10 PIC Raw Charge Thresholds: BSYA 1120 . . . 33
2.11 PIC Raw Charge Thresholds: BSYA 1320 . . . 33
2.12 PIC Raw Charge Thresholds: BSYA 1520 . . . 33
2.13 PIC Raw Charge Thresholds: BSYA 1701A . . . 34
2.14 PIC Raw Charge Thresholds: BSYA 1701B . . . 34
2.15 PIC Raw Charge Thresholds: BSYA 1980 . . . 34
2.16 Temperature RTD Summary: A-Line Before SL10 . . . 35
2.17 Vac Valve: VVFS BSYA 1030 (FV10) . . . 35
2.18 Vac Valve: VVPG BSYA 1018 (IV10) . . . 35
2.19 VVPG BSYA 340 Position . . . 35

3 Ignored when BX01/BX02 Is Off, YAG01 Is In, or YAG02 Is In 36
3.1 Toroid Comparator Dogleg 1 (IM02 vs IM03) . . . 36

4 Ignored when BX01/BX02 Is On, YAG01 Is In, or YAG02 Is In 37
4.1 BXS Status . . . 37
4.2 Toroid Comparator Inj Spectrometer (IM02 vs IMS1) . . . 37

5 Ignored when BXG Is Off or YAG01 Is In 38
5.1 Wakefield Shield Gun Spectrometer . . . 38

6 Ignored when BXG Is On or YAG01 Is In 39
6.1 Wakefield Shield Straight Ahead . . . 39

7 Ignored when Diag Stopper HFX DG2 Is In, Diag Stopper HFX UM6 Is In, Diag Stopper XCS SB1 Is In, Stopper SH1 Is In, Stopper SH2 Is In, Stopper XRT S5 Is In, Stopper: BSY D2 Summary Is In, TD11 Is In, TDUND Is In, YAG01 Is In, or YAG02 Is In 40
7.1 XCS SB1 VGC 02 Gate Valve Position . . . 40
7.2 XCS SB2 VGC 01 Gate Valve Position . . . 40

8 Ignored when Diag Stopper HFX DG2 Is In, Diag Stopper HFX UM6 Is In, Stopper S5B Is In, Stopper SH1 Is In, Stopper SH2 Is In, Stopper XRT S5 Is In, Stopper: BSY D2 Summary Is In, TD11 Is In, TDUND Is In, YAG01 Is In, or YAG02 Is In 41
8.1 CXI Configuration 1 Summary . . . 41
8.2 CXI Configuration 2 Summary . . . 42
8.3 CXI Configuration 3 Summary . . . 43
8.4 CXI Configuration 4 Summary . . . 45
8.5 CXI Configuration 5 Summary . . . 46
8.6 CXI Configuration 6 Summary . . . 47
8.7 CXI Configuration 7 Summary . . . 48

8.8 CXI KB2 VGC 02 Gate Valve Position . . . 49
8.9 CXI MPS PLC Readiness Status . . . 49
8.10 CXI User Patch Panel 1 Ready . . . 50
8.11 CXI User Patch Panel 2 Ready . . . 50
8.12 CXI:DG1:VGC:01 Gate Valve Open Position . . . 50
8.13 CXI:DG1:VGC:02 Gate Valve Open Position . . . 50
8.14 CXI:DG2:VGC:01 Gate Valve Position . . . 51
8.15 CXI:DG2:VGC:02 Gate Valve Position . . . 51
8.16 CXI:DG4:VGC:01 Gate Valve Position . . . 51
8.17 CXI:DSC:VGC:01 Gate Valve Position . . . 52
8.18 CXI:KB1:VGC:01 Gate Valve Open Position . . . 52
8.19 CXI:KB1:VGC:02 Gate Valve Open Position . . . 52
8.20 CXI:KB2:VGC:01 Gate Valve Open Position . . . 52
8.21 CXI:SC1:VGC:01 Gate Valve Position . . . 53
8.22 CXI:SC3:VGC:01 Be Gate Valve Position - Status from PLC . . . 53
8.23 HF4 LAM VGC 01 Gate Valve Position . . . 53

9 Ignored when Diag Stopper HFX DG2 Is In, Diag Stopper HFX UM6 Is In, Stopper SH1 Is In, Stopper SH2 Is In, Stopper XRT S5 Is In, Stopper: BSY D2 Summary Is In, TD11 Is In, TDUND Is In, YAG01 Is In, or YAG02 Is In 54
9.1 CXI XRT Laser Reference Mirror Position . . . 54
9.2 HFA:SND:VGC:01 Gate Valve Open Position . . . 54
9.3 HFX:DIA:VGC:02 Gate Valve Open Position . . . 54
9.4 PPS Stopper S5B Position . . . 55
9.5 XCS SB1 Diagnostic Stopper Position . . . 55
9.6 XCS SB1 VGC 01 Gate Valve Position . . . 55
9.7 XRT HXRAY DIA Isolation Valve HXX-DIA-VGC-01 . . . 56

10 Ignored when Diag Stopper HFX DG2 Is In, Diag Stopper HFX UM6 Is In, Stopper SH1 Is In, Stopper SH2 Is In, Stopper: BSY D2 Summary Is In, TD11 Is In, TDUND Is In, YAG01 Is In, or YAG02 Is In 57
10.1 HFX:DG2:VGC:01 Gate Valve Position . . . 57
10.2 HFX:MON:VGC:01 Gate Valve Position . . . 57
10.3 HFX:MON:VGC:02 Gate Valve Position . . . 57
10.4 Stopper XRT S5 Position . . . 58

11 Ignored when Diag Stopper HFX UM6 Is In, Stopper MFX S4.5 Is In, Stopper SH1 Is In, Stopper SH2 Is In, Stopper: BSY D2 Summary Is In, TD11 Is In, TDUND Is In, YAG01 Is In, or YAG02 Is In 59
11.1 MFX MPS Summary - Downstream of Stopper 4.5 . . . 59

12 Ignored when Diag Stopper HFX UM6 Is In, Stopper SH1 Is In, Stopper SH2 Is In, Stopper XRT S6 Is In, Stopper: BSY D2 Summary Is In, TD11 Is In, TDUND Is In, YAG01 Is In, or YAG02 Is In 60
12.1 MEC DV4 VCG 01 Gate Valve Position . . . 60

12.2 MEC DV5 VGC 01 Gate Valve Position . . . 60
12.3 MEC HXM VGC 01 Gate Valve Position . . . 60
12.4 MEC XT1 Reference Laser Position . . . 61
12.5 MEC XT1 VGC 01 Gate Valve Position . . . 61
12.6 MEC XT2 VGC 02 Gate Valve Position . . . 61
12.7 MEC XT2 VGC 03 Gate Valve Position . . . 61
12.8 MEC XT2 VGC 04 Gate Valve Position . . . 62
12.9 MEC XT2 VGC 05 Gate Valve Position . . . 62
12.10 MEC XT2 VGC 06 Gate Valve Position . . . 62

13 Ignored when Diag Stopper HFX UM6 Is In, Stopper SH1 Is In, Stopper SH2 Is In, Stopper: BSY D2 Summary Is In, TD11 Is In, TDUND Is In, YAG01 Is In, or YAG02 Is In 63
13.1 DG2 Diagnostic Stopper Position . . . 63
13.2 MEC BXL VGC 01 Gate Valve Position . . . 63
13.3 MEC XRT Attenuator Inspection Mirror Position . . . 63
13.4 MFX Gate Valve Summary - Upstream of Stopper 4.5 . . . 64
13.5 Stopper MFX S4.5 Position . . . 64
13.6 Stopper XRT S6 Position . . . 64
13.7 XRT HXRAY LOM Isolation Valve HXX-LOM-VGC-01 . . . 65
13.8 XRT HXRAY MXT Gate Valve HXX:MXT:VGC:01 . . . 65
13.9 XRT HXRAY MXT Gate Valve HXX:MXT:VGC:02 . . . 65
13.10 XRT HXRAY MXT Gate Valve HXX:MXT:VGC:03 . . . 66
13.11 XRT HXRAY MXT Gate Valve HXX:MXT:VGC:05 . . . 66
13.12 XRT-M2 Mirror and DG2 STP Fault . . . 66

14 Ignored when Laser Heater Attenuator Is In 67
14.1 Laser Heater Photodiode Shutter Position . . . 67
14.2 OTRH1 Position When LH Atten Not In . . . 67
14.3 OTRH2 Position When LH Atten Not In . . . 67

15 Ignored when Stopper S1 Is In, Stopper: BSY D2 Summary Is In, TD11 Is In, TDUND Is In, YAG01 Is In, or YAG02 Is In 68
15.1 NEH AMO Laser Reference Mirror Position . . . 68
15.2 NEH AMO Valves Ok for Beam - Summary From PLC . . . 68
15.3 NEH1 Camera 1124 Position . . . 68
15.4 NEH1 XTOD S1 Isolation Valve Summary . . . 69

16 Ignored when Stopper S2 Is In, Stopper S2B Is In, Stopper: BSY D2 Summary Is In, TD11 Is In, TDUND Is In, YAG01 Is In, or YAG02 Is In 70
16.1 NEH SXR Differential Pump Isolation Valve SXR-DFP-VGC-01 . . . 70
16.2 NEH SXR End Station Ready SXR-EXP-MPS-01 . . . 70
16.3 NEH SXR Intensity Monitor Isolation Valve SXR-FLX-VGC-01 . . . 70
16.4 NEH SXR KB Optics Isolation Valve SXR-KBO-VGC-01 . . . 71
16.5 NEH SXR Laser In-coupling Mirror Isolation Valve SXR-LIN-VGC-01 . . . 71

17 Ignored when Stopper S2 Is In, Stopper: BSY D2 Summary Is In, TD11 Is In, TDUND Is In, YAG01 Is In, or YAG02 Is In **72**
17.1 NEH Camera 2124 Position . . . 72
17.2 NEH SXR Collimator 3 Isolation Valve SXR-COL-VGC-01 . . . 72
17.3 NEH SXR Exit Slits Isolation Valve SXR-EXS-VGC-01 . . . 73
17.4 NEH SXR GMD VGC 01 Protection . . . 73
17.5 NEH SXR Monochromator Tank Isolation Valve SXR-MON-VGC-01 . . . 73
17.6 NEH SXR Photon Stoppers Isolation Valve SXR-PST-VGC-01 . . . 74
17.7 NEH SXR Transmission Sample System Isolation Valve SXR-TSS-VGC-01 . . . 74
17.8 NEH SXR Zero Order Interlock SXR-MON-MMS-06, SXR-EXS-MMS-01 . . . 74
17.9 NEH1 XTOD S2 Isolation Valve Summary . . . 75

18 Ignored when Stopper SH1 Is In, Stopper SH2 Is In, Stopper: BSY D2 Summary Is In, TD11 Is In, TDUND Is In, YAG01 Is In, or YAG02 Is In **76**
18.1 UM6 Diagnostic Stopper Position . . . 76
18.2 XRT HXRAY UM6 Isolation Valve HXX-UM6-VGC-01 . . . 76
18.3 XRT UM6 Camera Position HXX-UM6-CVP-01 . . . 77

19 Ignored when Stopper SH1 Is In, Stopper: BSY D2 Summary Is In, TD11 Is In, TDUND Is In, XPP-NH3-POS-00 Beamline Is In, YAG01 Is In, or YAG02 Is In **78**
19.1 NEH3 HXRAY DVD Isolation Valve HX3-DVD-VGC-01 . . . 78

20 Ignored when Stopper SH1 Is In, Stopper: BSY D2 Summary Is In, TD11 Is In, TDUND Is In, XPP-NH3-POS-00 Beamline Is Not In, YAG01 Is In, or YAG02 Is In **79**
20.1 XPP SB2 VGC 01 Gate Valve Position . . . 79
20.2 XPP SB2 VGC 02 Gate Valve Position . . . 79
20.3 XPP SB2 VGC 03 Gate Valve Position . . . 79

21 Ignored when Stopper SH1 Is In, Stopper: BSY D2 Summary Is In, TD11 Is In, TDUND Is In, YAG01 Is In, or YAG02 Is In **80**
21.1 HX2 UVD VGC 01 Gate Valve Position . . . 80
21.2 HX3 MON VGC 01 Gate Valve Position . . . 80
21.3 NEH HXTD Vacuum Valve Summary . . . 80
21.4 NEH1 Camera 124 Position . . . 81
21.5 NEH1 Camera 195 Position . . . 81
21.6 NEH2 HXRAY DVD Isolation Valve HX2-DVD-VGC-01 . . . 81
21.7 NEH3 HXRAY UVD Isolation Valve HX3-UVD-VGC-01 . . . 82

22 Ignored when Stopper: BSY D2 Summary Is In or TDUND Is In **83**
22.1 HXRSS Beamline Position . . . 83
22.2 HXRSS Chicane Bend Magnet Power Supply . . . 83
22.3 HXRSS Crystal Position . . . 83
22.4 HXRSS Crystal Valid Position . . . 84
22.5 HXRSS Mode State . . . 84
22.6 SXRSS Grating/M1 GRAT UND1 934 Position . . . 86

22.7 SXRSS M2 MIRR UND1 964 Position . . . 86
22.8 SXRSS M3 MIRR UND1 966 Position . . . 87
22.9 SXRSS Mode State . . . 87
22.10 SXRSS SLIT UND1 962 Position . . . 90
22.11 SXRSS Watchdog . . . 90

23 Ignored when Stopper: BSY D2 Summary Is In, TD11 Is In, TDUND Is In, YAG01 Is In, or YAG02 Is In 91
23.1 BCS PIC RAW Charge Threshold DMP 997 . . . 91
23.2 BCS PIC RAW Charge Threshold DMP 998 . . . 91
23.3 BFW 1010 Position . . . 91
23.4 BFW 110 Position . . . 92
23.5 BFW 1110 Position . . . 92
23.6 BFW 1210 Position . . . 92
23.7 BFW 1310 Position . . . 93
23.8 BFW 1410 Position . . . 93
23.9 BFW 1510 Position . . . 93
23.10 BFW 1610 Position . . . 94
23.11 BFW 1710 Position . . . 94
23.12 BFW 1810 Position . . . 94
23.13 BFW 1910 Position . . . 95
23.14 BFW 2010 Position . . . 95
23.15 BFW 210 Position . . . 95
23.16 BFW 2110 Position . . . 96
23.17 BFW 2210 Position . . . 96
23.18 BFW 2310 Position . . . 96
23.19 BFW 2410 Position . . . 97
23.20 BFW 2510 Position . . . 97
23.21 BFW 2610 Position . . . 97
23.22 BFW 2710 Position . . . 98
23.23 BFW 2810 Position . . . 98
23.24 BFW 2910 Position . . . 98
23.25 BFW 3010 Position . . . 99
23.26 BFW 310 Position . . . 99
23.27 BFW 3110 Position . . . 99
23.28 BFW 3210 Position . . . 100
23.29 BFW 3310 Position . . . 100
23.30 BFW 410 Position . . . 100
23.31 BFW 510 Position . . . 101
23.32 BFW 610 Position . . . 101
23.33 BFW 710 Position . . . 101
23.34 BFW 810 Position . . . 102
23.35 BFW 910 Position . . . 102
23.36 BFW Inserted Count . . . 102
23.37 BLM Argonne Heartbeat (LN32) . . . 104

23.38 BLM Argonne Heartbeat (LN33) . . . 104
23.39 BLM Argonne Heartbeat (LN35) . . . 104
23.40 BLM Argonne Heartbeat (LN36) . . . 105
23.41 BLM Argonne Heartbeat (LN37) . . . 105
23.42 BLM HVPS UND1 120 . . . 105
23.43 BLM HVPS UND1 1720 . . . 106
23.44 BLM HVPS UND1 2221 . . . 106
23.45 BLM HVPS UND1 2520 . . . 106
23.46 BLM HVPS UND1 3320 . . . 107
23.47 BLM HVPS UND1 920 . . . 107
23.48 BLM Pedestal Thresholds: LTU1 722 . . . 107
23.49 BLM Pedestal Thresholds: LTU1 732 . . . 108
23.50 BLM Pedestal Thresholds: LTU1 762 . . . 108
23.51 BLM Pedestal Thresholds: LTU1 772 . . . 108
23.52 BLM Pedestal Thresholds: LTU1 980 . . . 109
23.53 BLM Pedestal Thresholds: UND 1021 . . . 109
23.54 BLM Pedestal Thresholds: UND 1121 . . . 109
23.55 BLM Pedestal Thresholds: UND 120 . . . 110
23.56 BLM Pedestal Thresholds: UND 121 . . . 110
23.57 BLM Pedestal Thresholds: UND 1221 . . . 110
23.58 BLM Pedestal Thresholds: UND 1321 . . . 111
23.59 BLM Pedestal Thresholds: UND 1421 . . . 111
23.60 BLM Pedestal Thresholds: UND 1521 . . . 111
23.61 BLM Pedestal Thresholds: UND 1621 . . . 112
23.62 BLM Pedestal Thresholds: UND 1720 . . . 112
23.63 BLM Pedestal Thresholds: UND 1721 . . . 112
23.64 BLM Pedestal Thresholds: UND 1821 . . . 113
23.65 BLM Pedestal Thresholds: UND 1921 . . . 113
23.66 BLM Pedestal Thresholds: UND 2021 . . . 113
23.67 BLM Pedestal Thresholds: UND 2121 . . . 114
23.68 BLM Pedestal Thresholds: UND 221 . . . 114
23.69 BLM Pedestal Thresholds: UND 2221 . . . 114
23.70 BLM Pedestal Thresholds: UND 2321 . . . 115
23.71 BLM Pedestal Thresholds: UND 2421 . . . 115
23.72 BLM Pedestal Thresholds: UND 2520 . . . 115
23.73 BLM Pedestal Thresholds: UND 2521 . . . 116
23.74 BLM Pedestal Thresholds: UND 2621 . . . 116
23.75 BLM Pedestal Thresholds: UND 2721 . . . 116
23.76 BLM Pedestal Thresholds: UND 2821 . . . 117
23.77 BLM Pedestal Thresholds: UND 2921 . . . 117
23.78 BLM Pedestal Thresholds: UND 3021 . . . 117
23.79 BLM Pedestal Thresholds: UND 3121 . . . 118
23.80 BLM Pedestal Thresholds: UND 321 . . . 118
23.81 BLM Pedestal Thresholds: UND 3221 . . . 118
23.82 BLM Pedestal Thresholds: UND 3320 . . . 119

23.83 BLM Pedestal Thresholds: UND 3321 . . . 119
23.84 BLM Pedestal Thresholds: UND 421 . . . 119
23.85 BLM Pedestal Thresholds: UND 521 . . . 120
23.86 BLM Pedestal Thresholds: UND 621 . . . 120
23.87 BLM Pedestal Thresholds: UND 721 . . . 120
23.88 BLM Pedestal Thresholds: UND 821 . . . 121
23.89 BLM Pedestal Thresholds: UND 920 . . . 121
23.90 BLM Pedestal Thresholds: UND 921 . . . 121
23.91 BLM Pedestal Thresholds: UND BLF1 . . . 122
23.92 BLM Pedestal Thresholds: UND BLF17 . . . 122
23.93 BLM PEP Timing Check (LN32) . . . 122
23.94 BLM PEP Timing Check (LN33) . . . 123
23.95 BLM PEP Timing Check (LN35) . . . 123
23.96 BLM PEP Timing Check (LN36) . . . 123
23.97 BLM PEP Timing Check (LN37) . . . 124
23.98 BLM Raw Charge Thresholds: LTU1 722 . . . 124
23.99 BLM Raw Charge Thresholds: LTU1 732 . . . 124
23.100 BLM Raw Charge Thresholds: LTU1 762 . . . 125
23.101 BLM Raw Charge Thresholds: LTU1 772 . . . 125
23.102 BLM Raw Charge Thresholds: LTU1 980 . . . 125
23.103 BLM Raw Charge Thresholds: UND 1021 . . . 126
23.104 BLM Raw Charge Thresholds: UND 1121 . . . 126
23.105 BLM Raw Charge Thresholds: UND 120 . . . 126
23.106 BLM Raw Charge Thresholds: UND 121 . . . 127
23.107 BLM Raw Charge Thresholds: UND 1221 . . . 127
23.108 BLM Raw Charge Thresholds: UND 1321 . . . 127
23.109 BLM Raw Charge Thresholds: UND 1421 . . . 128
23.110 BLM Raw Charge Thresholds: UND 1521 . . . 128
23.111 BLM Raw Charge Thresholds: UND 1621 . . . 128
23.112 BLM Raw Charge Thresholds: UND 1720 . . . 129
23.113 BLM Raw Charge Thresholds: UND 1721 . . . 129
23.114 BLM Raw Charge Thresholds: UND 1821 . . . 129
23.115 BLM Raw Charge Thresholds: UND 1921 . . . 130
23.116 BLM Raw Charge Thresholds: UND 2021 . . . 130
23.117 BLM Raw Charge Thresholds: UND 2121 . . . 130
23.118 BLM Raw Charge Thresholds: UND 221 . . . 131
23.119 BLM Raw Charge Thresholds: UND 2221 . . . 131
23.120 BLM Raw Charge Thresholds: UND 2321 . . . 131
23.121 BLM Raw Charge Thresholds: UND 2421 . . . 132
23.122 BLM Raw Charge Thresholds: UND 2520 . . . 132
23.123 BLM Raw Charge Thresholds: UND 2521 . . . 132
23.124 BLM Raw Charge Thresholds: UND 2621 . . . 133
23.125 BLM Raw Charge Thresholds: UND 2721 . . . 133
23.126 BLM Raw Charge Thresholds: UND 2821 . . . 133
23.127 BLM Raw Charge Thresholds: UND 2921 . . . 134

23.128 BLM Raw Charge Thresholds: UND 3021 . . . 134
23.129 BLM Raw Charge Thresholds: UND 3121 . . . 134
23.130 BLM Raw Charge Thresholds: UND 321 . . . 135
23.131 BLM Raw Charge Thresholds: UND 3221 . . . 135
23.132 BLM Raw Charge Thresholds: UND 3320 . . . 135
23.133 BLM Raw Charge Thresholds: UND 3321 . . . 136
23.134 BLM Raw Charge Thresholds: UND 421 . . . 136
23.135 BLM Raw Charge Thresholds: UND 521 . . . 136
23.136 BLM Raw Charge Thresholds: UND 621 . . . 137
23.137 BLM Raw Charge Thresholds: UND 721 . . . 137
23.138 BLM Raw Charge Thresholds: UND 821 . . . 137
23.139 BLM Raw Charge Thresholds: UND 920 . . . 138
23.140 BLM Raw Charge Thresholds: UND 921 . . . 138
23.141 BLM Raw Charge Thresholds: UND BLF1 . . . 138
23.142 BLM Raw Charge Thresholds: UND BLF17 . . . 139
23.143 BLM Trigger Missed (LN32) . . . 139
23.144 BLM Trigger Missed (LN33) . . . 139
23.145 BLM Trigger Missed (LN35) . . . 139
23.146 BLM Trigger Missed (LN36) . . . 140
23.147 BLM Trigger Missed (LN37) . . . 140
23.148 BLM/PIC Watchdog: Downstream of TDUND . . . 140
23.149 BOD UND1 1005 . . . 140
23.150 BOD UND1 1305 . . . 141
23.151 BPM Summary (1-9) - Status From IOC-UND1-BP01 . . . 141
23.152 BPM Summary (10-18) - Status From IOC-UND1-BP02 . . . 141
23.153 BPM Summary (19-27) - Status From IOC-UND1-BP03 . . . 141
23.154 BPM Summary (28-36) - Status From IOC-UND1-BP04 . . . 142
23.155 FEE Camera 1692 Position . . . 142
23.156 FEE Camera 1953 Position . . . 142
23.157 FEE Camera 2953 Position . . . 143
23.158 FEE Camera 852 Position Fault - Status From PLC . . . 143
23.159 FEE Camera 913 Position Fault - Status From PLC . . . 143
23.160 FEE Gas System Summary . . . 143
23.161 FEE HXTD Vacuum Valve Summary . . . 144
23.162 FEE M1S Mirror Beam Energy Upper Limit . . . 144
23.163 FEE M1S Mirror State . . . 144
23.164 FEE Spectrometer Crystal - Beam Energy Too Low When Crystal Not Out . . . 145
23.165 FEE Spectrometer Crystal - Pulse Energy Too High When Crystal Not Out . . . 145
23.166 FEE XTOD S1 Isolation Valve Summary . . . 145
23.167 FEE XTOD S2 Isolation Valve Summary . . . 146
23.168 Gas Detector Problem When FEE Spectrometer Crystal Not Out . . . 146
23.169 HXR - Beam Energy Too Low With M1S Out . . . 146
23.170 Magnet In Tolerance: QE31 . . . 147
23.171 Magnet In Tolerance: QUM1 . . . 147
23.172 Magnet In Tolerance: QUM2 . . . 147

23.173 Magnet In Tolerance: QUM3 . . . 147
23.174 Magnet In Tolerance: QUM4 . . . 148
23.175 Magnet Power: QE31 . . . 148
23.176 Magnet Power: QUM1 . . . 148
23.177 Magnet Power: QUM2 . . . 148
23.178 Magnet Power: QUM3 . . . 149
23.179 Magnet Power: QUM4 . . . 149
23.180 OTR01 IN20 541 Position and TDUND Not In . . . 149
23.181 OTR02 IN20 571 Position and TDUND Not In . . . 150
23.182 OTR03 IN20 621 Position and TDUND Not In . . . 150
23.183 OTR04 IN20 711 Position and TDUND Not In . . . 150
23.184 OTR11 LI21 237 Position and TDUND Not In . . . 151
23.185 OTR12 LI21 291 Position and TDUND Not In . . . 151
23.186 OTR21 Position When TDUND Not In . . . 151
23.187 OTR33 Position When TDUND Not In . . . 152
23.188 OTRH1 Position When TDUND Not In . . . 152
23.189 OTRH2 Position When TDUND Not In . . . 152
23.190 PIC HVPS B921 - Location B921-2235 . . . 153
23.191 PIC Raw Charge Thresholds: DMP1 698 . . . 153
23.192 PIC Raw Charge Thresholds: DMP1 699 . . . 153
23.193 PIC Trigger Missed (LN34) . . . 153
23.194 Toroid Comparator Dump (IMUNDO vs IMDUMP) . . . 154
23.195 Toroid Comparator Power Status (B921) . . . 154
23.196 Toroid Comparator Undulator (IMUNDI vs IMUNDO) . . . 154
23.197 VVFS DMP1 107 Position . . . 155
23.198 VVMG DMP1 743 Position . . . 155
23.199 VVMG UND1 1645 Position . . . 155
23.200 VVMG UND1 1655 Position . . . 155
23.201 VVPG DMP1 355 Position . . . 156
23.202 XLEAP PRXL1 - YAGS LTU1 844 Position and TDUND Not In . . . 156
23.203 XLEAP PRXL2 - YAGS LTU1 853 Position and TDUND Not In . . . 156
23.204 XLEAP PRXL3 - OTRS LTU1 858 Position and TDUND Not In . . . 157
23.205 YAG LTU1 743 Position When TDUND Not In (PSI Prof Mon) . . . 157

24 Ignored when Stopper: BSY D2 Summary Is In, TD11 Is In, YAG01 Is In, or YAG02 Is In 158
24.1 BCS LION LTU1 404 Threshold . . . 158
24.2 BCS LION LTU1 405 Threshold . . . 158
24.3 BCS LION LTU1 504 Threshold . . . 158
24.4 BCS LION LTU1 505 Threshold . . . 158
24.5 BCS LION LTU1 584 Threshold . . . 159
24.6 BCS LION LTU1 585 Threshold . . . 159
24.7 BCS LION LTU1 716 Threshold . . . 159
24.8 BCS LION LTU1 717 Threshold . . . 159
24.9 BCS LION LTU1 732 Threshold . . . 160
24.10 BCS LION LTU1 733 Threshold . . . 160

24.11 BCS LION LTU1 752 Threshold . . . 160
24.12 BCS LION LTU1 753 Threshold . . . 160
24.13 BCS LION LTU1 765 Threshold . . . 161
24.14 BCS LION LTU1 766 Threshold . . . 161
24.15 BLM Heartbeat: Dechirper LTU1 BLF545 . . . 161
24.16 BLM Heartbeat: XLEAP LTU1 BLF859 . . . 161
24.17 BLM HVPS LTU1 762 . . . 162
24.18 BLM Pedestal Thresholds: Dechirper LTU1 BLF545 . . . 162
24.19 BLM Pedestal Thresholds: XLEAP LTU1 BLF859 . . . 162
24.20 BLM PEP Timing Check (LN30) . . . 163
24.21 BLM Raw Charge Thresholds: Dechirper LTU1 BLF545 . . . 163
24.22 BLM Raw Charge Thresholds: XLEAP LTU1 BLF859 . . . 163
24.23 BLM Timing Check (LN30) . . . 164
24.24 BLM Trigger Missed (LN30) . . . 164
24.25 BYD Watchdog . . . 164
24.26 BYKIK 120 Hz Abort Trigger . . . 165
24.27 BYKIK 120 Hz Standby Trigger . . . 165
24.28 BYKIK 30 Hz Abort Trigger . . . 165
24.29 BYKIK 30 Hz Standby Trigger . . . 165
24.30 BYKIK Readback Signal . . . 166
24.31 LTU Dechirper - Horizontal Gap Too Small . . . 166
24.32 LTU Dechirper - MIRR LTU1 548 Position (MIRDVDHCP) . . . 166
24.33 LTU Dechirper - Vertical Gap Too Small . . . 167
24.34 Magnet In Tolerance: BYD1 . . . 167
24.35 Magnet Power: BYD1 . . . 167
24.36 OTR33 Position . . . 167
24.37 PIC HVPS B911 - Location B911-2135 . . . 168
24.38 PIC HVPS B912 - Location B912-2135 . . . 168
24.39 PIC HVPS B913 - Location B913-2135 . . . 168
24.40 PIC Raw Charge Thresholds: LTU1 220 . . . 168
24.41 PIC Raw Charge Thresholds: LTU1 252 . . . 169
24.42 PIC Raw Charge Thresholds: LTU1 280 . . . 169
24.43 PIC Raw Charge Thresholds: LTU1 420 . . . 169
24.44 PIC Raw Charge Thresholds: LTU1 450 . . . 170
24.45 PIC Raw Charge Thresholds: LTU1 480 . . . 170
24.46 PIC Raw Charge Thresholds: LTU1 722 . . . 170
24.47 PIC Raw Charge Thresholds: LTU1 732 . . . 171
24.48 PIC Raw Charge Thresholds: LTU1 762 . . . 171
24.49 PIC Raw Charge Thresholds: LTU1 772 . . . 171
24.50 PIC Trigger Missed (LN28) . . . 172
24.51 PIC Trigger Missed (LN29) . . . 172
24.52 PIC Trigger Missed (LN31) . . . 172
24.53 TDUND Flow Switch Fault With TDUND Not Out . . . 172
24.54 TDUND Position . . . 173
24.55 THZ-2 Position . . . 173

24.56 Undulator Beam Energy Lower Limit . . . 173
24.57 VVFS LTU1 102 Position . . . 173
24.58 VVMG LTU1 174 Position . . . 174
24.59 VVMG LTU1 355 Position . . . 174
24.60 VVMG LTU1 505 Position . . . 174
24.61 VVMG LTU1 670 Position . . . 174
24.62 VVMG LTU1 742 Position . . . 175
24.63 VVMG LTU1 774 Position . . . 175
24.64 VVMG UND1 932 Position . . . 175
24.65 VVMG UND1 968 Position . . . 175
24.66 VVPG DMP1 103 Position . . . 176
24.67 VVPG DMP1 395 Position . . . 176
24.68 VVPG DMP1 700 Position . . . 176
24.69 VVPG LTU1 100 Position . . . 176
24.70 VVPG LTU1 265 Position . . . 177
24.71 VVPG LTU1 435 Position . . . 177
24.72 VVPG LTU1 580 Position . . . 177
24.73 VVPG LTU1 725 Position . . . 177
24.74 VVPG LTU1 757 Position . . . 178
24.75 VVPG LTU1 999 Position . . . 178
24.76 VVPG UND1 1000 Position . . . 178
24.77 VVPG UND1 2500 Position . . . 178
24.78 XLEAP MIRXL - MIRR LTU1 829 Position . . . 179
24.79 XLEAP PRXL1 - YAGS LTU1 844 Position . . . 179
24.80 XLEAP PRXL2 - YAGS LTU1 853 Position . . . 179
24.81 XLEAP PRXL3 - OTRS LTU1 858 Position . . . 180
24.82 YAG LTU1 743 Position (PSI Prof Mon) . . . 180

25 Ignored when TD11 Is In, YAG01 Is In, or YAG02 Is In 181
25.1 BLM/PIC Watchdog BSY0/BSYA . . . 181
25.2 BLM/PIC Watchdog LI24 . . . 181
25.3 BLM/PIC Watchdog LI30 . . . 181
25.4 Bunch Length Monitor BL21 Position . . . 182
25.5 Dump LI28 5879 Flowswitch . . . 182
25.6 Dump LI28 5879 Klixon . . . 182
25.7 Flowswitch: BSY RAD LCW Slit 10/30 . . . 182
25.8 Flowswitch: CE21 . . . 183
25.9 Flowswitch: COLL BSYH 479, 487, 495, 503 (PCAPM1-4) . . . 183
25.10 Flowswitch: COLL LI28-9 . . . 183
25.11 Flowswitch: COLL LI29-1 . . . 183
25.12 Flowswitch: COLL LI29-4 . . . 184
25.13 Flowswitch: COLL LI29-5 . . . 184
25.14 Flowswitch: COLL LI29-9 . . . 184
25.15 Flowswitch: COLL LI30-1 . . . 184
25.16 Flowswitch: COLL LI30-4 . . . 185

25.17 Flowswitch: COLL LI30-5 . . . 185
25.18 Hydrogen Recombiner For BSY 1 Collimator . . . 185
25.19 Hydrogen Recombiner For BSY 2 Slit 10/30 . . . 185
25.20 KICK BSYH 475 PM1 State (A-Line Kicker) . . . 186
25.21 KICK BSYH 475 PM1 Trigger State (A-Line Kicker) . . . 186
25.22 KICK BSYH 491 PM3 State (A-Line Kicker) . . . 186
25.23 KICK BSYH 491 PM3 Trigger State (A-Line Kicker) . . . 187
25.24 Main Manifold Gauge: LI22 Station 5 . . . 187
25.25 Main Manifold Gauge: LI23 Station 5 . . . 187
25.26 Main Manifold Gauge: LI24 Station 5 . . . 187
25.27 Main Manifold Gauge: LI25 Station 5 . . . 188
25.28 Main Manifold Gauge: LI26 Station 5 . . . 188
25.29 Main Manifold Gauge: LI27 Station 5 . . . 188
25.30 Main Manifold Gauge: LI28 Station 5 . . . 188
25.31 Main Manifold Gauge: LI29 Station 5 . . . 189
25.32 Main Manifold Gauge: LI30 Station 5 . . . 189
25.33 OTR LI25 920 Position . . . 189
25.34 OTR21 Position . . . 189
25.35 PIC Gas Pressure LI24 . . . 190
25.36 PIC HVPS BSY 1 - Location B005-3921 . . . 190
25.37 PIC HVPS BSY 2 - Location B005-3921 . . . 190
25.38 PIC HVPS BSY 3 - Location B005-3921 . . . 190
25.39 PIC HVPS BSY 4 - Location B005-3918 . . . 191
25.40 PIC HVPS BSY 5 - Location B005-3918 . . . 191
25.41 PIC HVPS BSY 6 - Location B005-3918 . . . 191
25.42 PIC HVPS LI24 - Location LKF24-0235 . . . 191
25.43 PIC HVPS LI30 - KG30-C1322 . . . 192
25.44 PIC Raw Charge Thresholds: BSYH 479 (PCAPM1) . . . 192
25.45 PIC Raw Charge Thresholds: BSYH 487 (PCAPM2) . . . 192
25.46 PIC Raw Charge Thresholds: BSYH 495 (PCAPM3) . . . 193
25.47 PIC Raw Charge Thresholds: BSYH 503 (PCAPM4) . . . 193
25.48 PIC Raw Charge Thresholds: BSYH 762 (PC90) . . . 193
25.49 PIC Raw Charge Thresholds: BSYH 836 (PC119) . . . 194
25.50 PIC Raw Charge Thresholds: LI24 791 . . . 194
25.51 PIC Raw Charge Thresholds: LI24 811 . . . 194
25.52 PIC Raw Charge Thresholds: LI28 916 . . . 195
25.53 PIC Raw Charge Thresholds: LI29 146 . . . 195
25.54 PIC Raw Charge Thresholds: LI29 446 . . . 195
25.55 PIC Raw Charge Thresholds: LI29 546 . . . 196
25.56 PIC Raw Charge Thresholds: LI29 801 . . . 196
25.57 PIC Raw Charge Thresholds: LI29 956 . . . 196
25.58 PIC Raw Charge Thresholds: LI30 146 . . . 197
25.59 PIC Raw Charge Thresholds: LI30 446 . . . 197
25.60 PIC Raw Charge Thresholds: LI30 546 . . . 197
25.61 PIC Raw Charge Thresholds: LI30 801 . . . 198

25.62 PIC Trigger Missed (LN16) . . . 198
25.63 PIC Trigger Missed (LN22) . . . 198
25.64 PIC Trigger Missed (LN25) . . . 198
25.65 Scraper Water LI21-9 (Station 22-1) . . . 199
25.66 Scraper Water LI22-9 (Station 23-1) . . . 199
25.67 Scraper Water LI23-9 (Station 24-1) . . . 199
25.68 Scraper Water LI24-9 (Station 25-1) . . . 199
25.69 Scraper Water LI25-9 (Station 26-1) . . . 200
25.70 Scraper Water LI26-9 (Station 27-1) . . . 200
25.71 Scraper Water LI27-9 (Station 28-1) . . . 200
25.72 Scraper Water LI28-9 (Station 29-1) . . . 200
25.73 Scraper Water LI29-9 (Station 30-1) . . . 201
25.74 Stopper LI28 950 and 960 Position . . . 201
25.75 Stopper: BSY D2, 60, 61 DM60 Summary . . . 201
25.76 Sub-booster Ready: LI22 . . . 204
25.77 Sub-booster Ready: LI25 . . . 204
25.78 Sub-booster Ready: LI26 . . . 204
25.79 Sub-booster Ready: LI27 . . . 205
25.80 Sub-booster Ready: LI28 . . . 205
25.81 Sub-booster Ready: LI29 . . . 205
25.82 Sub-booster Ready: LI30 . . . 205
25.83 Temperature RTD Summary: BSY Common Line . . . 206
25.84 Toroid Chassis LI24 IMBC2 . . . 206
25.85 Toroid Comparator BC2 (IMBC2IN vs IMBC2OUT) . . . 206
25.86 VVFS CLTH 101 Position . . . 206
25.87 VVFS LI21-9 Position (Station 22-1) . . . 207
25.88 VVFS LI22-9 Position (Station 23-1) . . . 207
25.89 VVFS LI23-9 Position (Station 24-1) . . . 207
25.90 VVFS LI24-9 Position (Station 25-1) . . . 207
25.91 VVFS LI25-9 Position (Station 26-1) . . . 208
25.92 VVFS LI26-9 Position (Station 27-1) . . . 208
25.93 VVFS LI27-9 Position (Station 28-1) . . . 208
25.94 VVFS LI28-9 Position (Station 29-1) . . . 208
25.95 VVFS LI29-9 Position (Station 30-1) . . . 209
25.96 VVPG BSYH 470 Position . . . 209
25.97 VVPG BSYH 541 Position . . . 209
25.98 VVPG BSYH 837 Position . . . 209
25.99 VVPG CLTH 178 Position . . . 210
25.100 VVPG CLTH 375 Position . . . 210
25.101 VVPG LI21-9 Position (Station 22-1) . . . 210
25.102 VVPG LI22-9 Position (Station 23-1) . . . 210
25.103 VVPG LI23-9 Position (Station 24-1) . . . 211
25.104 VVPG LI24 710 Position . . . 211
25.105 VVPG LI24 896 Position . . . 211
25.106 VVPG LI25-9 Position (Station 26-1) . . . 211

25.107 VVPG LI26-9 Position (Station 27-1) . . . 212
25.108 VVPG LI27-9 Position (Station 28-1) . . . 212
25.109 VVPG LI28-9 Position (Station 29-1) . . . 212
25.110 VVPG LI29-9 Position (Station 30-1) . . . 212
25.111 VVPG LI30-9 Position (Station 30-9) . . . 213

26 Ignored when YAG01 Is In 214
26.1 BXG Status . . . 214
26.2 Toroid Peak Current Monitor IM01 . . . 214
26.3 YAG02 IN20 241 Position . . . 214

27 Ignored when YAG01 Is In or YAG02 Is In 215
27.1 BLM/PIC Watchdog: Upstream of TDUND . . . 215
27.2 BX01/BX02 Status . . . 215
27.3 Flowswitch: CE11 . . . 215
27.4 Flowswitch: TD11 . . . 215
27.5 Main Manifold Gauge: LI21 Station 5 . . . 216
27.6 Mirror BL11 Position . . . 216
27.7 OTR01 IN20 541 Position . . . 216
27.8 OTR02 IN20 571 Position . . . 217
27.9 OTR03 IN20 621 Position . . . 217
27.10 OTR04 IN20 711 Position . . . 217
27.11 OTR11 LI21 237 Position . . . 218
27.12 OTR12 LI21 291 Position . . . 218
27.13 OTRH1 Position . . . 218
27.14 OTRH2 Position . . . 219
27.15 Sub-booster Ready: LI21 . . . 219
27.16 TD11 Position . . . 219
27.17 Toroid Chassis IN20 IM11 . . . 219
27.18 Toroid Chassis IN20 IM12 . . . 220
27.19 Toroid Comparator BC1 (IMBC1IN vs IMBC1OUT) . . . 220
27.20 VVFV IN20 785 Position . . . 220
27.21 VVMG LI21 195 Position . . . 221
27.22 VVPG IN20 435 Position . . . 221
27.23 VVPG IN20 545 Position . . . 221
27.24 VVPG IN20 635 Position . . . 221
27.25 VVPG IN20 915 Position . . . 222
27.26 VVS Circuit Breaker: LI22 . . . 222
27.27 VVS Circuit Breaker: LI24 . . . 222
27.28 VVS Circuit Breaker: LI26 . . . 222
27.29 VVS Circuit Breaker: LI28 . . . 223
27.30 VVS Circuit Breaker: LI30 . . . 223
27.31 YAG03 IN20 351 Position . . . 223
27.32 YAGS1 IN20 921 Position . . . 223
27.33 YAGS2 LI21 995 Position . . . 224

28 Always Evaluated **225**
28.1 Backward Beam Stopper (RST1) . . . 225
28.2 Beam Destination: HXR . . . 225
28.3 Beam Destination: SXR . . . 225
28.4 BLM/PIC Watchdog: IN20 . . . 225
28.5 Bypass Recover . . . 226
28.6 Gun RF Peak Power 20-6 . . . 226
28.7 Gun Waveguide Vacuum Summary . . . 226
28.8 IOC-IN20-MP01 MPS Support IOC Heartbeat . . . 226
28.9 Laser Heater Attenuator Position . . . 227
28.10 MCC Emergency Radiation Stopper . . . 227
28.11 Mechanical Shutter Position . . . 227
28.12 Mirror AM01 Position . . . 227
28.13 MPS Beam Permit: BYKIK . . . 228
28.14 MPS Beam Permit: BYKIKS . . . 228
28.15 MPS Beam Permit: Gun RF . . . 228
28.16 MPS Beam Permit: Gun RF HXR . . . 228
28.17 MPS Beam Permit: Gun RF SXR . . . 229
28.18 MPS Beam Permit: Heater Shutter . . . 229
28.19 MPS Beam Permit: Mechanical Shutter . . . 229
28.20 MPS Mechanical Shutter Position . . . 229
28.21 PIC HVPS LI20 - Location LKG-1535 . . . 230
28.22 PIC Raw Charge Thresholds: IN20 185 . . . 230
28.23 PIC Raw Charge Thresholds: IN20 232 . . . 230
28.24 PIC Raw Charge Thresholds: IN20 245 . . . 231
28.25 PIC Raw Charge Thresholds: IN20 665 . . . 231
28.26 PIC Raw Charge Thresholds: IN20 775 . . . 231
28.27 PIC Raw Charge Thresholds: IN20 933 . . . 232
28.28 PIC Trigger Missed (LN11) . . . 232
28.29 Pockels Cell AND Gate 100 . . . 232
28.30 Pockels Cell AND Gate 200 . . . 232
28.31 Rate Request: BYKIK 1 Hz . . . 233
28.32 Rate Request: BYKIK 10 Hz . . . 233
28.33 Rate Request: BYKIK 30 Hz . . . 233
28.34 Rate Request: BYKIK 60 Hz . . . 233
28.35 Rate Request: BYKIK Burst . . . 234
28.36 Rate Request: BYKIK Single Shot . . . 234
28.37 Rate Request: BYKIKS 1 Hz . . . 234
28.38 Rate Request: BYKIKS 10 Hz . . . 234
28.39 Rate Request: BYKIKS 30 Hz . . . 235
28.40 Rate Request: BYKIKS 60 Hz . . . 235
28.41 Rate Request: BYKIKS Burst . . . 235
28.42 Rate Request: BYKIKS Single Shot . . . 235
28.43 Rate Request: Gun RF HXR 1 Hz . . . 236
28.44 Rate Request: Gun RF HXR 10 Hz . . . 236

28.45 Rate Request: Gun RF HXR 30 Hz . . . 236
28.46 Rate Request: Gun RF HXR 60 Hz . . . 236
28.47 Rate Request: Gun RF HXR Burst . . . 237
28.48 Rate Request: Gun RF HXR Single Shot . . . 237
28.49 Rate Request: Gun RF SXR 1 Hz . . . 237
28.50 Rate Request: Gun RF SXR 10 Hz . . . 237
28.51 Rate Request: Gun RF SXR 30 Hz . . . 238
28.52 Rate Request: Gun RF SXR 60 Hz . . . 238
28.53 Rate Request: Gun RF SXR Burst . . . 238
28.54 Rate Request: Gun RF SXR Single Shot . . . 238
28.55 Rate Request: Pockels Cell 1 Hz . . . 239
28.56 Rate Request: Pockels Cell 10 Hz . . . 239
28.57 Rate Request: Pockels Cell 30 Hz . . . 239
28.58 Rate Request: Pockels Cell 60 Hz . . . 239
28.59 Rate Request: Pockels Cell Burst . . . 240
28.60 Rate Request: Pockels Cell Single Shot . . . 240
28.61 VVMG IN20 175 Position . . . 240
28.62 VVPG IN20 155 Position . . . 240
28.63 VVS Circuit Breaker: LI20 . . . 241
28.64 YAG01 IN20 211 Position . . . 241
28.65 YAGG1 IN20 841 Position . . . 241

29 Ignore Logic 242
29.1 A-Line Kicker Is Not Enabled . . . 242
29.2 A-Line SL10 Is Closed . . . 242
29.3 BX01/BX02 Is Off . . . 242
29.4 BX01/BX02 Is On . . . 242
29.5 BXG Is Off . . . 243
29.6 BXG Is On . . . 243
29.7 Diag Stopper HFX DG2 Is In . . . 243
29.8 Diag Stopper HFX UM6 Is In . . . 243
29.9 Diag Stopper XCS SB1 Is In . . . 244
29.10 Laser Heater Attenuator Is In . . . 244
29.11 LTU Dechirper Is Out . . . 244
29.12 Stopper MFX S4.5 Is In . . . 244
29.13 Stopper S1 Is In . . . 245
29.14 Stopper S2 Is In . . . 245
29.15 Stopper S2B Is In . . . 245
29.16 Stopper S5B Is In . . . 245
29.17 Stopper SH1 Is In . . . 245
29.18 Stopper SH2 Is In . . . 246
29.19 Stopper XRT S5 Is In . . . 246
29.20 Stopper XRT S6 Is In . . . 246
29.21 Stopper: BSY D2 Summary Is In . . . 246
29.22 TD11 Is In . . . 247

29.23 TDUND Is In 247
29.24 XPP-NH3-POS-00 Beamline Is In 247
29.25 XPP-NH3-POS-00 Beamline Is Not In 247
29.26 XRT-M2 Mirror Is Out of Beam 247
29.27 YAG01 Is In 248
29.28 YAG02 Is In 248

1 Ignored when A-Line Kicker Is Not Enabled, A-Line SL10 Is Closed, TD11 Is In, YAG01 Is In, or YAG02 Is In

1.1 Flowswitch: COLL BSYA 2060 (PC20)

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
FAULT	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `COLL_BSYA_2060_FLOW_SW_STATE`

1.2 Flowswitch: COLL BSYA 2410 (COLL24H)

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
FAULT	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `COLL_BSYA_2470_H_FLOW_SW_STATE`

1.3 Flowswitch: COLL BSYA 2410 (COLL24V)

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
FAULT	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `COLL_BSYA_2470_V_FLOW_SW_STATE`

1.4 Flowswitch: COLL BSYA 2410 (PC24)

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
FAULT	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = COLL_BSYA_2410_FLOW_SW_STATE

1.5 Flowswitch: COLL BSYA 2600 (PC26)

Name	A	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
FAULT	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = COLL_BSYA_2600_FLOW_SW_STATE

1.6 Flowswitch: COLL BSYA 2990 (PC29)

Name	A	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
FAULT	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = COLL_BSYA_2990_FLOW_SW_STATE

1.7 Flowswitch: COLL BSYA 3710 (C37)

Name	A	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
FAULT	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = COLL_BSYA_3710_FLOW_SW_STATE

1.8 Flowswitch: COLL BSYA 4120 (3C1A)

Name	A	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
FAULT	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = COLL_ESA0_4120_FLOW_SW_STATE

1.9 PIC Raw Charge Thresholds: BSYA 2061

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `PICM_BSYA_2061_LOSSL_THRESHOLD`,
B = `PICM_BSYA_2061_LOSSH_THRESHOLD`

1.10 PIC Raw Charge Thresholds: BSYA 2120

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `PICM_BSYA_2120_LOSSL_THRESHOLD`,
B = `PICM_BSYA_2120_LOSSH_THRESHOLD`

1.11 PIC Raw Charge Thresholds: BSYA 2220

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `PICM_BSYA_2220_LOSSL_THRESHOLD`,
B = `PICM_BSYA_2220_LOSSH_THRESHOLD`

1.12 PIC Raw Charge Thresholds: BSYA 2321

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `PICM_BSYA_2321_LOSSL_THRESHOLD`,
B = `PICM_BSYA_2321_LOSSH_THRESHOLD`

1.13 PIC Raw Charge Thresholds: BSYA 2411

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `PICM_BSYA_2411_LOSSL_THRESHOLD`,
B = `PICM_BSYA_2411_LOSSH_THRESHOLD`

1.14 PIC Raw Charge Thresholds: BSYA 2472

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `PICM_BSYA_2472_LOSSL_THRESHOLD`,
B = `PICM_BSYA_2472_LOSSH_THRESHOLD`

1.15 PIC Raw Charge Thresholds: BSYA 2473

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `PICM_BSYA_2473_LOSSL_THRESHOLD`,
B = `PICM_BSYA_2473_LOSSH_THRESHOLD`

1.16 PIC Raw Charge Thresholds: BSYA 2474

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `PICM_BSYA_2474_LOSSL_THRESHOLD`,
B = `PICM_BSYA_2474_LOSSH_THRESHOLD`

1.17 PIC Raw Charge Thresholds: BSYA 2475

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `PICM_BSYA_2475_LOSSL_THRESHOLD`,
B = `PICM_BSYA_2475_LOSSH_THRESHOLD`

1.18 PIC Raw Charge Thresholds: BSYA 2520

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `PICM_BSYA_2520_LOSSL_THRESHOLD`,
B = `PICM_BSYA_2520_LOSSH_THRESHOLD`

1.19 PIC Raw Charge Thresholds: BSYA 2601

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `PICM_BSYA_2601_LOSSL_THRESHOLD`,
B = `PICM_BSYA_2601_LOSSH_THRESHOLD`

1.20 PIC Raw Charge Thresholds: BSYA 2861

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `PICM_BSYA_2861_LOSSL_THRESHOLD`,
B = `PICM_BSYA_2861_LOSSH_THRESHOLD`

1.21 PIC Raw Charge Thresholds: BSYA 2990

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = PICM_BSYA_2990_LOSSL_THRESHOLD,
B = PICM_BSYA_2990_LOSSH_THRESHOLD

1.22 PIC Raw Charge Thresholds: BSYA 3320

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = PICM_BSYA_3320_LOSSL_THRESHOLD,
B = PICM_BSYA_3320_LOSSH_THRESHOLD

1.23 PIC Raw Charge Thresholds: BSYA 3720

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = PICM_BSYA_3720_LOSSL_THRESHOLD,
B = PICM_BSYA_3720_LOSSH_THRESHOLD

1.24 PIC Raw Charge Thresholds: BSYA 3721

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = PICM_BSYA_3721_LOSSL_THRESHOLD,
B = PICM_BSYA_3721_LOSSH_THRESHOLD

1.25 PIC Raw Charge Thresholds: BSYA 3890

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = PICM_BSYA_3890_LOSSL_THRESHOLD,
B = PICM_BSYA_3890_LOSSH_THRESHOLD

1.26 PIC Trigger Missed (LN42)

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Missed	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = PICM_BSYA_2061_NO_TRIG_MISSED

1.27 Stopper BSYA 2275 (ST22) Position

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
MOVING	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OUT	F	T	120 Hz	120 Hz	120 Hz	–	–	–	–
IN	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
BROKEN	T	T	0 Hz	0 Hz	0 Hz	–	–	–	–

Where
A = STPR_BSYA_2275_ST22_OUT_LIM_STATE,
B = STPR_BSYA_2275_ST22_IN_LIM_STATE

1.28 Stopper BSYA 2930 (ST29) Position

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
MOVING	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OUT	F	T	120 Hz	120 Hz	120 Hz	–	–	–	–
IN	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Broken	T	T	0 Hz	0 Hz	0 Hz	–	–	–	–

Where
A = STPR_BSYA_2930_ST29_OUT_LIM_STATE,
B = STPR_BSYA_2930_ST29_IN_LIM_STATE

1.29 Temperature RTD Summary: A-line Past SL10

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
FAULT	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = RTD_BSYA_2060_PASTSL10SUM_STATUS

1.30 Vac Valve BSYA 4005 (IV40)

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
FAULT	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = VVPG_BSYA_4005_POSITION_STATE

1.31 Vac Valve: VVFS BSYA 2855 (FV28)

Name	A	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
NOT_OPEN	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OPEN	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = VVFS_BSYA_2855_POSITION_STATE

1.32 Vac Valve: VVPG BSYA 2635 (IV26)

Name	A	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
NOT_OPEN	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OPEN	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = VVPG_BSYA_2635_POSITION_STATE

1.33 Vac Valve: VVPG ESA0 4195 POSITION (IV41)

Name	A	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
FAULT	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = VVPG_ESA0_4195_POSITION_STATE

2 Ignored when A-Line Kicker Is Not Enabled, TD11 Is In, YAG01 Is In, or YAG02 Is In

2.1 A-Line SL10 Position

The following code assigns the truth table's state number to the `unsigned int` variable `state`.

```
state = (unsigned int) -1;

if ( SLIT_BSYA_2010_SL10_FB_IN_STATE &&
        SLIT_BSYA_2010_SL10_FT_IN_STATE &&
        SLIT_BSYA_2010_SL10_RB_IN_STATE &&
        SLIT_BSYA_2010_SL10_RT_IN_STATE )
{
    state = 0; /* SL10 is Closed */
}

else
{
    state = 1; /* SL10 is Not Closed */
}
```

Name	State	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Closed	0	120 Hz	120 Hz	120 Hz	–	–	–	–
Not_Closed	1	120 Hz	120 Hz	120 Hz	–	–	–	–

2.2 Flowswitch: BPM BSYA 1020 (BPM10)

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
IS_NOT_OK	F	0 Hz	0 Hz	–	–	–	–	–
OK	T	120 Hz	120 Hz	–	–	–	–	–

Where
A = `BPM_BSYA_1020_FLOW_SW_STATE`

2.3 Flowswitch: BPM BSYA 1240 (BPM12)

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
IS_NOT_OK	F	0 Hz	0 Hz	–	–	–	–	–
OK	T	120 Hz	120 Hz	–	–	–	–	–

Where
A = `BPM_BSYA_1240_FLOW_SW_STATE`

2.4 Flowswitch: COLL BSYA 1015 (PC10)

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
IS_NOT_OK	F	0 Hz	0 Hz	–	–	–	–	–
OK	T	120 Hz	120 Hz	–	–	–	–	–

Where
A = `COLL_BSYA_1015_FLOW_SW_STATE`

2.5 Flowswitch: COLL BSYA 1230 (PC12)

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
IS_NOT_OK	F	0 Hz	0 Hz	–	–	–	–	–
OK	T	120 Hz	120 Hz	–	–	–	–	–

Where
A = `COLL_BSYA_1230_FLOW_SW_STATE`

2.6 Flowswitch: COLL BSYA 1490 (PC14)

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
FAULT	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `COLL_BSYA_1490_FLOW_SW_STATE`

2.7 Flowswitch: COLL BSYA 1700 (PC17)

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
FAULT	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `COLL_BSYA_1700_FLOW_SW_STATE`

2.8 PIC Raw Charge Thresholds: BSYA 1016

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	–	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	–	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	–	–	–	–	–
OK	T	T	120 Hz	120 Hz	–	–	–	–	–

Where
A = `PICM_BSYA_1016_LOSSL_THRESHOLD`,
B = `PICM_BSYA_1016_LOSSH_THRESHOLD`

2.9 PIC Raw Charge Thresholds: BSYA 1021

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	–	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	–	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	–	–	–	–	–
OK	T	T	120 Hz	120 Hz	–	–	–	–	–

Where
A = `PICM_BSYA_1021_LOSSL_THRESHOLD`,
B = `PICM_BSYA_1021_LOSSH_THRESHOLD`

2.10 PIC Raw Charge Thresholds: BSYA 1120

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	–	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	–	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	–	–	–	–	–
OK	T	T	120 Hz	120 Hz	–	–	–	–	–

Where
A = `PICM_BSYA_1120_LOSSL_THRESHOLD`,
B = `PICM_BSYA_1120_LOSSH_THRESHOLD`

2.11 PIC Raw Charge Thresholds: BSYA 1320

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	–	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	–	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	–	–	–	–	–
OK	T	T	120 Hz	120 Hz	–	–	–	–	–

Where
A = `PICM_BSYA_1320_LOSSL_THRESHOLD`,
B = `PICM_BSYA_1320_LOSSH_THRESHOLD`

2.12 PIC Raw Charge Thresholds: BSYA 1520

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	–	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	–	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	–	–	–	–	–
OK	T	T	120 Hz	120 Hz	–	–	–	–	–

Where
A = `PICM_BSYA_1520_LOSSL_THRESHOLD`,
B = `PICM_BSYA_1520_LOSSH_THRESHOLD`

2.13 PIC Raw Charge Thresholds: BSYA 1701A

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	–	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	–	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	–	–	–	–	–
OK	T	T	120 Hz	120 Hz	–	–	–	–	–

Where
A = `PICM_BSYA_1701A_LOSSL_THRESHOLD`,
B = `PICM_BSYA_1701A_LOSSH_THRESHOLD`

2.14 PIC Raw Charge Thresholds: BSYA 1701B

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	–	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	–	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	–	–	–	–	–
OK	T	T	120 Hz	120 Hz	–	–	–	–	–

Where
A = `PICM_BSYA_1701B_LOSSL_THRESHOLD`,
B = `PICM_BSYA_1701B_LOSSH_THRESHOLD`

2.15 PIC Raw Charge Thresholds: BSYA 1980

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	–	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	–	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	–	–	–	–	–
OK	T	T	120 Hz	120 Hz	–	–	–	–	–

Where
A = `PICM_BSYA_1980_LOSSL_THRESHOLD`,
B = `PICM_BSYA_1980_LOSSH_THRESHOLD`

2.16 Temperature RTD Summary: A-Line Before SL10

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Faulted	F	0 Hz	0 Hz	–	–	–	–	–
OK	T	120 Hz	120 Hz	–	–	–	–	–

Where
A = `RTD_BSYA_1015_PRESL10SUM_STATUS`

2.17 Vac Valve: VVFS BSYA 1030 (FV10)

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
NOT_OPEN	F	0 Hz	0 Hz	–	–	–	–	–
OPEN	T	120 Hz	120 Hz	–	–	–	–	–

Where
A = `VVFS_BSYA_1030_POSITION_STATE`

2.18 Vac Valve: VVPG BSYA 1018 (IV10)

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
NOT_OPEN	F	0 Hz	0 Hz	–	–	–	–	–
OPEN	T	120 Hz	120 Hz	–	–	–	–	–

Where
A = `VVPG_BSYA_1018_POSITION_STATE`

2.19 VVPG BSYA 340 Position

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not Open	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Open	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `VVPG_BSYA_340_OPEN_LIMSW_POSITION`

3 Ignored when BX01/BX02 Is Off, YAG01 Is In, or YAG02 Is In

3.1 Toroid Comparator Dogleg 1 (IM02 vs IM03)

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Downstream > Upstream	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Upstream > Downstream	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = TC203L1_STATE,
B = TC203L2_STATE

4 Ignored when BX01/BX02 Is On, YAG01 Is In, or YAG02 Is In

4.1 BXS Status

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Fault	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `BEND_IN20_931_OK_STATE`

4.2 Toroid Comparator Inj Spectrometer (IM02 vs IMS1)

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Downstream > Upstream	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Upstream > Downstream	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `TC2S1L1_STATE`,
B = `TC2S1L2_STATE`

5 Ignored when BXG Is Off or YAG01 Is In

5.1 Wakefield Shield Gun Spectrometer

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Fault	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	10 Hz	10 Hz	10 Hz	–	–	–	–

Where
A = `WL_BL231_IN_STATE`

6 Ignored when BXG Is On or YAG01 Is In

6.1 Wakefield Shield Straight Ahead

Name	A	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Fault	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `WL_BL231_OUT_STATE`

7 Ignored when Diag Stopper HFX DG2 Is In, Diag Stopper HFX UM6 Is In, Diag Stopper XCS SB1 Is In, Stopper SH1 Is In, Stopper SH2 Is In, Stopper XRT S5 Is In, Stopper: BSY D2 Summary Is In, TD11 Is In, TDUND Is In, YAG01 Is In, or YAG02 Is In

7.1 XCS SB1 VGC 02 Gate Valve Position

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Moving	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Open	F	T	120 Hz	120 Hz	120 Hz	–	–	–	–
Closed	T	F	120 Hz	120 Hz	120 Hz	–	–	–	–
Broken	T	T	0 Hz	0 Hz	0 Hz	–	–	–	–

Where
A = `XCS_SB1_VGC_02_OPN_DI_POSITION`,
B = `XCS_SB1_VGC_02_CLS_DI_POSITION`

7.2 XCS SB2 VGC 01 Gate Valve Position

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Moving	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Open	F	T	120 Hz	120 Hz	120 Hz	–	–	–	–
Closed	T	F	120 Hz	120 Hz	120 Hz	–	–	–	–
Broken	T	T	0 Hz	0 Hz	0 Hz	–	–	–	–

Where
A = `XCS_SB2_VGC_01_OPN_DI_POSITION`,
B = `XCS_SB2_VGC_01_CLS_DI_POSITION`

8 Ignored when Diag Stopper HFX DG2 Is In, Diag Stopper HFX UM6 Is In, Stopper S5B Is In, Stopper SH1 Is In, Stopper SH2 Is In, Stopper XRT S5 Is In, Stopper: BSY D2 Summary Is In, TD11 Is In, TDUND Is In, YAG01 Is In, or YAG02 Is In

8.1 CXI Configuration 1 Summary

The following code assigns the truth table's state number to the `unsigned int` variable `state`.

```
/*
state = 0 beam dump
state = 1 beam allowed
state = 2 other, beam allowed
*/

/* Initialize to a guard value */
state = (unsigned int) -1;
{
int evalCXIConfigOne = -1;
{
        if ( CXI_MPS_CFG_1_CONFID ) /* EPS PLC asserts we are in config
            1 */
        {
                /* Evaluate inputs to identify if we're in beam dump
                    state for Cfg 1 */
                if ((! CXI_DG1_MMS_03_A_POSITION) ||
                (! CXI_DG2_MMS_06_B_POSITION) ||
                (! CXI_SC1_VGC_02_OPN_DI_POSITION) )
                {
                        evalCXIConfigOne = 0;
                }
                else
                {
                        evalCXIConfigOne = 1;
                }
        }
}
```

```
switch( evalCXIConfigOne )
{
        case 0: state = 0; break;
        case 1: state = 1; break;
        default: state = 2; break;
}
}
```

Name	State	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Config 1 Fault	0	0 Hz	0 Hz	0 Hz	–	–	–	–
Config 1 Ok	1	120 Hz	120 Hz	120 Hz	–	–	–	–
Not In Config 1	2	120 Hz	120 Hz	120 Hz	–	–	–	–

8.2 CXI Configuration 2 Summary

The following code assigns the truth table's state number to the `unsigned int` variable `state`.

```
/*
state = 0 beam dump
state = 1 beam allowed
state = 2 other, beam allowed
*/

/* Initialize to a guard value */
state = (unsigned int) -1;
{
int evalCXIConfigTwo = -1;
{
        if ( CXI_MPS_CFG_2_CONFID ) /* EPS PLC asserts we are in config
            2 */
        {
                /* Evaluate inputs to identify if we're in beam dump
                   state for Cfg 2 */
                if (    (! CXI_DG1_MMS_03_A_POSITION) ||
                        (! CXI_SC1_VGC_02_OPN_DI_POSITION) || /* If the
                            valve is not open, trip */
                        (       (! CXI_DIA_ATTEN_OK_POSITION) && /* DIA
                            attenuation */
                                (! (    CXI_DG1_MMS_08_B_POSITION &&
                                                CXI_DG1_MMS_08_B_POSITION
                                                    &&
```

```
                                                        CXI_DG2_MMS_08_B_POSITION
                                                            &&
                                                        CXI_DG2_MMS_09_B_POSITION
                                                            &&
                                                        CXI_DG2_MMS_10_B_POSITION
                                                            &&
                                                        CXI_DG4_MMS_05_B_POSITION
                                                            &&
                                                        CXI_DG4_MMS_03_B_POSITION

                                                    )
                                                )
                                            )
                                            )
                        {
                                evalCXIConfigTwo = 0;
                        }
                        else
                        {
                                evalCXIConfigTwo = 1;
                        }
        }
}

switch( evalCXIConfigTwo )
{
        case 0: state = 0; break;
        case 1: state = 1; break;
        default: state = 2; break;
}
}
```

Name	State	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Faulted	0	0 Hz	0 Hz	0 Hz	–	–	–	–
Ok	1	120 Hz	120 Hz	120 Hz	–	–	–	–
Not In Config 2	2	120 Hz	120 Hz	120 Hz	–	–	–	–

8.3 CXI Configuration 3 Summary

The following code assigns the truth table's state number to the `unsigned int` variable `state`.

```
/*
```

```
state = 0 beam dump
state = 1 beam allowed
state = 2 other, beam allowed
*/

/* Initialize to a guard value */
state = (unsigned int) -1;
{
int evalCXIConfigThree = -1;
{
        if ( CXI_MPS_CFG_3_CONFID ) /* EPS PLC asserts we are in config
            3 */
        {
                /* Evaluate inputs to identify if we're in beam dump
                   state for Cfg 3 */
                if ((! CXI_DG1_MMS_03_A_POSITION) ||
                (! CXI_SC1_VGC_02_OPN_DI_POSITION) )
                {
                        evalCXIConfigThree = 0;
                }
                else
                {
                        evalCXIConfigThree = 1;
                }
        }
}

switch( evalCXIConfigThree )
{
        case 0: state = 0; break;
        case 1: state = 1; break;
        default: state = 2; break;
}
}
```

Name	State	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Faulted	0	0 Hz	0 Hz	0 Hz	–	–	–	–
Ok	1	120 Hz	120 Hz	120 Hz	–	–	–	–
Not in Config 3	2	120 Hz	120 Hz	120 Hz	–	–	–	–

8.4 CXI Configuration 4 Summary

The following code assigns the truth table's state number to the `unsigned int` variable `state`.

```
/*
state = 0 beam dump
state = 1 beam allowed
state = 2 other, beam allowed
*/

/* Initialize to a guard value */
state = (unsigned int) -1;
{
int evalCXIConfigFour = -1;
{
        if ( CXI_MPS_CFG_4_CONFID ) /* EPS PLC asserts we are in config
            4 */
        {
                /* Evaluate inputs to identify if we're in beam dump
                   state for Cfg 4 */
                if ((! CXI_DG1_MMS_03_A_POSITION) ||
                (! CXI_SC1_VGC_02_OPN_DI_POSITION) )
                {
                        evalCXIConfigFour = 0;
                }
                else
                {
                        evalCXIConfigFour = 1;
                }
        }
}

switch( evalCXIConfigFour )
{
        case 0: state = 0; break;
        case 1: state = 1; break;
        default: state = 2; break;
}
}
```

Name	State	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Faulted	0	0 Hz	0 Hz	0 Hz	–	–	–	–
Ok	1	120 Hz	120 Hz	120 Hz	–	–	–	–
Not In Config 4	2	120 Hz	120 Hz	120 Hz	–	–	–	–

8.5 CXI Configuration 5 Summary

The following code assigns the truth table's state number to the `unsigned int` variable `state`.

```
/*
state = 0 beam dump
state = 1 beam allowed
state = 2 other, beam allowed
*/

/* Initialize to a guard value */
state = (unsigned int) -1;
{
int evalCXIConfigFive = -1;
{
        if ( CXI_MPS_CFG_5_CONFID ) /* EPS PLC asserts we are in config
            5 */
        {
                /* Evaluate inputs to identify if we're in beam dump
                   state for Cfg 5 */
                if ((! CXI_DG1_MMS_03_A_POSITION) ||
                (! CXI_SC1_VGC_02_OPN_DI_POSITION) )
                {
                        evalCXIConfigFive = 0;
                }
                else
                {
                        evalCXIConfigFive = 1;
                }
        }
}

switch( evalCXIConfigFive )
{
        case 0: state = 0; break;
        case 1: state = 1; break;
        default: state = 2; break;
```

```
}
}
```

Name	State	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Faulted	0	0 Hz	0 Hz	0 Hz	–	–	–	–
Ok	1	120 Hz	120 Hz	120 Hz	–	–	–	–
Not In Config 5	2	120 Hz	120 Hz	120 Hz	–	–	–	–

8.6 CXI Configuration 6 Summary

The following code assigns the truth table's state number to the `unsigned int` variable `state`.

```
/*
state = 0 beam dump
state = 1 beam allowed
state = 2 other, beam allowed
*/

/* Initialize to a guard value */
state = (unsigned int) -1;
{
int evalCXIConfigSix = -1;
{
        if ( CXI_MPS_CFG_6_CONFID ) /* EPS PLC asserts we are in config
            6 */
        {
                /* Evaluate inputs to identify if we're in beam dump
                   state for Cfg 6 */
                if ((! CXI_DG1_MMS_03_A_POSITION) ||
                        (! CXI_DG2_MMS_06_B_POSITION) ||
                (! CXI_SC2_VGC_02_OPN_DI_POSITION) )
                {
                        evalCXIConfigSix = 0;
                }
                else
                {
                        evalCXIConfigSix = 1;
                }
        }
}

switch( evalCXIConfigSix )
```

```
{
        case 0: state = 0; break;
        case 1: state = 1; break;
        default: state = 2; break;
}
}
```

Name	State	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Faulted	0	0 Hz	0 Hz	0 Hz	–	–	–	–
Ok	1	120 Hz	120 Hz	120 Hz	–	–	–	–
Not In Config 6	2	120 Hz	120 Hz	120 Hz	–	–	–	–

8.7 CXI Configuration 7 Summary

The following code assigns the truth table's state number to the `unsigned int` variable `state`.

```
/*
state = 0 beam dump
state = 1 beam allowed
state = 2 other, beam allowed
*/

/* Initialize to a guard value */
state = (unsigned int) -1;
{
int evalCXIConfigSeven = -1;
{
        if ( CXI_MPS_CFG_7_CONFID ) /* EPS PLC asserts we are in config
            7 */
        {
                /* Evaluate inputs to identify if we're in beam dump
                   state for Cfg 7 */
                if ((! CXI_DG1_MMS_03_A_POSITION)        ||
                        (! CXI_SC1_VGC_02_OPN_DI_POSITION) ||
                (! CXI_SC2_VGC_02_OPN_DI_POSITION) )
                {
                        evalCXIConfigSeven = 0;
                }
                else
                {
                        evalCXIConfigSeven = 1;
                }
```

```
        }
}

switch( evalCXIConfigSeven )
{
        case 0: state = 0; break;
        case 1: state = 1; break;
        default: state = 2; break;
}
}
```

Name	State	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Faulted	0	0 Hz	0 Hz	0 Hz	–	–	–	–
Ok	1	120 Hz	120 Hz	120 Hz	–	–	–	–
Not In Config 7	2	120 Hz	120 Hz	120 Hz	–	–	–	–

8.8 CXI KB2 VGC 02 Gate Valve Position

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Moving	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Open	F	T	120 Hz	120 Hz	120 Hz	–	–	–	–
Closed	T	F	120 Hz	120 Hz	120 Hz	–	–	–	–
Broken	T	T	0 Hz	0 Hz	0 Hz	–	–	–	–

Where
A = `CXI_KB2_VGC_02_OPN_DI_POSITION`,
B = `CXI_KB2_VGC_02_CLS_DI_POSITION`

8.9 CXI MPS PLC Readiness Status

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
PLC Not OK	F	0 Hz	0 Hz	0 Hz	–	–	–	–
PLC OK	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `CXI_MPS_PLC_01_OK_STATUS`

8.10 CXI User Patch Panel 1 Ready

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not Ready	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Ready	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `CXI_USR_01_MPSFAULT_STATUS`

8.11 CXI User Patch Panel 2 Ready

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not Ready	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Ready	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `CXI_USR_02_MPSFAULT_STATUS`

8.12 CXI:DG1:VGC:01 Gate Valve Open Position

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not Open	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Open	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `CXI_DG1_VGC_01_OPN_DI_POSITION`

8.13 CXI:DG1:VGC:02 Gate Valve Open Position

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not Open	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Open	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `CXI_DG1_VGC_02_OPN_DI_POSITION`

8.14 CXI:DG2:VGC:01 Gate Valve Position

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Moving	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Open	F	T	120 Hz	120 Hz	120 Hz	–	–	–	–
Closed	T	F	120 Hz	120 Hz	120 Hz	–	–	–	–
Broken	T	T	0 Hz	0 Hz	0 Hz	–	–	–	–

Where
A = `CXI_DG2_VGC_01_OPN_DI_POSITION`,
B = `CXI_DG2_VGC_01_CLS_DI_POSITION`

8.15 CXI:DG2:VGC:02 Gate Valve Position

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Moving	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Open	F	T	120 Hz	120 Hz	120 Hz	–	–	–	–
Closed	T	F	120 Hz	120 Hz	120 Hz	–	–	–	–
Broken	T	T	0 Hz	0 Hz	0 Hz	–	–	–	–

Where
A = `CXI_DG2_VGC_02_OPN_DI_POSITION`,
B = `CXI_DG2_VCG_02_CLS_DI_POSITION`

8.16 CXI:DG4:VGC:01 Gate Valve Position

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Moving	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Open	F	T	120 Hz	120 Hz	120 Hz	–	–	–	–
Closed	T	F	120 Hz	120 Hz	120 Hz	–	–	–	–
Broken	T	T	0 Hz	0 Hz	0 Hz	–	–	–	–

Where
A = `CXI_DG4_VGC_01_OPN_DI_POSITION`,
B = `CXI_DG4_VGC_01_CLS_DI_POSITION`

8.17 CXI:DSC:VGC:01 Gate Valve Position

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Moving	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Open	F	T	120 Hz	120 Hz	120 Hz	–	–	–	–
Closed	T	F	120 Hz	120 Hz	120 Hz	–	–	–	–
Broken	T	T	0 Hz	0 Hz	0 Hz	–	–	–	–

Where
A = `CXI_DSC_VGC_01_OPN_DI_POSITION`,
B = `CXI_DSC_VGC_01_CLS_DI_POSITION`

8.18 CXI:KB1:VGC:01 Gate Valve Open Position

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not Open	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Open	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `CXI_KB1_VGC_01_OPN_DI_POSITION`

8.19 CXI:KB1:VGC:02 Gate Valve Open Position

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not Open	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Open	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `CXI_KB1_VGC_02_OPN_DI_POSITION`

8.20 CXI:KB2:VGC:01 Gate Valve Open Position

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not Open	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Open	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = CXI_KB2_VGC_01_OPN_DI_POSITION

8.21 CXI:SC1:VGC:01 Gate Valve Position

Name	B	A	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Moving	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Open	F	T	120 Hz	120 Hz	120 Hz	–	–	–	–
Closed	T	F	120 Hz	120 Hz	120 Hz	–	–	–	–
Broken	T	T	0 Hz	0 Hz	0 Hz	–	–	–	–

Where
A = CXI_SC1_VGC_01_OPN_DI_POSITION,
B = CXI_SC1_VGC_01_CLS_DI_POSITION

8.22 CXI:SC3:VGC:01 Be Gate Valve Position - Status from PLC

Name	A	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Moving or Broken	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Open or Closed	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = CXI_SC3_VGC_01_OPN_DI_POSITION

8.23 HF4 LAM VGC 01 Gate Valve Position

Name	A	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not Open	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Open	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = HF4_LAM_VGC_01_OPN_DI_POSITION

9 Ignored when Diag Stopper HFX DG2 Is In, Diag Stopper HFX UM6 Is In, Stopper SH1 Is In, Stopper SH2 Is In, Stopper XRT S5 Is In, Stopper: BSY D2 Summary Is In, TD11 Is In, TDUND Is In, YAG01 Is In, or YAG02 Is In

9.1 CXI XRT Laser Reference Mirror Position

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Mirror In Beam	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Mirror Out of Beam	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `XRT_DIA_MMS_01_B_POSITION`

9.2 HFA:SND:VGC:01 Gate Valve Open Position

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not Open	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Open	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `HFA_SND_VGC_01_OPN_DI_POSITION`

9.3 HFX:DIA:VGC:02 Gate Valve Open Position

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not Open	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Open	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `HFX_DIA_VGC_02_OPN_DI_POSITION`

9.4 PPS Stopper S5B Position

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Moving	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
In	F	T	–	–	–	–	–	–	–
Out	T	F	–	–	–	–	–	–	–
Broken	T	T	0 Hz	0 Hz	0 Hz	–	–	–	–

Where
A = `STPR_FEH1_5_S5BIN_POSITION`,
B = `STPR_FEH1_5_S5BOUT_POSITION`

9.5 XCS SB1 Diagnostic Stopper Position

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Moving	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Out	F	T	120 Hz	120 Hz	120 Hz	–	–	–	–
In	T	F	120 Hz	120 Hz	120 Hz	–	–	–	–
Broken	T	T	0 Hz	0 Hz	0 Hz	–	–	–	–

Where
A = `XCS_SB1_STP_01_OPN_DI_POSITION`,
B = `XCS_SB1_STP_01_CLS_DI_POSITION`

9.6 XCS SB1 VGC 01 Gate Valve Position

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Moving	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Open	F	T	120 Hz	120 Hz	120 Hz	–	–	–	–
Closed	T	F	120 Hz	120 Hz	120 Hz	–	–	–	–
Broken	T	T	0 Hz	0 Hz	0 Hz	–	–	–	–

Where
A = `XCS_SB1_VGC_01_OPN_DI_POSITION`,
B = `XCS_SB1_VGC_01_CLS_DI_POSITION`

9.7 XRT HXRAY DIA Isolation Valve HXX-DIA-VGC-01

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Moving	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Closed	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Open	T	F	120 Hz	120 Hz	120 Hz	–	–	–	–
Broken	T	T	0 Hz	0 Hz	0 Hz	–	–	–	–

Where
A = `HXX_DIA_VGC_01_CLS_DI_STATE`,
B = `HXX_DIA_VGC_01_OPN_DI_STATE`

10 Ignored when Diag Stopper HFX DG2 Is In, Diag Stopper HFX UM6 Is In, Stopper SH1 Is In, Stopper SH2 Is In, Stopper: BSY D2 Summary Is In, TD11 Is In, TDUND Is In, YAG01 Is In, or YAG02 Is In

10.1 HFX:DG2:VGC:01 Gate Valve Position

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not Open	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Open	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `HFX_DG2_VGC_01_OPN_DI_POSITION`

10.2 HFX:MON:VGC:01 Gate Valve Position

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not Open	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Open	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `HFX_MON_VGC_01_OPN_DI_POSITION`

10.3 HFX:MON:VGC:02 Gate Valve Position

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not Open	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Open	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `HFX_MON_VGC_02_OPN_DI_POSITION`

10.4 Stopper XRT S5 Position

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Moving	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Out	F	T	–	–	–	–	–	–	–
In	T	F	–	–	–	–	–	–	–
Broken	T	T	0 Hz	0 Hz	0 Hz	–	–	–	–

Where
A = `STPR_XRT1_1_S5OUT_POSITION`,
B = `STPR_XRT1_1_S5IN_POSITION`

11 Ignored when Diag Stopper HFX UM6 Is In, Stopper MFX S4.5 Is In, Stopper SH1 Is In, Stopper SH2 Is In, Stopper: BSY D2 Summary Is In, TD11 Is In, TDUND Is In, YAG01 Is In, or YAG02 Is In

11.1 MFX MPS Summary - Downstream of Stopper 4.5

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not Ok	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Ok	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `MFX_MPS_1_SUM_STATE`

12 Ignored when Diag Stopper HFX UM6 Is In, Stopper SH1 Is In, Stopper SH2 Is In, Stopper XRT S6 Is In, Stopper: BSY D2 Summary Is In, TD11 Is In, TDUND Is In, YAG01 Is In, or YAG02 Is In

12.1 MEC DV4 VCG 01 Gate Valve Position

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not open	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Open	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `MEC_DV4_VGC_01_OPN_DI_POSITION`

12.2 MEC DV5 VGC 01 Gate Valve Position

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not Open	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Open	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `MEC_DV5_VGC_01_OPN_DI_POSITION`

12.3 MEC HXM VGC 01 Gate Valve Position

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not Open	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Open	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `MEC_HXM_VGC_01_OPN_DI_POSITION`

12.4 MEC XT1 Reference Laser Position

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not Out	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Out	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `MEC_XT1_MMS_01_B_POSITION`

12.5 MEC XT1 VGC 01 Gate Valve Position

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not Open	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Open	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `MEC_XT1_VGC_01_OPN_DI_POSITION`

12.6 MEC XT2 VGC 02 Gate Valve Position

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not Open	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Open	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `MEC_XT2_VGC_02_OPN_DI_POSITION`

12.7 MEC XT2 VGC 03 Gate Valve Position

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not Open	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Open	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `MEC_XT2_VGC_03_OPN_DI_POSITION`

12.8 MEC XT2 VGC 04 Gate Valve Position

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not Open	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Open	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `MEC_XT2_VGC_04_OPN_DI_POSITION`

12.9 MEC XT2 VGC 05 Gate Valve Position

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Moving	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Open	F	T	120 Hz	120 Hz	120 Hz	–	–	–	–
Closed	T	F	120 Hz	120 Hz	120 Hz	–	–	–	–
Broken	T	T	0 Hz	0 Hz	0 Hz	–	–	–	–

Where
A = `MEC_XT2_VGC_05_OPN_DI_POSITION`,
B = `MEC_XT2_VGC_05_CLS_DI_POSITION`

12.10 MEC XT2 VGC 06 Gate Valve Position

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not Open	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Open	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `MEC_XT2_VGC_06_OPN_DI_POSITION`

13 Ignored when Diag Stopper HFX UM6 Is In, Stopper SH1 Is In, Stopper SH2 Is In, Stopper: BSY D2 Summary Is In, TD11 Is In, TDUND Is In, YAG01 Is In, or YAG02 Is In

13.1 DG2 Diagnostic Stopper Position

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Moving	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
In	F	T	–	–	–	–	–	–	–
Out	T	F	–	–	–	–	–	–	–
Broken	T	T	0 Hz	0 Hz	0 Hz	–	–	–	–

Where
A = `HFX_DG2_STP_01_IN_DI_POSITION`,
B = `HFX_DG2_STP_01_OUT_DI_POSITION`

13.2 MEC BXL VGC 01 Gate Valve Position

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not Open	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Open	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `MEC_BXL_VGC_01_OPN_DI_POSITION`

13.3 MEC XRT Attenuator Inspection Mirror Position

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Mirror Not Out	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Mirror Out	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `MEC_HXM_MMS_04_B_POSITION`

13.4 MFX Gate Valve Summary - Upstream of Stopper 4.5

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not All Out	F	0 Hz	0 Hz	0 Hz	–	–	–	–
All Out	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `MFX_XRT_VGC_OUT_SUM_STATE`

13.5 Stopper MFX S4.5 Position

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Moving	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Out	F	T	120 Hz	120 Hz	120 Hz	–	–	–	–
In	T	F	120 Hz	120 Hz	120 Hz	–	–	–	–
Broken	T	T	0 Hz	0 Hz	0 Hz	–	–	–	–

Where
A = `STPR_XRT_1_S45OUT_STATE`,
B = `STPR_XRT_1_S45IN_STATE`

13.6 Stopper XRT S6 Position

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Moving	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
In	F	T	120 Hz	120 Hz	120 Hz	–	–	–	–
Out	T	F	120 Hz	120 Hz	120 Hz	–	–	–	–
Broken	T	T	0 Hz	0 Hz	0 Hz	–	–	–	–

Where
A = `STPR_XRT1_1_S6IN_POSITION`,
B = `STPR_XRT1_1_S6OUT_POSITION`

13.7 XRT HXRAY LOM Isolation Valve HXX-LOM-VGC-01

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Moving	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Closed	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Open	T	F	120 Hz	120 Hz	120 Hz	–	–	–	–
Broken	T	T	0 Hz	0 Hz	0 Hz	–	–	–	–

Where
A = `HXX_LOM_VGC_01_CLS_DI_STATE`,
B = `HXX_LOM_VGC_01_OPN_DI_STATE`

13.8 XRT HXRAY MXT Gate Valve HXX:MXT:VGC:01

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not Open	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Open	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `HXX_MXT_VGC_01_OPN_DI_POSITION`

13.9 XRT HXRAY MXT Gate Valve HXX:MXT:VGC:02

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not Open	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Open	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `HXX_MXT_VGC_02_OPN_DI_POSITION`

13.10 XRT HXRAY MXT Gate Valve HXX:MXT:VGC:03

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Moving	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Closed	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Open	T	F	120 Hz	120 Hz	120 Hz	–	–	–	–
Broken	T	T	0 Hz	0 Hz	0 Hz	–	–	–	–

Where
A = `HXX_MXT_VGC_03_CLS_DI_POSITION`,
B = `HXX_MXT_VGC_03_OPN_DI_POSITION`

13.11 XRT HXRAY MXT Gate Valve HXX:MXT:VGC:05

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not Open	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Open	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `HXX_MXT_VGC_05_OPN_DI_POSITION`

13.12 XRT-M2 Mirror and DG2 STP Fault

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	G
In Transit: DG2 STP Not In Beam, XRT-M2 Mirror Not Out	F	F	0 Hz	0 Hz	0 Hz	–	–	
In Transit: DG2 STP Not In Beam, XRT-M2 Mirror Out	F	T	120 Hz	120 Hz	120 Hz	–	–	
Safe: DG2 STP In Beam, XRT-M2 Mirror Not Out	T	F	120 Hz	120 Hz	120 Hz	–	–	
Safe: DG2 STP In Beam, XRT-M2 Mirror Out	T	T	120 Hz	120 Hz	120 Hz	–	–	

Where
A = `HXX_HXM_MMS_01_B_POSITION`,
B = `HFX_DG2_STP_01_IN_DI_POSITION`

14 Ignored when Laser Heater Attenuator Is In

14.1 Laser Heater Photodiode Shutter Position

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Moving	F	F	–	–	–	0 Hz	–	–	–
Out	F	T	–	–	–	0 Hz	–	–	–
In	T	F	–	–	–	120 Hz	–	–	–
Broken	T	T	–	–	–	0 Hz	–	–	–

Where
A = `LHPHD_OUT_LIMIT_STATE`,
B = `LHPHD_IN_LIMIT_STATE`

14.2 OTRH1 Position When LH Atten Not In

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Moving	F	F	–	–	–	0 Hz	–	–	–
Out	F	T	–	–	–	120 Hz	–	–	–
In	T	F	–	–	–	0 Hz	–	–	–
Broken	T	T	–	–	–	0 Hz	–	–	–

Where
A = `OTRH1_OUT_LIMIT_STATE`,
B = `OTRH1_IN_LIMIT_STATE`

14.3 OTRH2 Position When LH Atten Not In

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Moving	F	F	–	–	–	0 Hz	–	–	–
Out	F	T	–	–	–	120 Hz	–	–	–
In	T	F	–	–	–	0 Hz	–	–	–
Broken	T	T	–	–	–	0 Hz	–	–	–

Where
A = `OTRH2_OUT_LIMIT_STATE`,
B = `OTRH2_IN_LIMIT_STATE`

15 Ignored when Stopper S1 Is In, Stopper: BSY D2 Summary Is In, TD11 Is In, TDUND Is In, YAG01 Is In, or YAG02 Is In

15.1 NEH AMO Laser Reference Mirror Position

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not Out	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Out	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = SAS_MMM_01_B_POSITION

15.2 NEH AMO Valves Ok for Beam - Summary From PLC

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Fault	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Ok	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = AMO_MPS_VAC_OK_SUM_STATE

15.3 NEH1 Camera 1124 Position

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Moving	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Out	F	T	120 Hz	120 Hz	120 Hz	–	–	–	–
In	T	F	120 Hz	120 Hz	120 Hz	–	–	–	–
Broken	T	T	0 Hz	0 Hz	0 Hz	–	–	–	–

Where
A = CAMR_NEH1_1124_OUT_STATE,
B = CAMR_NEH1_1124_IN_STATE

15.4 NEH1 XTOD S1 Isolation Valve Summary

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Faulted	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `VMPS_NEH_703_ISOL_S1_STATE`

16 Ignored when Stopper S2 Is In, Stopper S2B Is In, Stopper: BSY D2 Summary Is In, TD11 Is In, TDUND Is In, YAG01 Is In, or YAG02 Is In

16.1 NEH SXR Differential Pump Isolation Valve SXR-DFP-VGC-01

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Moving	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Closed	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Open	T	F	120 Hz	120 Hz	120 Hz	–	–	–	–
Broken	T	T	0 Hz	0 Hz	0 Hz	–	–	–	–

Where
A = `SXR_DFP_VGC_01_CLS_DI_STATE`,
B = `SXR_DFP_VGC_01_OPN_DI_STATE`

16.2 NEH SXR End Station Ready SXR-EXP-MPS-01

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not Ready	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Ready	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `SXR_EXP_MPS_01_STATE`

16.3 NEH SXR Intensity Monitor Isolation Valve SXR-FLX-VGC-01

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Moving	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Closed	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Open	T	F	120 Hz	120 Hz	120 Hz	–	–	–	–
Broken	T	T	0 Hz	0 Hz	0 Hz	–	–	–	–

Where
A = SXR_FLX_VGC_01_CLS_DI_STATE,
B = SXR_FLX_VGC_01_OPN_DI_STATE

16.4 NEH SXR KB Optics Isolation Valve SXR-KBO-VGC-01

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Moving	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Closed	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Open	T	F	120 Hz	120 Hz	120 Hz	–	–	–	–
Broken	T	T	0 Hz	0 Hz	0 Hz	–	–	–	–

Where
A = SXR_KBO_VGC_01_CLS_DI_STATE,
B = SXR_KBO_VGC_01_OPN_DI_STATE

16.5 NEH SXR Laser In-coupling Mirror Isolation Valve SXR-LIN-VGC-01

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Moving	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Closed	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Open	T	F	120 Hz	120 Hz	120 Hz	–	–	–	–
Broken	T	T	0 Hz	0 Hz	0 Hz	–	–	–	–

Where
A = SXR_LIN_VGC_01_CLS_DI_STATE,
B = SXR_LIN_VGC_01_OPN_DI_STATE

17 Ignored when Stopper S2 Is In, Stopper: BSY D2 Summary Is In, TD11 Is In, TDUND Is In, YAG01 Is In, or YAG02 Is In

17.1 NEH Camera 2124 Position

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Moving	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Out	F	T	120 Hz	120 Hz	120 Hz	–	–	–	–
In	T	F	120 Hz	120 Hz	120 Hz	–	–	–	–
Broken	T	T	0 Hz	0 Hz	0 Hz	–	–	–	–

Where
A = `CAMR_NEH1_2124_OUT_STATE`,
B = `CAMR_NEH1_2124_IN_STATE`

17.2 NEH SXR Collimator 3 Isolation Valve SXR-COL-VGC-01

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Moving	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Closed	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Open	T	F	120 Hz	120 Hz	120 Hz	–	–	–	–
Broken	T	T	0 Hz	0 Hz	0 Hz	–	–	–	–

Where
A = `SXR_COL_VGC_01_CLS_DI_STATE`,
B = `SXR_COL_VGC_01_OPN_DI_STATE`

17.3 NEH SXR Exit Slits Isolation Valve SXR-EXS-VGC-01

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Moving	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Closed	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Open	T	F	120 Hz	120 Hz	120 Hz	–	–	–	–
Broken	T	T	0 Hz	0 Hz	0 Hz	–	–	–	–

Where
A = SXR_EXS_VGC_01_CLS_DI_STATE,
B = SXR_EXS_VGC_01_OPN_DI_STATE

17.4 NEH SXR GMD VGC 01 Protection

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
In Transit: SXR GMD VGC 01 In Motion	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Safe: SXR GMD VGC 01 Open	F	T	120 Hz	120 Hz	120 Hz	–	–	–	–
Closed: SXR GMD VGC 01 Closed	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Error: SXR GMD VGC 01 Open and Closed	T	T	0 Hz	0 Hz	0 Hz	–	–	–	–

Where
A = SXR_GMD_VGC_01_OPN_DI_POSITION,
B = SXR_GMD_VGC_01_CLS_DI_POSITION

17.5 NEH SXR Monochromator Tank Isolation Valve SXR-MON-VGC-01

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Moving	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Closed	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Open	T	F	120 Hz	120 Hz	120 Hz	–	–	–	–
Broken	T	T	0 Hz	0 Hz	0 Hz	–	–	–	–

Where
A = SXR_MON_VGC_01_CLS_DI_STATE,
B = SXR_MON_VGC_01_OPN_DI_STATE

17.6 NEH SXR Photon Stoppers Isolation Valve SXR-PST-VGC-01

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Moving	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Closed	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Open	T	F	120 Hz	120 Hz	120 Hz	–	–	–	–
Broken	T	T	0 Hz	0 Hz	0 Hz	–	–	–	–

Where
A = SXR_PST_VGC_01_CLS_DI_STATE,
B = SXR_PST_VGC_01_OPN_DI_STATE

17.7 NEH SXR Transmission Sample System Isolation Valve SXR-TSS-VGC-01

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Moving	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Closed	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Open	T	F	120 Hz	120 Hz	120 Hz	–	–	–	–
Broken	T	T	0 Hz	0 Hz	0 Hz	–	–	–	–

Where
A = SXR_TSS_VGC_01_CLS_DI_STATE,
B = SXR_TSS_VGC_01_OPN_DI_STATE

17.8 NEH SXR Zero Order Interlock SXR-MON-MMS-06, SXR-EXS-MMS-01

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Slits Not Open, No Zero Order	F	F	120 Hz	120 Hz	120 Hz	–	–	–	–
Slits Not Open, Zero Order Fault	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Slits Open, No Zero Order	T	F	120 Hz	120 Hz	120 Hz	–	–	–	–
Slits Open, Zero Order	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = SXR_MON_MMS_06_B_STATE,
B = SXR_EXS_MMS_01_B_STATE

17.9 NEH1 XTOD S2 Isolation Valve Summary

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Faulted	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `VMPS_NEH_703_ISOL_S2_STATE`

18 Ignored when Stopper SH1 Is In, Stopper SH2 Is In, Stopper: BSY D2 Summary Is In, TD11 Is In, TDUND Is In, YAG01 Is In, or YAG02 Is In

18.1 UM6 Diagnostic Stopper Position

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Moving	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
In	F	T	–	–	–	–	–	–	–
Out	T	F	–	–	–	–	–	–	–
Broken	T	T	0 Hz	0 Hz	0 Hz	–	–	–	–

Where
A = HFX_UM6_STP_01_IN_DI_POSITION,
B = HFX_UM6_STP_01_OUT_DI_POSITION

18.2 XRT HXRAY UM6 Isolation Valve HXX-UM6-VGC-01

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Moving	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Closed	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Open	T	F	120 Hz	120 Hz	120 Hz	–	–	–	–
Broken	T	T	0 Hz	0 Hz	0 Hz	–	–	–	–

Where
A = HXX_UM6_VGC_01_CLS_DI_STATE,
B = HXX_UM6_VGC_01_OPN_DI_STATE

18.3 XRT UM6 Camera Position HXX-UM6-CVP-01

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Moving	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Out	F	T	120 Hz	120 Hz	120 Hz	–	–	–	–
In	T	F	120 Hz	120 Hz	120 Hz	–	–	–	–
Broken	T	T	0 Hz	0 Hz	0 Hz	–	–	–	–

Where
A = `HXX_UM6_CVP_01_B_STATE`,
B = `HXX_UM6_CVP_01_A_STATE`

19 Ignored when Stopper SH1 Is In, Stopper: BSY D2 Summary Is In, TD11 Is In, TDUND Is In, XPP-NH3-POS-00 Beamline Is In, YAG01 Is In, or YAG02 Is In

19.1 NEH3 HXRAY DVD Isolation Valve HX3-DVD-VGC-01

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Moving	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Closed	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Open	T	F	120 Hz	120 Hz	120 Hz	–	–	–	–
Broken	T	T	0 Hz	0 Hz	0 Hz	–	–	–	–

Where
A = `HX3_DVD_VGC_01_CLS_DI_STATE`,
B = `HX3_DVD_VGC_01_OPN_DI_STATE`

20 Ignored when Stopper SH1 Is In, Stopper: BSY D2 Summary Is In, TD11 Is In, TDUND Is In, XPP-NH3-POS-00 Beamline Is Not In, YAG01 Is In, or YAG02 Is In

20.1 XPP SB2 VGC 01 Gate Valve Position

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Moving	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Open	F	T	120 Hz	120 Hz	120 Hz	–	–	–	–
Closed	T	F	120 Hz	120 Hz	120 Hz	–	–	–	–
Broken	T	T	0 Hz	0 Hz	0 Hz	–	–	–	–

Where
A = `XPP_SB2_VGC_01_OPN_DI_POSITION`,
B = `XPP_SB2_VGC_01_CLS_DI_POSITION`

20.2 XPP SB2 VGC 02 Gate Valve Position

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not Open	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Open	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `XPP_SB2_VGC_02_OPN_DI_POSITION`

20.3 XPP SB2 VGC 03 Gate Valve Position

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not Open	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Open	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `XPP_SB2_VGC_03_OPN_DI_POSITION`

21 Ignored when Stopper SH1 Is In, Stopper: BSY D2 Summary Is In, TD11 Is In, TDUND Is In, YAG01 Is In, or YAG02 Is In

21.1 HX2 UVD VGC 01 Gate Valve Position

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Moving	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Open	F	T	120 Hz	120 Hz	120 Hz	–	–	–	–
Closed	T	F	120 Hz	120 Hz	120 Hz	–	–	–	–
Broken	T	T	0 Hz	0 Hz	0 Hz	–	–	–	–

Where
A = `HX2_SB1_VGC_01_OPN_DI_STATE`,
B = `HX2_SB1_VGC_01_CLS_DI_STATE`

21.2 HX3 MON VGC 01 Gate Valve Position

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Moving	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Open	F	T	120 Hz	120 Hz	120 Hz	–	–	–	–
Closed	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Broken	T	T	0 Hz	0 Hz	0 Hz	–	–	–	–

Where
A = `HX3_MON_VGC_01_OPN_DI_POSITION`,
B = `HX3_MON_VGC_01_CLS_DI_POSITION`

21.3 NEH HXTD Vacuum Valve Summary

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not All Open	F	0 Hz	0 Hz	0 Hz	–	–	–	–
All Open	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `VMPS_NEH1_HXTD_SUM_FAULT`

21.4 NEH1 Camera 124 Position

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Moving	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Out	F	T	120 Hz	120 Hz	120 Hz	–	–	–	–
In	T	F	120 Hz	120 Hz	120 Hz	–	–	–	–
Broken	T	T	0 Hz	0 Hz	0 Hz	–	–	–	–

Where
A = `CAMR_NEH1_124_OUT_STATE`,
B = `CAMR_NEH1_124_IN_STATE`

21.5 NEH1 Camera 195 Position

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Moving	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Out	F	T	120 Hz	120 Hz	120 Hz	–	–	–	–
In	T	F	120 Hz	120 Hz	120 Hz	–	–	–	–
Broken	T	T	0 Hz	0 Hz	0 Hz	–	–	–	–

Where
A = `CAMR_NEH1_195_OUT_STATE`,
B = `CAMR_NEH1_195_IN_STATE`

21.6 NEH2 HXRAY DVD Isolation Valve HX2-DVD-VGC-01

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Moving	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Closed	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Open	T	F	120 Hz	120 Hz	120 Hz	–	–	–	–
Fault	T	T	0 Hz	0 Hz	0 Hz	–	–	–	–

Where
A = `HX2_DVD_VGC_01_CLS_DI_STATE`,
B = `HX2_DVD_VGC_01_OPN_DI_STATE`

21.7 NEH3 HXRAY UVD Isolation Valve HX3-UVD-VGC-01

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Moving	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Closed	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Open	T	F	120 Hz	120 Hz	120 Hz	–	–	–	–
Broken	T	T	0 Hz	0 Hz	0 Hz	–	–	–	–

Where
A = `HX3_UVD_VGC_01_CLS_DI_STATE`,
B = `HX3_UVD_VGC_01_OPN_DI_STATE`

22 Ignored when Stopper: BSY D2 Summary Is In or TDUND Is In

22.1 HXRSS Beamline Position

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Moving	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Out	F	T	120 Hz	120 Hz	120 Hz	–	–	–	–
In	T	F	120 Hz	120 Hz	120 Hz	–	–	–	–
Broken	T	T	0 Hz	0 Hz	0 Hz	–	–	–	–

Where
A = `BMLN_UND1_1650_OUT_LMTSW_STATE`,
B = `BMLN_UND1_1650_IN_LMTSW_STATE`

22.2 HXRSS Chicane Bend Magnet Power Supply

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
ON	F	T	120 Hz	120 Hz	120 Hz	–	–	–	–
OFF	T	F	120 Hz	120 Hz	120 Hz	–	–	–	–
Broken	T	T	0 Hz	0 Hz	0 Hz	–	–	–	–

Where
A = `BEND_UND1_1640_ON_STATE`,
B = `BEND_UND1_1640_OFF_STATE`

22.3 HXRSS Crystal Position

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Moving	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Out	F	T	120 Hz	120 Hz	120 Hz	–	–	–	–
In	T	F	120 Hz	120 Hz	120 Hz	–	–	–	–
Broken	T	T	0 Hz	0 Hz	0 Hz	–	–	–	–

Where
A = XTAL_UND1_1650_OUT_LMTSW_STATE,
B = XTAL_UND1_1650_IN_ENCDR_STATE

22.4 HXRSS Crystal Valid Position

Name	A	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not Valid	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Valid	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = XTAL_UND1_1650_POSITIONSTAT_STATE

22.5 HXRSS Mode State

The following code assigns the truth table's state number to the `unsigned int` variable `state`.

```
/*
 * state = 0 : full rate (120 Hz) beam allowed, HXRSS Seeded Mode
 * state = 1 : full rate (120 Hz) beam allowed, HXRSS SASE Mode
 * state = 2 : full rate (120 Hz) beam allowed, HXRSS Phase Shifter
    Mode
 * state = 3 : no beam allowed, HXRSS undefined state
*/

/* Initialize to a guard value */
state = (unsigned int) -1;

/*
 * Allow beam if HXRSS is ON, Seeded Mode: the raft is in;
 *                            the magnet is on in and tolerance;
 *                            the photon energy is OK;
 *                            the crystal is IN
 * Allow beam if HXRSS is OFF, SASE Mode: the raft is out;
 *                             the magnet is off;
 *                             the crystal is out
 * Allow beam if HXRSS is in Phase Shifter Mode: the raft is in;
 *                             the magnet is in ANY state;
 *                             the crystal is out
 * Otherwise, do not allow beam.
```

```
 */


/* Input Descriptions
*
* BEND_DMP1_400_INTOL_BRANGE_STATE= HXRSS Beam Energy OK when 10 GeV <
    E < 15 GeV
* XTAL_UND1_1650_OUT_LMTSW_STATE    = Crystal OUT Limit Switch
* XTAL_UND1_1650_IN_ENCDR_STATE      = Crystal IN Limit Switch, from
    encoder
* BMLN_UND1_1650_IN_LMTSW_STATE      = HXRSS Raft IN Limit Switch
* BMLN_UND1_1650_OUT_LMTSW_STATE    = HXRSS Raft OUT Limit Switch
* BEND_UND1_1640_INTOL_BMIN_STATE    = HXRSS Chicane Bend INTOL, greater
    than +0.6 kG-m
* BEND_UND1_1640_OFF_STATE                = HXRSS Chicane Bend String is
    OFF
* BEND_UND1_1640_ON_STATE                 = HXRSS Chicane Bend String is
    ON
*
*/

if ( BMLN_UND1_1650_IN_LMTSW_STATE &&
            BEND_UND1_1640_INTOL_BMIN_STATE &&
            BEND_UND1_1640_ON_STATE &&
            BEND_DMP1_400_INTOL_BRANGE_STATE &&
            ( XTAL_UND1_1650_IN_ENCDR_STATE   ) )
{
    state = 0; /* HXRSS ON, HXRSS Seeded Mode, okay to run beam */
}

else if ( BMLN_UND1_1650_OUT_LMTSW_STATE &&
            BEND_UND1_1640_OFF_STATE &&
            XTAL_UND1_1650_OUT_LMTSW_STATE )
{
    state = 1; /* HXRSS OFF,SASE Mode, okay to run beam */
}

else if ( BMLN_UND1_1650_IN_LMTSW_STATE &&
            XTAL_UND1_1650_OUT_LMTSW_STATE )
{
    state = 2; /* HXRSS in Phase Shifter Mode, okay to run beam */
}

else
{
```

```
    state = 3; /* HXRSS Undefined State, no beam allowed */
}
```

Name	State	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
HXRSS Seeded Mode	0	120 Hz	120 Hz	120 Hz	–	–	–	–
HXRSS SASE Mode	1	120 Hz	120 Hz	120 Hz	–	–	–	–
HXRSS Phase Shifter Mode	2	120 Hz	120 Hz	120 Hz	–	–	–	–
HXRSS Undefined State	3	0 Hz	0 Hz	0 Hz	–	–	–	–

22.6 SXRSS Grating/M1 GRAT UND1 934 Position

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Moving	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Out	F	T	120 Hz	120 Hz	120 Hz	–	–	–	–
In	T	F	120 Hz	120 Hz	120 Hz	–	–	–	–
Broken	T	T	0 Hz	0 Hz	0 Hz	–	–	–	–

Where
A = `GRAT_UND1_934_OUT_LIMIT_POSITION`,
B = `GRAT_UND1_934_IN_LIMIT_POSITION`

22.7 SXRSS M2 MIRR UND1 964 Position

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Moving	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Out	F	T	120 Hz	120 Hz	120 Hz	–	–	–	–
In	T	F	120 Hz	120 Hz	120 Hz	–	–	–	–
Broken	T	T	0 Hz	0 Hz	0 Hz	–	–	–	–

Where
A = `MIRR_UND1_964_OUT_LIMIT_POSITION`,
B = `MIRR_UND1_964_IN_LIMIT_POSITION`

22.8 SXRSS M3 MIRR UND1 966 Position

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Moving	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Out	F	T	120 Hz	120 Hz	120 Hz	–	–	–	–
In	T	F	120 Hz	120 Hz	120 Hz	–	–	–	–
Broken	T	T	0 Hz	0 Hz	0 Hz	–	–	–	–

Where
A = `MIRR_UND1_966_OUT_LIMIT_POSITION`,
B = `MIRR_UND1_966_IN_LIMIT_POSITION`

22.9 SXRSS Mode State

The following code assigns the truth table's state number to the `unsigned int` variable `state`.

```
/* Production MPS SXRSS Modes
 *
 * state = 0 : full rate (120 Hz) beam allowed, SXRSS Seeded Mode
 * state = 1 : full rate (120 Hz) beam allowed, SXRSS SASE Mode
 * state = 2 : full rate (120 Hz) beam allowed, Harmonic Mode
 * state = 3 : no beam allowed, SXRSS undefined state
 *
 * Allow beam if SXRSS is ON, Seeded Mode:
 *                              { grating/M1 is IN and M3 is IN or OUT
    }
 *                             OR
 *                             { slit is IN and grating/M1/M2/M3 are
   OUT }
 *                              chicane is ON;
 *                              e- beam position OK  [mm]
 *                              e- beam energy   OK [GeV]
 *                              upstream undulators IN OK
 * Allow beam if SXRSS is OFF, SASE Mode:
 *                              grating/M1 is OUT;
 *                              slit is OUT;
 *                             M2 is OUT;
 *                             M3 is OUT;
 *                              e- beam position    OK  [mm]
 * Allow beam if SXRSS is in Harmonic Mode:
 *                              grating/M1 is OUT;
 *                              slit is NOT_IN and NOT_OUT;
 *                             M2 is OUT;
```

```
*                                M3 is OUT;
*                                chicane is ON;
*                                e- beam position  OK  [mm]
*                                e- beam energy     OK       [GeV]
* Otherwise, do not allow beam.
*
* Input Descriptions
*
*  Link Node MPS PV Name                  Link Node MPS Fault Name
                Desciption
* ------------------------------
   --------------------------------
   ------------------------------------------------
*  BEND:UND1:940:ON_MPS                =  BEND_UND1_940_ON_STATE
               =  Chicane power supply on
*  GRAT:UND1:934:IN_LIMIT_MPS          =  GRAT_UND1_934_IN_LIMIT_POSITION
      =  Grating/M1 IN limit switch
*  GRAT:UND1:934:OUT_LIMIT_MPS         =
   GRAT_UND1_934_OUT_LIMIT_POSITION    =  Grating/M1 OUT limit switch
*  SLIT:UND1:962:IN_LIMIT_MPS          =  SLIT_UND1_962_IN_LIMIT_POSITION
      =  Slit IN limit switch
*  SLIT:UND1:962:OUT_LIMIT_MPS         =
   SLIT_UND1_962_OUT_LIMIT_POSITION    =  Slit OUT limit switch
*  MIRR:UND1:964:IN_LIMIT_MPS          =  MIRR_UND1_964_IN_LIMIT_POSITION
      =  M2 IN limit switch
*  MIRR:UND1:964:OUT_LIMIT_MPS         =
   MIRR_UND1_964_OUT_LIMIT_POSITION    =  M2 OUT limit switch
*  MIRR:UND1:966:IN_LIMIT_MPS          =  MIRR_UND1_966_IN_LIMIT_POSITION
      =  M3 IN limit switch
*  MIRR:UND1:966:OUT_LIMIT_MPS         =
   MIRR_UND1_966_OUT_LIMIT_POSITION    =  M3 OUT limit switch
*  MPS:UND1:950:SX_HRMNC_ENERGY_MPS =
   MPS_UND1_950_SX_HRMNC_ENERGY_STATE =  e- beam energy safe for
   Harmonic mode
*  MPS:UND1:950:SX_HRMNC_X_MPS         =  MPS_UND1_950_SX_HRMNC_X_STATE
      =  e- beam position safe for Harmonic mode
*  MPS:UND1:950:SX_SASE_X_MPS          =  MPS_UND1_950_SX_SASE_X_STATE
      =  e- beam position safe for SASE mode
*  MPS:UND1:950:SX_SS_ENERGY_MPS       =  MPS_UND1_950_SX_SS_ENERGY_STATE
      =  e- beam energy safe for Seeded mode
*  MPS:UND1:950:SX_SS_UND_MPS          =  MPS_UND1_950_SX_SS_UND_STATE
      =  Inserted upstream undulators safe for Seeded mode
*  MPS:UND1:950:SX_SS_X_MPS            =  MPS_UND1_950_SX_SS_X_STATE
      =  e- beam position safe for Seeded mode
*/
```

```
/* Initialize to a guard value */
state = (unsigned int) -1;

if (     ((GRAT_UND1_934_IN_LIMIT_POSITION &&
         (MIRR_UND1_966_IN_LIMIT_POSITION ||
             MIRR_UND1_966_OUT_LIMIT_POSITION)) ||
          (SLIT_UND1_962_IN_LIMIT_POSITION  &&
              GRAT_UND1_934_OUT_LIMIT_POSITION &&
            MIRR_UND1_964_OUT_LIMIT_POSITION &&
                MIRR_UND1_966_OUT_LIMIT_POSITION)) &&
         BEND_UND1_940_ON_STATE &&
         MPS_UND1_950_SX_SS_X_STATE &&
         MPS_UND1_950_SX_SS_ENERGY_STATE &&
         MPS_UND1_950_SX_SS_UND_STATE )
{
    state = 0; /* SXRSS Seeded Mode, okay to run beam */
}

else if ( GRAT_UND1_934_OUT_LIMIT_POSITION &&
         SLIT_UND1_962_OUT_LIMIT_POSITION &&
         MIRR_UND1_964_OUT_LIMIT_POSITION &&
         MIRR_UND1_966_OUT_LIMIT_POSITION &&
         MPS_UND1_950_SX_SASE_X_STATE )
{
    state = 1; /* SXRSS SASE Mode, okay to run beam */
}

else if ( GRAT_UND1_934_OUT_LIMIT_POSITION &&
         !SLIT_UND1_962_IN_LIMIT_POSITION && !
             SLIT_UND1_962_OUT_LIMIT_POSITION &&
         MIRR_UND1_964_OUT_LIMIT_POSITION &&
         MIRR_UND1_966_OUT_LIMIT_POSITION &&
         BEND_UND1_940_ON_STATE &&
         MPS_UND1_950_SX_HRMNC_X_STATE &&
         MPS_UND1_950_SX_HRMNC_ENERGY_STATE )
{
    state = 2; /* SXRSS Harmonic Mode, okay to run beam */
}

else
{
    state = 3; /* SXRSS Undefined State, no beam allowed */
}
```

Name	State	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
SXRSS Seeded Mode	0	120 Hz	120 Hz	120 Hz	–	–	–	–
SXRSS SASE Mode	1	120 Hz	120 Hz	120 Hz	–	–	–	–
SXRSS Harmonic Mode	2	120 Hz	120 Hz	120 Hz	–	–	–	–
SXRSS Undefined State	3	0 Hz	0 Hz	0 Hz	–	–	–	–

22.10 SXRSS SLIT UND1 962 Position

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Moving	F	F	120 Hz	120 Hz	120 Hz	–	–	–	–
Out	F	T	120 Hz	120 Hz	120 Hz	–	–	–	–
In	T	F	120 Hz	120 Hz	120 Hz	–	–	–	–
Broken	T	T	0 Hz	0 Hz	0 Hz	–	–	–	–

Where
A = `SLIT_UND1_962_OUT_LIMIT_POSITION`,
B = `SLIT_UND1_962_IN_LIMIT_POSITION`

22.11 SXRSS Watchdog

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
NOT_OK	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `MPS_UND1_950_SXRSS_WDOG_STATE`

23 Ignored when Stopper: BSY D2 Summary Is In, TD11 Is In, TDUND Is In, YAG01 Is In, or YAG02 Is In

23.1 BCS PIC RAW Charge Threshold DMP 997

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Exceeded	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `PIC997_STATE`

23.2 BCS PIC RAW Charge Threshold DMP 998

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Exceeded	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `PIC998_STATE`

23.3 BFW 1010 Position

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Moving	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Out	F	T	–	–	–	–	–	–	–
In	T	F	–	–	–	–	–	–	–
Broken	T	T	0 Hz	0 Hz	0 Hz	–	–	–	–

Where
A = `BFW_UND1_1010_OUT_STATE`,
B = `BFW_UND1_1010_IN_STATE`

23.4 BFW 110 Position

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Moving	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Out	F	T	–	–	–	–	–	–	–
In	T	F	–	–	–	–	–	–	–
Broken	T	T	0 Hz	0 Hz	0 Hz	–	–	–	–

Where
A = `BFW_UND1_110_OUT_STATE`,
B = `BFW_UND1_110_IN_STATE`

23.5 BFW 1110 Position

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Moving	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Out	F	T	–	–	–	–	–	–	–
In	T	F	–	–	–	–	–	–	–
Broken	T	T	0 Hz	0 Hz	0 Hz	–	–	–	–

Where
A = `BFW_UND1_1110_OUT_STATE`,
B = `BFW_UND1_1110_IN_STATE`

23.6 BFW 1210 Position

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Moving	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Out	F	T	–	–	–	–	–	–	–
In	T	F	–	–	–	–	–	–	–
Broken	T	T	0 Hz	0 Hz	0 Hz	–	–	–	–

Where
A = `BFW_UND1_1210_OUT_STATE`,
B = `BFW_UND1_1210_IN_STATE`

23.7 BFW 1310 Position

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Moving	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Out	F	T	–	–	–	–	–	–	–
In	T	F	–	–	–	–	–	–	–
Broken	T	T	0 Hz	0 Hz	0 Hz	–	–	–	–

Where
A = `BFW_UND1_1310_OUT_STATE`,
B = `BFW_UND1_1310_IN_STATE`

23.8 BFW 1410 Position

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Moving	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Out	F	T	–	–	–	–	–	–	–
In	T	F	–	–	–	–	–	–	–
Broken	T	T	0 Hz	0 Hz	0 Hz	–	–	–	–

Where
A = `BFW_UND1_1410_OUT_STATE`,
B = `BFW_UND1_1410_IN_STATE`

23.9 BFW 1510 Position

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Moving	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Out	F	T	–	–	–	–	–	–	–
In	T	F	–	–	–	–	–	–	–
Broken	T	T	0 Hz	0 Hz	0 Hz	–	–	–	–

Where
A = `BFW_UND1_1510_OUT_STATE`,
B = `BFW_UND1_1510_IN_STATE`

23.10 BFW 1610 Position

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Moving	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Out	F	T	–	–	–	–	–	–	–
In	T	F	–	–	–	–	–	–	–
Broken	T	T	0 Hz	0 Hz	0 Hz	–	–	–	–

Where
A = `BFW_UND1_1610_OUT_STATE`,
B = `BFW_UND1_1610_IN_STATE`

23.11 BFW 1710 Position

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Moving	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Out	F	T	–	–	–	–	–	–	–
In	T	F	–	–	–	–	–	–	–
Broken	T	T	0 Hz	0 Hz	0 Hz	–	–	–	–

Where
A = `BFW_UND1_1710_OUT_STATE`,
B = `BFW_UND1_1710_IN_STATE`

23.12 BFW 1810 Position

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Moving	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Out	F	T	–	–	–	–	–	–	–
In	T	F	–	–	–	–	–	–	–
Broken	T	T	0 Hz	0 Hz	0 Hz	–	–	–	–

Where
A = `BFW_UND1_1810_OUT_STATE`,
B = `BFW_UND1_1810_IN_STATE`

23.13 BFW 1910 Position

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Moving	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Out	F	T	–	–	–	–	–	–	–
In	T	F	–	–	–	–	–	–	–
Broken	T	T	0 Hz	0 Hz	0 Hz	–	–	–	–

Where
A = BFW_UND1_1910_OUT_STATE,
B = BFW_UND1_1910_IN_STATE

23.14 BFW 2010 Position

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Moving	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Out	F	T	–	–	–	–	–	–	–
In	T	F	–	–	–	–	–	–	–
Broken	T	T	0 Hz	0 Hz	0 Hz	–	–	–	–

Where
A = BFW_UND1_2010_OUT_STATE,
B = BFW_UND1_2010_IN_STATE

23.15 BFW 210 Position

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Moving	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Out	F	T	–	–	–	–	–	–	–
In	T	F	–	–	–	–	–	–	–
Broken	T	T	0 Hz	0 Hz	0 Hz	–	–	–	–

Where
A = BFW_UND1_210_OUT_STATE,
B = BFW_UND1_210_IN_STATE

23.16 BFW 2110 Position

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Moving	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Out	F	T	–	–	–	–	–	–	–
In	T	F	–	–	–	–	–	–	–
Broken	T	T	0 Hz	0 Hz	0 Hz	–	–	–	–

Where
A = `BFW_UND1_2110_OUT_STATE`,
B = `BFW_UND1_2110_IN_STATE`

23.17 BFW 2210 Position

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Moving	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Out	F	T	–	–	–	–	–	–	–
In	T	F	–	–	–	–	–	–	–
Broken	T	T	0 Hz	0 Hz	0 Hz	–	–	–	–

Where
A = `BFW_UND1_2210_OUT_STATE`,
B = `BFW_UND1_2210_IN_STATE`

23.18 BFW 2310 Position

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Moving	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Out	F	T	–	–	–	–	–	–	–
In	T	F	–	–	–	–	–	–	–
Broken	T	T	0 Hz	0 Hz	0 Hz	–	–	–	–

Where
A = `BFW_UND1_2310_OUT_STATE`,
B = `BFW_UND1_2310_IN_STATE`

23.19 BFW 2410 Position

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Moving	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Out	F	T	–	–	–	–	–	–	–
In	T	F	–	–	–	–	–	–	–
Broken	T	T	0 Hz	0 Hz	0 Hz	–	–	–	–

Where
A = `BFW_UND1_2410_OUT_STATE`,
B = `BFW_UND1_2410_IN_STATE`

23.20 BFW 2510 Position

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Moving	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Out	F	T	–	–	–	–	–	–	–
In	T	F	–	–	–	–	–	–	–
Broken	T	T	0 Hz	0 Hz	0 Hz	–	–	–	–

Where
A = `BFW_UND1_2510_OUT_STATE`,
B = `BFW_UND1_2510_IN_STATE`

23.21 BFW 2610 Position

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Moving	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Out	F	T	–	–	–	–	–	–	–
In	T	F	–	–	–	–	–	–	–
Broken	T	T	0 Hz	0 Hz	0 Hz	–	–	–	–

Where
A = `BFW_UND1_2610_OUT_STATE`,
B = `BFW_UND1_2610_IN_STATE`

23.22 BFW 2710 Position

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Moving	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Out	F	T	–	–	–	–	–	–	–
In	T	F	–	–	–	–	–	–	–
Broken	T	T	0 Hz	0 Hz	0 Hz	–	–	–	–

Where
A = `BFW_UND1_2710_OUT_STATE`,
B = `BFW_UND1_2710_IN_STATE`

23.23 BFW 2810 Position

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Moving	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Out	F	T	–	–	–	–	–	–	–
In	T	F	–	–	–	–	–	–	–
Broken	T	T	0 Hz	0 Hz	0 Hz	–	–	–	–

Where
A = `BFW_UND1_2810_OUT_STATE`,
B = `BFW_UND1_2810_IN_STATE`

23.24 BFW 2910 Position

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Moving	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Out	F	T	–	–	–	–	–	–	–
In	T	F	–	–	–	–	–	–	–
Broken	T	T	0 Hz	0 Hz	0 Hz	–	–	–	–

Where
A = `BFW_UND1_2910_OUT_STATE`,
B = `BFW_UND1_2910_IN_STATE`

23.25 BFW 3010 Position

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Moving	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Out	F	T	–	–	–	–	–	–	–
In	T	F	–	–	–	–	–	–	–
Broken	T	T	0 Hz	0 Hz	0 Hz	–	–	–	–

Where
A = `BFW_UND1_3010_OUT_STATE`,
B = `BFW_UND1_3010_IN_STATE`

23.26 BFW 310 Position

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Moving	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Out	F	T	–	–	–	–	–	–	–
In	T	F	–	–	–	–	–	–	–
Broken	T	T	0 Hz	0 Hz	0 Hz	–	–	–	–

Where
A = `BFW_UND1_310_OUT_STATE`,
B = `BFW_UND1_310_IN_STATE`

23.27 BFW 3110 Position

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Moving	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Out	F	T	–	–	–	–	–	–	–
In	T	F	–	–	–	–	–	–	–
Broken	T	T	0 Hz	0 Hz	0 Hz	–	–	–	–

Where
A = `BFW_UND1_3110_OUT_STATE`,
B = `BFW_UND1_3110_IN_STATE`

23.28 BFW 3210 Position

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Moving	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Out	F	T	–	–	–	–	–	–	–
In	T	F	–	–	–	–	–	–	–
Broken	T	T	0 Hz	0 Hz	0 Hz	–	–	–	–

Where
A = BFW_UND1_3210_OUT_STATE,
B = BFW_UND1_3210_IN_STATE

23.29 BFW 3310 Position

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Moving	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Out	F	T	–	–	–	–	–	–	–
In	T	F	–	–	–	–	–	–	–
Broken	T	T	0 Hz	0 Hz	0 Hz	–	–	–	–

Where
A = BFW_UND1_3310_OUT_STATE,
B = BFW_UND1_3310_IN_STATE

23.30 BFW 410 Position

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Moving	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Out	F	T	–	–	–	–	–	–	–
In	T	F	–	–	–	–	–	–	–
Broken	T	T	0 Hz	0 Hz	0 Hz	–	–	–	–

Where
A = BFW_UND1_410_OUT_STATE,
B = BFW_UND1_410_IN_STATE

23.31 BFW 510 Position

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Moving	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Out	F	T	–	–	–	–	–	–	–
In	T	F	–	–	–	–	–	–	–
Broken	T	T	0 Hz	0 Hz	0 Hz	–	–	–	–

Where
A = `BFW_UND1_510_OUT_STATE`,
B = `BFW_UND1_510_IN_STATE`

23.32 BFW 610 Position

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Moving	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Out	F	T	–	–	–	–	–	–	–
In	T	F	–	–	–	–	–	–	–
Broken	T	T	0 Hz	0 Hz	0 Hz	–	–	–	–

Where
A = `BFW_UND1_610_OUT_STATE`,
B = `BFW_UND1_610_IN_STATE`

23.33 BFW 710 Position

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Moving	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Out	F	T	–	–	–	–	–	–	–
In	T	F	–	–	–	–	–	–	–
Broken	T	T	0 Hz	0 Hz	0 Hz	–	–	–	–

Where
A = `BFW_UND1_710_OUT_STATE`,
B = `BFW_UND1_710_IN_STATE`

23.34 BFW 810 Position

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Moving	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Out	F	T	–	–	–	–	–	–	–
In	T	F	–	–	–	–	–	–	–
Broken	T	T	0 Hz	0 Hz	0 Hz	–	–	–	–

Where
A = `BFW_UND1_810_OUT_STATE`,
B = `BFW_UND1_810_IN_STATE`

23.35 BFW 910 Position

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Moving	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Out	F	T	–	–	–	–	–	–	–
In	T	F	–	–	–	–	–	–	–
Broken	T	T	0 Hz	0 Hz	0 Hz	–	–	–	–

Where
A = `BFW_UND1_910_OUT_STATE`,
B = `BFW_UND1_910_IN_STATE`

23.36 BFW Inserted Count

The following code assigns the truth table's state number to the `unsigned int` variable `state`.

```
unsigned int beamFinderWireInCount = 0;

/* "BFW UND1 XXX" is IN when BFW_UND1_XXX_OUT_STATE == 0 */
if (!( BFW_UND1_110_OUT_STATE)) { beamFinderWireInCount++; }
if (!( BFW_UND1_210_OUT_STATE)) { beamFinderWireInCount++; }
if (!( BFW_UND1_310_OUT_STATE)) { beamFinderWireInCount++; }
if (!( BFW_UND1_410_OUT_STATE)) { beamFinderWireInCount++; }
if (!( BFW_UND1_510_OUT_STATE)) { beamFinderWireInCount++; }
if (!( BFW_UND1_610_OUT_STATE)) { beamFinderWireInCount++; }
if (!( BFW_UND1_710_OUT_STATE)) { beamFinderWireInCount++; }
if (!( BFW_UND1_810_OUT_STATE)) { beamFinderWireInCount++; }
if (!( BFW_UND1_910_OUT_STATE)) { beamFinderWireInCount++; }
if (!(BFW_UND1_1010_OUT_STATE)) { beamFinderWireInCount++; }
```

```
if (!(BFW_UND1_1110_OUT_STATE)) { beamFinderWireInCount++; }
if (!(BFW_UND1_1210_OUT_STATE)) { beamFinderWireInCount++; }
if (!(BFW_UND1_1310_OUT_STATE)) { beamFinderWireInCount++; }
if (!(BFW_UND1_1410_OUT_STATE)) { beamFinderWireInCount++; }
if (!(BFW_UND1_1510_OUT_STATE)) { beamFinderWireInCount++; }
if (!(BFW_UND1_1610_OUT_STATE)) { beamFinderWireInCount++; }
if (!(BFW_UND1_1710_OUT_STATE)) { beamFinderWireInCount++; }
if (!(BFW_UND1_1810_OUT_STATE)) { beamFinderWireInCount++; }
if (!(BFW_UND1_1910_OUT_STATE)) { beamFinderWireInCount++; }
if (!(BFW_UND1_2010_OUT_STATE)) { beamFinderWireInCount++; }
if (!(BFW_UND1_2110_OUT_STATE)) { beamFinderWireInCount++; }
if (!(BFW_UND1_2210_OUT_STATE)) { beamFinderWireInCount++; }
if (!(BFW_UND1_2310_OUT_STATE)) { beamFinderWireInCount++; }
if (!(BFW_UND1_2410_OUT_STATE)) { beamFinderWireInCount++; }
if (!(BFW_UND1_2510_OUT_STATE)) { beamFinderWireInCount++; }
if (!(BFW_UND1_2610_OUT_STATE)) { beamFinderWireInCount++; }
if (!(BFW_UND1_2710_OUT_STATE)) { beamFinderWireInCount++; }
if (!(BFW_UND1_2810_OUT_STATE)) { beamFinderWireInCount++; }
if (!(BFW_UND1_2910_OUT_STATE)) { beamFinderWireInCount++; }
if (!(BFW_UND1_3010_OUT_STATE)) { beamFinderWireInCount++; }
if (!(BFW_UND1_3110_OUT_STATE)) { beamFinderWireInCount++; }
if (!(BFW_UND1_3210_OUT_STATE)) { beamFinderWireInCount++; }
if (!(BFW_UND1_3310_OUT_STATE)) { beamFinderWireInCount++; }

switch(beamFinderWireInCount)
{
    case 0:  state = 0; break; /* No BFWs in */
    case 1:  state = 1; break; /* One BFW in */
    default: state = 2; break; /* More than one BFW in */
}
```

Name	State	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
No BFWs In	0	120 Hz	120 Hz	120 Hz	–	–	–	–
One BFW In	1	10 Hz	10 Hz	10 Hz	–	–	–	–
More Than One BFW In	2	0 Hz	0 Hz	0 Hz	–	–	–	–

23.37 BLM Argonne Heartbeat (LN32)

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = BLM_UND1_120_TEST_L_THRESHOLD,
B = BLM_UND1_120_TEST_H_THRESHOLD

23.38 BLM Argonne Heartbeat (LN33)

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = BLM_UND1_920_TEST_L_THRESHOLD,
B = BLM_UND1_920_TEST_H_THRESHOLD

23.39 BLM Argonne Heartbeat (LN35)

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = BLM_UND1_1720_TEST_L_THRESHOLD,
B = BLM_UND1_1720_TEST_H_THRESHOLD

23.40 BLM Argonne Heartbeat (LN36)

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `BLM_2520_QTL_THRESHOLD`,
B = `BLM_2520_QTH_THRESHOLD`

23.41 BLM Argonne Heartbeat (LN37)

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `BLM_UND1_3320_TEST_L_THRESHOLD`,
B = `BLM_UND1_3320_TEST_H_THRESHOLD`

23.42 BLM HVPS UND1 120

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `HVPS_UND1_120_LOW_FAULT`,
B = `HVPS_UND1_120_HIGH_FAULT`

23.43 BLM HVPS UND1 1720

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `HVPS_UND1_1720_LOW_FAULT`,
B = `HVPS_UND1_1720_HIGH_FAULT`

23.44 BLM HVPS UND1 2221

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `HVPS_UND1_2221_LOW_FAULT`,
B = `HVPS_UND1_2221_HIGH_FAULT`

23.45 BLM HVPS UND1 2520

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `HVPS_UND1_2520_LOW_FAULT`,
B = `HVPS_UND1_2520_HIGH_FAULT`

23.46 BLM HVPS UND1 3320

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = HVPS_UND1_3320_LOW_FAULT,
B = HVPS_UND1_3320_HIGH_FAULT

23.47 BLM HVPS UND1 920

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = HVPS_UND1_920_LOW_FAULT,
B = HVPS_UND1_920_HIGH_FAULT

23.48 BLM Pedestal Thresholds: LTU1 722

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = BLM_LTU1_722_PED_L_THRESHOLD,
B = BLM_LTU1_722_PED_H_THRESHOLD

23.49 BLM Pedestal Thresholds: LTU1 732

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `BLM_LTU1_732_PED_L_THRESHOLD`,
B = `BLM_LTU1_732_PED_H_THRESHOLD`

23.50 BLM Pedestal Thresholds: LTU1 762

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `BLM_LTU1_762_PED_L_THRESHOLD`,
B = `BLM_LTU1_762_PED_H_THRESHOLD`

23.51 BLM Pedestal Thresholds: LTU1 772

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `BLM_LTU1_772_PED_L_THRESHOLD`,
B = `BLM_LTU1_772_PED_H_THRESHOLD`

23.52 BLM Pedestal Thresholds: LTU1 980

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `BLM_LTU1_980_PED_L_THRESHOLD`,
B = `BLM_LTU1_980_PED_H_THRESHOLD`

23.53 BLM Pedestal Thresholds: UND 1021

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `BLM_UND1_1021_PED_L_THRESHOLD`,
B = `BLM_UND1_1021_PED_H_THRESHOLD`

23.54 BLM Pedestal Thresholds: UND 1121

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `BLM_UND1_1121_PED_L_THRESHOLD`,
B = `BLM_UND1_1121_PED_H_THRESHOLD`

23.55 BLM Pedestal Thresholds: UND 120

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `BLM_UND1_120_PED_L_THRESHOLD`,
B = `BLM_UND1_120_PED_H_THRESHOLD`

23.56 BLM Pedestal Thresholds: UND 121

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `BLM_UND1_121_PED_L_THRESHOLD`,
B = `BLM_UND1_121_PED_H_THRESHOLD`

23.57 BLM Pedestal Thresholds: UND 1221

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `BLM_UND1_1221_PED_L_THRESHOLD`,
B = `BLM_UND1_1221_PED_H_THRESHOLD`

23.58 BLM Pedestal Thresholds: UND 1321

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `BLM_UND1_1321_PED_L_THRESHOLD`,
B = `BLM_UND1_1321_PED_H_THRESHOLD`

23.59 BLM Pedestal Thresholds: UND 1421

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `BLM_UND1_1421_PED_L_THRESHOLD`,
B = `BLM_UND1_1421_PED_H_THRESHOLD`

23.60 BLM Pedestal Thresholds: UND 1521

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `BLM_UND1_1521_PED_L_THRESHOLD`,
B = `BLM_UND1_1521_PED_H_THRESHOLD`

23.61 BLM Pedestal Thresholds: UND 1621

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = BLM_UND1_1621_PED_L_THRESHOLD,
B = BLM_UND1_1621_PED_H_THRESHOLD

23.62 BLM Pedestal Thresholds: UND 1720

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = BLM_UND1_1720_PED_L_THRESHOLD,
B = BLM_UND1_1720_PED_H_THRESHOLD

23.63 BLM Pedestal Thresholds: UND 1721

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = BLM_UND1_1721_PED_L_THRESHOLD,
B = BLM_UND1_1721_PED_H_THRESHOLD

23.64 BLM Pedestal Thresholds: UND 1821

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `BLM_UND1_1821_PED_L_THRESHOLD`,
B = `BLM_UND1_1821_PED_H_THRESHOLD`

23.65 BLM Pedestal Thresholds: UND 1921

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `BLM_UND1_1921_PED_L_THRESHOLD`,
B = `BLM_UND1_1921_PED_H_THRESHOLD`

23.66 BLM Pedestal Thresholds: UND 2021

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `BLM_UND1_2021_PED_L_THRESHOLD`,
B = `BLM_UND1_2021_PED_H_THRESHOLD`

23.67 BLM Pedestal Thresholds: UND 2121

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = BLM_UND1_2121_PED_L_THRESHOLD,
B = BLM_UND1_2121_PED_H_THRESHOLD

23.68 BLM Pedestal Thresholds: UND 221

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = BLM_UND1_221_PED_L_THRESHOLD,
B = BLM_UND1_221_PED_H_THRESHOLD

23.69 BLM Pedestal Thresholds: UND 2221

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = BLM_2220_QBLL_THRESHOLD,
B = BLM_2220_QBLH_THRESHOLD

23.70 BLM Pedestal Thresholds: UND 2321

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `BLM_2320_QBLL_THRESHOLD`,
B = `BLM_2320_QBLH_THRESHOLD`

23.71 BLM Pedestal Thresholds: UND 2421

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `BLM_2420_QBLL_THRESHOLD`,
B = `BLM_2420_QBLH_THRESHOLD`

23.72 BLM Pedestal Thresholds: UND 2520

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `BLM_2520_QBLL_THRESHOLD`,
B = `BLM_2520_QBLH_THRESHOLD`

23.73 BLM Pedestal Thresholds: UND 2521

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `BLM_UND1_2521_PED_L_THRESHOLD`,
B = `BLM_UND1_2521_PED_H_THRESHOLD`

23.74 BLM Pedestal Thresholds: UND 2621

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `BLM_2620_QBLL_THRESHOLD`,
B = `BLM_2620_QBLH_THRESHOLD`

23.75 BLM Pedestal Thresholds: UND 2721

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `BLM_2720_QBLL_THRESHOLD`,
B = `BLM_2720_QBLH_THRESHOLD`

23.76 BLM Pedestal Thresholds: UND 2821

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `BLM_2820_QBLL_THRESHOLD`,
B = `BLM_2820_QBLH_THRESHOLD`

23.77 BLM Pedestal Thresholds: UND 2921

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `BLM_2920_QBLL_THRESHOLD`,
B = `BLM_2920_QBLH_THRESHOLD`

23.78 BLM Pedestal Thresholds: UND 3021

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `BLM_UND1_3021_PED_L_THRESHOLD`,
B = `BLM_UND1_3021_PED_H_THRESHOLD`

23.79 BLM Pedestal Thresholds: UND 3121

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `BLM_UND1_3121_PED_L_THRESHOLD`,
B = `BLM_UND1_3121_PED_H_THRESHOLD`

23.80 BLM Pedestal Thresholds: UND 321

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `BLM_UND1_321_PED_L_THRESHOLD`,
B = `BLM_UND1_321_PED_H_THRESHOLD`

23.81 BLM Pedestal Thresholds: UND 3221

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `BLM_UND1_3221_PED_L_THRESHOLD`,
B = `BLM_UND1_3221_PED_H_THRESHOLD`

23.82 BLM Pedestal Thresholds: UND 3320

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `BLM_UND1_3320_PED_L_THRESHOLD`,
B = `BLM_UND1_3320_PED_H_THRESHOLD`

23.83 BLM Pedestal Thresholds: UND 3321

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `BLM_UND1_3321_PED_L_THRESHOLD`,
B = `BLM_UND1_3321_PED_H_THRESHOLD`

23.84 BLM Pedestal Thresholds: UND 421

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `BLM_UND1_421_PED_L_THRESHOLD`,
B = `BLM_UND1_421_PED_H_THRESHOLD`

23.85 BLM Pedestal Thresholds: UND 521

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `BLM_UND1_521_PED_L_THRESHOLD`,
B = `BLM_UND1_521_PED_H_THRESHOLD`

23.86 BLM Pedestal Thresholds: UND 621

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `BLM_UND1_621_PED_L_THRESHOLD`,
B = `BLM_UND1_621_PED_H_THRESHOLD`

23.87 BLM Pedestal Thresholds: UND 721

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `BLM_UND1_721_PED_L_THRESHOLD`,
B = `BLM_UND1_721_PED_H_THRESHOLD`

23.88 BLM Pedestal Thresholds: UND 821

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `BLM_UND1_821_PED_L_THRESHOLD`,
B = `BLM_UND1_821_PED_H_THRESHOLD`

23.89 BLM Pedestal Thresholds: UND 920

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `BLM_UND1_920_PED_L_THRESHOLD`,
B = `BLM_UND1_920_PED_H_THRESHOLD`

23.90 BLM Pedestal Thresholds: UND 921

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `BLM_UND1_921_PED_L_THRESHOLD`,
B = `BLM_UND1_921_PED_H_THRESHOLD`

23.91 BLM Pedestal Thresholds: UND BLF1

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = BLM_UND1_BLF1_PED_L_THRESHOLD,
B = BLM_UND1_BLF1_PED_H_THRESHOLD

23.92 BLM Pedestal Thresholds: UND BLF17

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = BLM_UND1_BLF17_PED_L_THRESHOLD,
B = BLM_UND1_BLF17_PED_H_THRESHOLD

23.93 BLM PEP Timing Check (LN32)

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = BLM_LTU1_762_TEST_L_THRESHOLD,
B = BLM_LTU1_762_TEST_H_THRESHOLD

23.94 BLM PEP Timing Check (LN33)

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `BLM_UND1_621_TEST_L_THRESHOLD`,
B = `BLM_UND1_621_TEST_H_THRESHOLD`

23.95 BLM PEP Timing Check (LN35)

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `BLM_UND1_1421_TEST_L_THRESHOLD`,
B = `BLM_UND1_1421_TEST_H_THRESHOLD`

23.96 BLM PEP Timing Check (LN36)

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `BLM_2220_QTL_THRESHOLD`,
B = `BLM_2220_QTH_THRESHOLD`

23.97 BLM PEP Timing Check (LN37)

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `BLM_UND1_3021_TEST_L_THRESHOLD`,
B = `BLM_UND1_3021_TEST_H_THRESHOLD`

23.98 BLM Raw Charge Thresholds: LTU1 722

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `BLM_LTU1_722_LOSS_L_THRESHOLD`,
B = `BLM_LTU1_722_LOSS_H_THRESHOLD`

23.99 BLM Raw Charge Thresholds: LTU1 732

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `BLM_LTU1_732_LOSS_L_THRESHOLD`,
B = `BLM_LTU1_732_LOSS_H_THRESHOLD`

23.100 BLM Raw Charge Thresholds: LTU1 762

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `BLM_LTU1_762_LOSS_L_THRESHOLD`,
B = `BLM_LTU1_762_LOSS_H_THRESHOLD`

23.101 BLM Raw Charge Thresholds: LTU1 772

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `BLM_LTU1_772_LOSS_L_THRESHOLD`,
B = `BLM_LTU1_772_LOSS_H_THRESHOLD`

23.102 BLM Raw Charge Thresholds: LTU1 980

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `BLM_LTU1_980_LOSS_L_THRESHOLD`,
B = `BLM_LTU1_980_LOSS_H_THRESHOLD`

23.103 BLM Raw Charge Thresholds: UND 1021

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = BLM_UND1_1021_LOSS_L_THRESHOLD,
B = BLM_UND1_1021_LOSS_H_THRESHOLD

23.104 BLM Raw Charge Thresholds: UND 1121

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = BLM_UND1_1121_LOSS_L_THRESHOLD,
B = BLM_UND1_1121_LOSS_H_THRESHOLD

23.105 BLM Raw Charge Thresholds: UND 120

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = BLM_UND1_120_LOSS_L_THRESHOLD,
B = BLM_UND1_120_LOSS_H_THRESHOLD

23.106 BLM Raw Charge Thresholds: UND 121

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = BLM_UND1_121_LOSS_L_THRESHOLD,
B = BLM_UND1_121_LOSS_H_THRESHOLD

23.107 BLM Raw Charge Thresholds: UND 1221

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = BLM_UND1_1221_LOSS_L_THRESHOLD,
B = BLM_UND1_1221_LOSS_H_THRESHOLD

23.108 BLM Raw Charge Thresholds: UND 1321

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = BLM_UND1_1321_LOSS_L_THRESHOLD,
B = BLM_UND1_1321_LOSS_H_THRESHOLD

23.109 BLM Raw Charge Thresholds: UND 1421

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = BLM_UND1_1421_LOSS_L_THRESHOLD,
B = BLM_UND1_1421_LOSS_H_THRESHOLD

23.110 BLM Raw Charge Thresholds: UND 1521

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = BLM_UND1_1521_LOSS_L_THRESHOLD,
B = BLM_UND1_1521_LOSS_H_THRESHOLD

23.111 BLM Raw Charge Thresholds: UND 1621

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = BLM_UND1_1621_LOSS_L_THRESHOLD,
B = BLM_UND1_1621_LOSS_H_THRESHOLD

23.112 BLM Raw Charge Thresholds: UND 1720

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = BLM_UND1_1720_LOSS_L_THRESHOLD,
B = BLM_UND1_1720_LOSS_H_THRESHOLD

23.113 BLM Raw Charge Thresholds: UND 1721

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = BLM_UND1_1721_LOSS_L_THRESHOLD,
B = BLM_UND1_1721_LOSS_H_THRESHOLD

23.114 BLM Raw Charge Thresholds: UND 1821

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = BLM_UND1_1821_LOSS_L_THRESHOLD,
B = BLM_UND1_1821_LOSS_H_THRESHOLD

23.115 BLM Raw Charge Thresholds: UND 1921

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = BLM_UND1_1921_LOSS_L_THRESHOLD,
B = BLM_UND1_1921_LOSS_H_THRESHOLD

23.116 BLM Raw Charge Thresholds: UND 2021

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = BLM_UND1_2021_LOSS_L_THRESHOLD,
B = BLM_UND1_2021_LOSS_H_THRESHOLD

23.117 BLM Raw Charge Thresholds: UND 2121

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = BLM_UND1_2121_LOSS_L_THRESHOLD,
B = BLM_UND1_2121_LOSS_H_THRESHOLD

23.118 BLM Raw Charge Thresholds: UND 221

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `BLM_UND1_221_LOSS_L_THRESHOLD`,
B = `BLM_UND1_221_LOSS_H_THRESHOLD`

23.119 BLM Raw Charge Thresholds: UND 2221

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `BLM_2220_QBL_THRESHOLD`,
B = `BLM_2220_QBH_THRESHOLD`

23.120 BLM Raw Charge Thresholds: UND 2321

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `BLM_2320_QBL_THRESHOLD`,
B = `BLM_2320_QBH_THRESHOLD`

23.121 BLM Raw Charge Thresholds: UND 2421

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `BLM_2420_QBL_THRESHOLD`,
B = `BLM_2420_QBH_THRESHOLD`

23.122 BLM Raw Charge Thresholds: UND 2520

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `BLM_2520_QBL_THRESHOLD`,
B = `BLM_2520_QBH_THRESHOLD`

23.123 BLM Raw Charge Thresholds: UND 2521

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `BLM_UND1_2521_LOSS_L_THRESHOLD`,
B = `BLM_UND1_2521_LOSS_H_THRESHOLD`

23.124 BLM Raw Charge Thresholds: UND 2621

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `BLM_2620_QBL_THRESHOLD`,
B = `BLM_2620_QBH_THRESHOLD`

23.125 BLM Raw Charge Thresholds: UND 2721

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `BLM_2720_QBL_THRESHOLD`,
B = `BLM_2720_QBH_THRESHOLD`

23.126 BLM Raw Charge Thresholds: UND 2821

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `BLM_2820_QBL_THRESHOLD`,
B = `BLM_2820_QBH_THRESHOLD`

23.127 BLM Raw Charge Thresholds: UND 2921

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = BLM_2920_QBL_THRESHOLD,
B = BLM_2920_QBH_THRESHOLD

23.128 BLM Raw Charge Thresholds: UND 3021

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = BLM_UND1_3021_LOSS_L_THRESHOLD,
B = BLM_UND1_3021_LOSS_H_THRESHOLD

23.129 BLM Raw Charge Thresholds: UND 3121

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = BLM_UND1_3121_LOSS_L_THRESHOLD,
B = BLM_UND1_3121_LOSS_H_THRESHOLD

23.130 BLM Raw Charge Thresholds: UND 321

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `BLM_UND1_321_LOSS_L_THRESHOLD`,
B = `BLM_UND1_321_LOSS_H_THRESHOLD`

23.131 BLM Raw Charge Thresholds: UND 3221

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `BLM_UND1_3221_LOSS_L_THRESHOLD`,
B = `BLM_UND1_3221_LOSS_H_THRESHOLD`

23.132 BLM Raw Charge Thresholds: UND 3320

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `BLM_UND1_3320_LOSS_L_THRESHOLD`,
B = `BLM_UND1_3320_LOSS_H_THRESHOLD`

23.133 BLM Raw Charge Thresholds: UND 3321

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = BLM_UND1_3321_LOSS_L_THRESHOLD,
B = BLM_UND1_3321_LOSS_H_THRESHOLD

23.134 BLM Raw Charge Thresholds: UND 421

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = BLM_UND1_421_LOSS_L_THRESHOLD,
B = BLM_UND1_421_LOSS_H_THRESHOLD

23.135 BLM Raw Charge Thresholds: UND 521

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = BLM_UND1_521_LOSS_L_THRESHOLD,
B = BLM_UND1_521_LOSS_H_THRESHOLD

23.136 BLM Raw Charge Thresholds: UND 621

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `BLM_UND1_621_LOSS_L_THRESHOLD`,
B = `BLM_UND1_621_LOSS_H_THRESHOLD`

23.137 BLM Raw Charge Thresholds: UND 721

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `BLM_UND1_721_LOSS_L_THRESHOLD`,
B = `BLM_UND1_721_LOSS_H_THRESHOLD`

23.138 BLM Raw Charge Thresholds: UND 821

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `BLM_UND1_821_LOSS_L_THRESHOLD`,
B = `BLM_UND1_821_LOSS_H_THRESHOLD`

23.139 BLM Raw Charge Thresholds: UND 920

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = BLM_UND1_920_LOSS_L_THRESHOLD,
B = BLM_UND1_920_LOSS_H_THRESHOLD

23.140 BLM Raw Charge Thresholds: UND 921

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = BLM_UND1_921_LOSS_L_THRESHOLD,
B = BLM_UND1_921_LOSS_H_THRESHOLD

23.141 BLM Raw Charge Thresholds: UND BLF1

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = BLM_UND1_BLF1_LOSS_L_THRESHOLD,
B = BLM_UND1_BLF1_LOSS_H_THRESHOLD

23.142 BLM Raw Charge Thresholds: UND BLF17

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = BLM_UND1_BLF17_LOSS_L_THRESHOLD,
B = BLM_UND1_BLF17_LOSS_H_THRESHOLD

23.143 BLM Trigger Missed (LN32)

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Missed	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = BLM_LTU1_762_NO_TRIG_MISSED

23.144 BLM Trigger Missed (LN33)

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Missed	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = BLM_UND1_6_NO_TRIG_MISSED

23.145 BLM Trigger Missed (LN35)

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Missed	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = BLM_UND1_14_NO_TRIG_MISSED

23.146 BLM Trigger Missed (LN36)

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Missed	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = BLM_TRIG_MISSED

23.147 BLM Trigger Missed (LN37)

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Missed	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = BLM_UND1_30_NO_TRIG_MISSED

23.148 BLM/PIC Watchdog: Downstream of TDUND

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Faulted	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = MPS_MCC0_2_PICBLM_WD_STATUS

23.149 BOD UND1 1005

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Moving	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Out	F	T	120 Hz	120 Hz	120 Hz	–	–	–	–
In	T	F	10 Hz	10 Hz	10 Hz	–	–	–	–
Broken	T	T	0 Hz	0 Hz	0 Hz	–	–	–	–

Where
A = BOD_UND1_1005_OUT_LIMIT_POSITION,
B = BOD_UND1_1005_IN_LIMIT_POSITION

23.150 BOD UND1 1305

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Moving	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Out	F	T	120 Hz	120 Hz	120 Hz	–	–	–	–
In	T	F	10 Hz	10 Hz	10 Hz	–	–	–	–
Broken	T	T	0 Hz	0 Hz	0 Hz	–	–	–	–

Where
A = BOD_UND1_1305_OUT_LIMIT_POSITION,
B = BOD_UND1_1305_IN_LIMIT_POSITION

23.151 BPM Summary (1-9) - Status From IOC-UND1-BP01

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Faulted	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = IOC_UND1_BP01_MPSSTAT_STATE

23.152 BPM Summary (10-18) - Status From IOC-UND1-BP02

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Faulted	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = IOC_UND1_BP02_MPSSTAT_STATE

23.153 BPM Summary (19-27) - Status From IOC-UND1-BP03

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Faulted	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = IOC_UND1_BP03_MPSSTAT_STATE

23.154 BPM Summary (28-36) - Status From IOC-UND1-BP04

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Faulted	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = IOC_UND1_BP04_MPSSTAT_STATE

23.155 FEE Camera 1692 Position

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Moving	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Out	F	T	120 Hz	120 Hz	120 Hz	–	–	–	–
In	T	F	120 Hz	120 Hz	120 Hz	–	–	–	–
Broken	T	T	0 Hz	0 Hz	0 Hz	–	–	–	–

Where
A = CAMR_FEE1_1692_OUT_STATE,
B = CAMR_FEE1_1692_IN_STATE

23.156 FEE Camera 1953 Position

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Moving	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Out	F	T	120 Hz	120 Hz	120 Hz	–	–	–	–
In	T	F	120 Hz	120 Hz	120 Hz	–	–	–	–
Broken	T	T	0 Hz	0 Hz	0 Hz	–	–	–	–

Where
A = CAMR_FEE1_1953_OUT_STATE,
B = CAMR_FEE1_1953_IN_STATE

23.157 FEE Camera 2953 Position

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Moving	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Out	F	T	120 Hz	120 Hz	120 Hz	–	–	–	–
In	T	F	120 Hz	120 Hz	120 Hz	–	–	–	–
Broken	T	T	0 Hz	0 Hz	0 Hz	–	–	–	–

Where
A = `CAMR_FEE1_2953_OUT_STATE`,
B = `CAMR_FEE1_2953_IN_STATE`

23.158 FEE Camera 852 Position Fault - Status From PLC

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Fault	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Ok	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `CAMR_FEE1_852_STATUS_FAULT`

23.159 FEE Camera 913 Position Fault - Status From PLC

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Fault	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Ok	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `CAMR_FEE1_913_STATUS_FAULT`

23.160 FEE Gas System Summary

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Fault	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Ok	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = VMPS_FEE1_GAS_SUM_FAULT

23.161 FEE HXTD Vacuum Valve Summary

Name	A	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not All Open	F	0 Hz	0 Hz	0 Hz	–	–	–	–
All Open	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = VMPS_FEE1_HXTD_SUM_FAULT

23.162 FEE M1S Mirror Beam Energy Upper Limit

Name	B	A	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Fault	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Mirror Out	F	T	120 Hz	120 Hz	120 Hz	–	–	–	–
Energy Ok	T	F	120 Hz	120 Hz	120 Hz	–	–	–	–
Mirror Out and Energy Ok	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = MIRR_FEE1_1560_OUT_LIMIT1_POSITION,
B = MIRR_FEE1_1560_ENERGY_STATE

23.163 FEE M1S Mirror State

Name	B	A	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not Out	F	F	120 Hz	120 Hz	120 Hz	–	–	–	–
Inconsistent	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Inconsistent	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Out	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = MIRR_FEE1_1560_OUT_LIMIT1_POSITION,
B = MIRR_FEE1_1560_OUT_LIMIT2_POSITION

23.164 FEE Spectrometer Crystal - Beam Energy Too Low When Crystal Not Out

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Fault	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Energy Ok	F	T	120 Hz	120 Hz	120 Hz	–	–	–	–
Crystal Out	T	F	120 Hz	120 Hz	120 Hz	–	–	–	–
Crystal Out and Energy Ok	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `XTAL_FEE1_441_ENERGY_STATE`,
B = `XTAL_FEE1_441_OUT_LIMSW_POSITION`

23.165 FEE Spectrometer Crystal - Pulse Energy Too High When Crystal Not Out

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Fault	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Pulse Energy Ok	F	T	120 Hz	120 Hz	120 Hz	–	–	–	–
Crystal Out	T	F	120 Hz	120 Hz	120 Hz	–	–	–	–
Crystal Out and Pulse Energy Ok	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `XTAL_FEE1_441_PULSEENERGY_THRESHOLD`,
B = `XTAL_FEE1_441_OUT_LIMSW_POSITION`

23.166 FEE XTOD S1 Isolation Valve Summary

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Fault	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `VMPS_FEE1_703_ISOL_S1_FAULT`

23.167 FEE XTOD S2 Isolation Valve Summary

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Fault	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `VMPS_FEE1_703_ISOL_S2_FAULT`

23.168 Gas Detector Problem When FEE Spectrometer Crystal Not Out

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Fault	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Gas Detector Ok	F	T	120 Hz	120 Hz	120 Hz	–	–	–	–
Crystal Out	T	F	120 Hz	120 Hz	120 Hz	–	–	–	–
Crystal Out and Gas Detector Ok	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `GDET_FEE1_1_CAL_OK_STATE`,
B = `XTAL_FEE1_441_OUT_LIMSW_POSITION`

23.169 HXR - Beam Energy Too Low With M1S Out

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Ok	F	F	120 Hz	120 Hz	120 Hz	–	–	–	–
Ok	F	T	120 Hz	120 Hz	120 Hz	–	–	–	–
Ok	T	F	120 Hz	120 Hz	120 Hz	–	–	–	–
Fault	T	T	0 Hz	0 Hz	0 Hz	–	–	–	–

Where
A = `MIRR_FEE1_1560_ENERGY_STATE`,
B = `MIRR_FEE1_1560_OUT_LIMIT1_POSITION`

23.170 Magnet In Tolerance: QE31

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
No	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Yes	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = QUAD_LTU1_720_INTOL_STATUS

23.171 Magnet In Tolerance: QUM1

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
No	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Yes	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = QUAD_LTU1_820_INTOL_STATUS

23.172 Magnet In Tolerance: QUM2

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
No	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Yes	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = QUAD_LTU1_840_INTOL_STATUS

23.173 Magnet In Tolerance: QUM3

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
No	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Yes	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = QUAD_LTU1_860_INTOL_STATUS

23.174 Magnet In Tolerance: QUM4

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
No	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Yes	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = QUAD_LTU1_880_INTOL_STATUS

23.175 Magnet Power: QE31

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Off	F	0 Hz	0 Hz	0 Hz	–	–	–	–
On	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = QUAD_LTU1_720_STATE_STATUS

23.176 Magnet Power: QUM1

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Off	F	0 Hz	0 Hz	0 Hz	–	–	–	–
On	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = QUAD_LTU1_820_STATE_STATUS

23.177 Magnet Power: QUM2

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Off	F	0 Hz	0 Hz	0 Hz	–	–	–	–
On	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = QUAD_LTU1_840_STATE_STATUS

23.178 Magnet Power: QUM3

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Off	F	0 Hz	0 Hz	0 Hz	–	–	–	–
On	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `QUAD_LTU1_860_STATE_STATUS`

23.179 Magnet Power: QUM4

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Off	F	0 Hz	0 Hz	0 Hz	–	–	–	–
On	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `QUAD_LTU1_880_STATE_STATUS`

23.180 OTR01 IN20 541 Position and TDUND Not In

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Moving	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Out	F	T	120 Hz	120 Hz	120 Hz	–	–	–	–
In	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Broken	T	T	0 Hz	0 Hz	0 Hz	–	–	–	–

Where
A = `OTRS_IN20_541_OUT_LMTSW_STATE`,
B = `OTRS_IN20_541_IN_LMTSW_STATE`

23.181 OTR02 IN20 571 Position and TDUND Not In

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Moving	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Out	F	T	120 Hz	120 Hz	120 Hz	–	–	–	–
In	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Broken	T	T	0 Hz	0 Hz	0 Hz	–	–	–	–

Where
A = OTRS_IN20_571_OUT_LMTSW_STATE,
B = OTRS_IN20_571_IN_LMTSW_STATE

23.182 OTR03 IN20 621 Position and TDUND Not In

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Moving	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Out	F	T	120 Hz	120 Hz	120 Hz	–	–	–	–
In	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Broken	T	T	0 Hz	0 Hz	0 Hz	–	–	–	–

Where
A = OTRS_IN20_621_OUT_LMTSW_STATE,
B = OTRS_IN20_621_IN_LMTSW_STATE

23.183 OTR04 IN20 711 Position and TDUND Not In

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Moving	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Out	F	T	120 Hz	120 Hz	120 Hz	–	–	–	–
In	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Broken	T	T	0 Hz	0 Hz	0 Hz	–	–	–	–

Where
A = OTRS_IN20_711_OUT_LMTSW_STATE,
B = OTRS_IN20_711_IN_LMTSW_STATE

23.184 OTR11 LI21 237 Position and TDUND Not In

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Moving	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Out	F	T	120 Hz	120 Hz	120 Hz	–	–	–	–
In	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Broken	T	T	0 Hz	0 Hz	0 Hz	–	–	–	–

Where
A = OTRS_LI21_237_OUT_LMTSW_STATE,
B = OTRS_LI21_237_IN_LMTSW_STATE

23.185 OTR12 LI21 291 Position and TDUND Not In

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Moving	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Out	F	T	120 Hz	120 Hz	120 Hz	–	–	–	–
In	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Broken	T	T	0 Hz	0 Hz	0 Hz	–	–	–	–

Where
A = OTRS_LI21_291_OUT_LMTSW_STATE,
B = OTRS_LI21_291_IN_LMTSW_STATE

23.186 OTR21 Position When TDUND Not In

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Moving	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Out	F	T	120 Hz	120 Hz	120 Hz	–	–	–	–
In	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Broken	T	T	0 Hz	0 Hz	0 Hz	–	–	–	–

Where
A = OTRS_LI24_807_OUT_LMTSW_STATE,
B = OTRS_LI24_807_IN_LMTSW_STATE

23.187 OTR33 Position When TDUND Not In

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Moving	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Out	F	T	120 Hz	120 Hz	120 Hz	–	–	–	–
In	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Broken	T	T	0 Hz	0 Hz	0 Hz	–	–	–	–

Where
A = `OTR33_0745_OUT_STATE`,
B = `OTR33_0745_IN_STATE`

23.188 OTRH1 Position When TDUND Not In

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Moving	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Out	F	T	120 Hz	120 Hz	120 Hz	–	–	–	–
In	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Broken	T	T	0 Hz	0 Hz	0 Hz	–	–	–	–

Where
A = `OTRH1_OUT_LIMIT_STATE`,
B = `OTRH1_IN_LIMIT_STATE`

23.189 OTRH2 Position When TDUND Not In

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Moving	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Out	F	T	120 Hz	120 Hz	120 Hz	–	–	–	–
In	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Broken	T	T	0 Hz	0 Hz	0 Hz	–	–	–	–

Where
A = `OTRH2_OUT_LIMIT_STATE`,
B = `OTRH2_IN_LIMIT_STATE`

23.190 PIC HVPS B921 - Location B921-2235

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not On	F	0 Hz	0 Hz	0 Hz	–	–	–	–
On	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = PICM_DMP1_B921_HV_PWR_STATE

23.191 PIC Raw Charge Thresholds: DMP1 698

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = PICS_DMP1_100_LOSSL_THRESHOLD,
B = PICS_DMP1_100_LOSSH_THRESHOLD

23.192 PIC Raw Charge Thresholds: DMP1 699

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = PICS_DMP2_200_LOSSL_THRESHOLD,
B = PICS_DMP2_200_LOSSH_THRESHOLD

23.193 PIC Trigger Missed (LN34)

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Missed	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = PICS_DMP1_100_NO_TRIG_MISSED

23.194 Toroid Comparator Dump (IMUNDO vs IMDUMP)

Name	B	A	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
3E8 ppb Gain	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
3E8 ppb Loss	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Under 3E8 ppb Loss	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = IMUNDO_COMP_L1_STATE,
B = IMUNDO_COMP_L2_STATE

23.195 Toroid Comparator Power Status (B921)

Name	A	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Powered Off	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Powered On	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = COMP_STAT_ON_STATE

23.196 Toroid Comparator Undulator (IMUNDI vs IMUNDO)

Name	B	A	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
3E8 ppb Gain	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
3E8 ppb Loss	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Under 3E8 ppb Loss	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = IMUNDI_COMP_L1_STATE,
B = IMUNDI_COMP_L2_STATE

23.197 VVFS DMP1 107 Position

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not Open	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Open	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `VVFS_DMP1_107_OPEN_LMTSW_STATE`

23.198 VVMG DMP1 743 Position

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not Open	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Open	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `VVMG_DMP1_743_POSITION_STATE`

23.199 VVMG UND1 1645 Position

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not Out	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Out	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `VVMG_UND1_1645_OPEN_LMTSW_STATE`

23.200 VVMG UND1 1655 Position

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not Out	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Out	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `VVMG_UND1_1655_OPEN_LMTSW_STATE`

23.201 VVPG DMP1 355 Position

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Moving	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Open	F	T	120 Hz	120 Hz	120 Hz	–	–	–	–
Closed	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Broken	T	T	0 Hz	0 Hz	0 Hz	–	–	–	–

Where
A = `VVPG_DMP1_355_OPENSTATUS_STATE`,
B = `VVPG_DMP1_355_CLOSEDSTATUS_STATE`

23.202 XLEAP PRXL1 - YAGS LTU1 844 Position and TDUND Not In

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Moving	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Out	F	T	120 Hz	120 Hz	120 Hz	–	–	–	–
In	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Broken	T	T	0 Hz	0 Hz	0 Hz	–	–	–	–

Where
A = `YAGS_LTU1_844_OUT_LIMSW_POSITION`,
B = `YAGS_LTU1_844_IN_LIMSW_POSITION`

23.203 XLEAP PRXL2 - YAGS LTU1 853 Position and TDUND Not In

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Moving	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Out	F	T	120 Hz	120 Hz	120 Hz	–	–	–	–
In	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Broken	T	T	0 Hz	0 Hz	0 Hz	–	–	–	–

Where
A = `YAGS_LTU1_853_OUT_LIMSW_POSITION`,
B = `YAGS_LTU1_853_IN_LIMSW_POSITION`

23.204 XLEAP PRXL3 - OTRS LTU1 858 Position and TDUND Not In

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Moving	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Out	F	T	120 Hz	120 Hz	120 Hz	–	–	–	–
In	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Broken	T	T	0 Hz	0 Hz	0 Hz	–	–	–	–

Where
A = `OTRS_LTU1_858_OUT_LIMSW_POSITION`,
B = `OTRS_LTU1_858_IN_LIMSW_POSITION`

23.205 YAG LTU1 743 Position When TDUND Not In (PSI Prof Mon)

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Moving	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Out	F	T	120 Hz	120 Hz	120 Hz	–	–	–	–
In	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Broken	T	T	0 Hz	0 Hz	0 Hz	–	–	–	–

Where
A = `YAGS_LTU1_743_OUT_LIMIT_POSITION`,
B = `YAGS_LTU1_743_IN_LIMIT_POSITION`

24 Ignored when Stopper: BSY D2 Summary Is In, TD11 Is In, YAG01 Is In, or YAG02 Is In

24.1 BCS LION LTU1 404 Threshold

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Exceeded	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `LION404_STATE`

24.2 BCS LION LTU1 405 Threshold

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Exceeded	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `LION405_STATE`

24.3 BCS LION LTU1 504 Threshold

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Exceeded	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `LION504_STATE`

24.4 BCS LION LTU1 505 Threshold

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Exceeded	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = LION505_STATE

24.5 BCS LION LTU1 584 Threshold

Name	A	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Exceeded	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = LION584_STATE

24.6 BCS LION LTU1 585 Threshold

Name	A	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Exceeded	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = LION585_STATE

24.7 BCS LION LTU1 716 Threshold

Name	A	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Exceeded	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = LION716_STATE

24.8 BCS LION LTU1 717 Threshold

Name	A	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Exceeded	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = LION717_STATE

24.9 BCS LION LTU1 732 Threshold

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Exceeded	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `LION732_STATE`

24.10 BCS LION LTU1 733 Threshold

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Exceeded	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `LION733_STATE`

24.11 BCS LION LTU1 752 Threshold

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Exceeded	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `LION752_STATE`

24.12 BCS LION LTU1 753 Threshold

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Exceeded	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `LION753_STATE`

24.13 BCS LION LTU1 765 Threshold

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Exceeded	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `LION765_STATE`

24.14 BCS LION LTU1 766 Threshold

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Exceeded	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `LION766_STATE`

24.15 BLM Heartbeat: Dechirper LTU1 BLF545

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `BLM_LTU1_BLF545_TEST_L_THRESHOLD`,
B = `BLM_LTU1_BLF545_TEST_H_THRESHOLD`

24.16 BLM Heartbeat: XLEAP LTU1 BLF859

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = BLM_LTU1_BLF859_TEST_L_THRESHOLD,
B = BLM_LTU1_BLF859_TEST_H_THRESHOLD

24.17 BLM HVPS LTU1 762

Name	B	A	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = HVPS_LTU1_762_LOW_FAULT,
B = HVPS_LTU1_762_HIGH_FAULT

24.18 BLM Pedestal Thresholds: Dechirper LTU1 BLF545

Name	B	A	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = BLM_LTU1_BLF545_PED_L_THRESHOLD,
B = BLM_LTU1_BLF545_PED_H_THRESHOLD

24.19 BLM Pedestal Thresholds: XLEAP LTU1 BLF859

Name	B	A	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = BLM_LTU1_BLF859_PED_L_THRESHOLD,
B = BLM_LTU1_BLF859_PED_H_THRESHOLD

24.20 BLM PEP Timing Check (LN30)

Name	B	A	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = BLM_LTU1_722_TEST_L_THRESHOLD,
B = BLM_LTU1_722_TEST_H_THRESHOLD

24.21 BLM Raw Charge Thresholds: Dechirper LTU1 BLF545

Name	B	A	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = BLM_LTU1_BLF545_LOSS_L_THRESHOLD,
B = BLM_LTU1_BLF545_LOSS_H_THRESHOLD

24.22 BLM Raw Charge Thresholds: XLEAP LTU1 BLF859

Name	B	A	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = BLM_LTU1_BLF859_LOSS_L_THRESHOLD,
B = BLM_LTU1_BLF859_LOSS_H_THRESHOLD

24.23 BLM Timing Check (LN30)

Name	B	A	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Bad Timing	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Bad Timing High	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Bad Timing Low	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
All OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = BLM_LTU1_BLF859_TEST_L_THRESHOLD,
B = BLM_LTU1_BLF859_TEST_H_THRESHOLD

24.24 BLM Trigger Missed (LN30)

Name	A	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Missed	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = BLM_LTU1_722_NO_TRIG_MISSED

24.25 BYD Watchdog

Name	A	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
NOT_OK	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = BEND_DMP1_400_BACT_WDOG_STATE

24.26 BYKIK 120 Hz Abort Trigger

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Missed Trigger	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Stable	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = BYKIK_120HZ_ABRT_TRIG_MISSED

24.27 BYKIK 120 Hz Standby Trigger

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Missed Trigger	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Stable	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = BYKIK_120HZ_STBY_TRIG_MISSED

24.28 BYKIK 30 Hz Abort Trigger

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Missed Trigger	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Stable	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = BYKIK_30HZ_ABRT_TRIG_MISSED

24.29 BYKIK 30 Hz Standby Trigger

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Missed Trigger	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Stable	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = BYKIK_30HZ_STBY_TRIG_MISSED

24.30 BYKIK Readback Signal

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `BYKIK_THRESHOLD_UNDER_FAULT`,
B = `BYKIK_THRESHOLD_OVER_FAULT`

24.31 LTU Dechirper - Horizontal Gap Too Small

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Both ends gap too small	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Downstream end gap too small	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Upstream end gap too small	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Gap ok	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `DCHP_LTU1_555_GAP_LIMSW_NEGZ_POSITION`,
B = `DCHP_LTU1_555_GAP_LIMSW_POSZ_POSITION`

24.32 LTU Dechirper - MIRR LTU1 548 Position (MIRDVDHCP)

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Moving	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Out	F	T	120 Hz	120 Hz	120 Hz	–	–	–	–
In	T	F	120 Hz	120 Hz	120 Hz	–	–	–	–
Broken	T	T	0 Hz	0 Hz	0 Hz	–	–	–	–

Where
A = `MIRR_LTU1_548_OUT_LIMSW_POSITION`,
B = `MIRR_LTU1_548_IN_LIMSW_POSITION`

24.33 LTU Dechirper - Vertical Gap Too Small

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Both ends gap too small	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Downstream end gap too small	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Upstream end gap too small	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Gap ok	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `DCHP_LTU1_545_GAP_LIMSW_NEGZ_POSITION`,
B = `DCHP_LTU1_545_GAP_LIMSW_POSZ_POSITION`

24.34 Magnet In Tolerance: BYD1

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
No	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Yes	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `BEND_DMP1_400_INTOL_STATUS`

24.35 Magnet Power: BYD1

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Off	F	0 Hz	0 Hz	0 Hz	–	–	–	–
On	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `BEND_DMP1_400_STATE_STATUS`

24.36 OTR33 Position

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Moving	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Out	F	T	120 Hz	120 Hz	120 Hz	–	–	–	–
In	T	F	10 Hz	10 Hz	10 Hz	–	–	–	–
Broken	T	T	0 Hz	0 Hz	0 Hz	–	–	–	–

Where
A = OTR33_0745_OUT_STATE,
B = OTR33_0745_IN_STATE

24.37 PIC HVPS B911 - Location B911-2135

Name	A	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not On	F	0 Hz	0 Hz	0 Hz	–	–	–	–
On	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = PICM_LTU1_B911_HV_PWR_STATE

24.38 PIC HVPS B912 - Location B912-2135

Name	A	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not On	F	0 Hz	0 Hz	0 Hz	–	–	–	–
On	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = PICM_LTU1_B912_HV_PWR_STATE

24.39 PIC HVPS B913 - Location B913-2135

Name	A	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not On	F	0 Hz	0 Hz	0 Hz	–	–	–	–
On	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = PICM_LTU1_B913_HV_PWR_STATE

24.40 PIC Raw Charge Thresholds: LTU1 220

Name	B	A	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = PICS_LTU1_220_LOSSL_THRESHOLD,
B = PICS_LTU1_220_LOSSH_THRESHOLD

24.41 PIC Raw Charge Thresholds: LTU1 252

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = PICS_LTU1_252_LOSSL_THRESHOLD,
B = PICS_LTU1_252_LOSSH_THRESHOLD

24.42 PIC Raw Charge Thresholds: LTU1 280

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = PICS_LTU1_280_LOSSL_THRESHOLD,
B = PICS_LTU1_280_LOSSH_THRESHOLD

24.43 PIC Raw Charge Thresholds: LTU1 420

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = PICS_LTU1_420_LOSSL_THRESHOLD,
B = PICS_LTU1_420_LOSSH_THRESHOLD

24.44 PIC Raw Charge Thresholds: LTU1 450

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = PICS_LTU1_450_LOSSL_THRESHOLD,
B = PICS_LTU1_450_LOSSH_THRESHOLD

24.45 PIC Raw Charge Thresholds: LTU1 480

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = PICS_LTU1_480_LOSSL_THRESHOLD,
B = PICS_LTU1_480_LOSSH_THRESHOLD

24.46 PIC Raw Charge Thresholds: LTU1 722

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = PICS_LTU1_722_LOSSL_THRESHOLD,
B = PICS_LTU1_722_LOSSH_THRESHOLD

24.47 PIC Raw Charge Thresholds: LTU1 732

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = PICM_LTU1_732_LOSSL_THRESHOLD,
B = PICM_LTU1_732_LOSSH_THRESHOLD

24.48 PIC Raw Charge Thresholds: LTU1 762

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = PICS_LTU1_762_LOSSL_THRESHOLD,
B = PICS_LTU1_762_LOSSH_THRESHOLD

24.49 PIC Raw Charge Thresholds: LTU1 772

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = PICS_LTU1_772_LOSSL_THRESHOLD,
B = PICS_LTU1_772_LOSSH_THRESHOLD

24.50 PIC Trigger Missed (LN28)

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Missed	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = PICS_LTU1_220_NO_TRIG_MISSED

24.51 PIC Trigger Missed (LN29)

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Missed	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = PICS_LTU1_480_NO_TRIG_MISSED

24.52 PIC Trigger Missed (LN31)

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Missed	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = PICS_LTU1_762_NO_TRIG_MISSED

24.53 TDUND Flow Switch Fault With TDUND Not Out

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Fault	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Ok	F	T	120 Hz	120 Hz	120 Hz	–	–	–	–
Ok, TDUND Out	T	F	120 Hz	120 Hz	120 Hz	–	–	–	–
Ok	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = TDUND_FS_STATE,
B = DUMP_LTU1_970_TDUND_OUT_POSITION

24.54 TDUND Position

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Moving	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Out	F	T	–	–	–	–	–	–	–
In	T	F	–	–	10 Hz	–	–	–	–
Broken	T	T	0 Hz	0 Hz	0 Hz	–	–	–	–

Where
A = DUMP_LTU1_970_TDUND_OUT_POSITION,
B = DUMP_LTU1_970_TDUND_IN_POSITION

24.55 THZ-2 Position

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Moving	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Out	F	T	120 Hz	120 Hz	120 Hz	–	–	–	–
In	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Broken	T	T	0 Hz	0 Hz	0 Hz	–	–	–	–

Where
A = THZR_LTU1_741_OUT_LIMSW_POSITION,
B = THZR_LTU1_741_IN_LIMSW_POSITION

24.56 Undulator Beam Energy Lower Limit

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
FAULT	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = BEND_DMP1_400_INTOL_BMIN_STATE

24.57 VVFS LTU1 102 Position

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not Out	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Out	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = VACFS_LTU1_102_STATE

24.58 VVMG LTU1 174 Position

Name	A	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not Out	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Out	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = VACV_LTU1_174_STATE

24.59 VVMG LTU1 355 Position

Name	A	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not Out	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Out	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = VACV_LTU1_355_STATE

24.60 VVMG LTU1 505 Position

Name	A	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not Out	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Out	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = VVPG_0505_STATE

24.61 VVMG LTU1 670 Position

Name	A	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not Out	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Out	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = VVPG_0670_STATE

24.62 VVMG LTU1 742 Position

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not Out	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Out	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `VVPG_0742_STATE`

24.63 VVMG LTU1 774 Position

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not Out	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Out	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `VVPG_0774_STATE`

24.64 VVMG UND1 932 Position

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
NOT_OUT	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OUT	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `VVMG_UND1_932_OUT_LIMIT_POSITION`

24.65 VVMG UND1 968 Position

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
NOT_OUT	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OUT	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `VVMG_UND1_968_OUT_LIMIT_POSITION`

24.66 VVPG DMP1 103 Position

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not Out	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Out	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = VACV_DMP_100_STATE

24.67 VVPG DMP1 395 Position

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not Out	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Out	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = VACV_DMP_395_STATE

24.68 VVPG DMP1 700 Position

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not Out	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Out	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = VACV_DMP_700_STATE

24.69 VVPG LTU1 100 Position

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not Out	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Out	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = VACV_LTU1_100_STATE

24.70 VVPG LTU1 265 Position

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not Out	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Out	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `VACV_LTU1_265_STATE`

24.71 VVPG LTU1 435 Position

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not Out	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Out	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `VVPG_0435_STATE`

24.72 VVPG LTU1 580 Position

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not Out	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Out	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `VVPG_0580_STATE`

24.73 VVPG LTU1 725 Position

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not Out	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Out	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `VVPG_0725_STATE`

24.74 VVPG LTU1 757 Position

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not Out	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Out	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `VVPG_0757_STATE`

24.75 VVPG LTU1 999 Position

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not Out	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Out	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `VVPG_0999_STATE`

24.76 VVPG UND1 1000 Position

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not Out	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Out	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `VACV_LTU0_1000_OPEN_STATE`

24.77 VVPG UND1 2500 Position

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not Out	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Out	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `VACV_UND_2500_STATE`

24.78 XLEAP MIRXL - MIRR LTU1 829 Position

Name	*C*	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Moving	F	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Out	F	F	T	120 Hz	120 Hz	120 Hz	–	–	–	–
3 mm Aperture	F	T	F	120 Hz	120 Hz	120 Hz	–	–	–	–
Broken	F	T	T	0 Hz	0 Hz	0 Hz	–	–	–	–
5 mm Aperture	T	F	F	120 Hz	120 Hz	120 Hz	–	–	–	–
Broken	T	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Broken	T	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Broken	T	T	T	0 Hz	0 Hz	0 Hz	–	–	–	–

Where
A = `MIRR_LTU1_829_OUT_LIMSW_POSITION`,
B = `MIRR_LTU1_829_APERTURE_3MM_POSITION`,
C = `MIRR_LTU1_829_APERTURE_5MM_POSITION`

24.79 XLEAP PRXL1 - YAGS LTU1 844 Position

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Moving	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Out	F	T	120 Hz	120 Hz	120 Hz	–	–	–	–
In	T	F	10 Hz	10 Hz	10 Hz	–	–	–	–
Broken	T	T	0 Hz	0 Hz	0 Hz	–	–	–	–

Where
A = `YAGS_LTU1_844_OUT_LIMSW_POSITION`,
B = `YAGS_LTU1_844_IN_LIMSW_POSITION`

24.80 XLEAP PRXL2 - YAGS LTU1 853 Position

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Moving	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Out	F	T	120 Hz	120 Hz	120 Hz	–	–	–	–
In	T	F	10 Hz	10 Hz	10 Hz	–	–	–	–
Broken	T	T	0 Hz	0 Hz	0 Hz	–	–	–	–

Where
A = `YAGS_LTU1_853_OUT_LIMSW_POSITION`,
B = `YAGS_LTU1_853_IN_LIMSW_POSITION`

24.81 XLEAP PRXL3 - OTRS LTU1 858 Position

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Moving	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Out	F	T	120 Hz	120 Hz	120 Hz	–	–	–	–
In	T	F	10 Hz	10 Hz	10 Hz	–	–	–	–
Broken	T	T	0 Hz	0 Hz	0 Hz	–	–	–	–

Where
A = `OTRS_LTU1_858_OUT_LIMSW_POSITION`,
B = `OTRS_LTU1_858_IN_LIMSW_POSITION`

24.82 YAG LTU1 743 Position (PSI Prof Mon)

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Moving	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Out	F	T	120 Hz	120 Hz	120 Hz	–	–	–	–
In	T	F	10 Hz	10 Hz	10 Hz	–	–	–	–
Broken	T	T	0 Hz	0 Hz	0 Hz	–	–	–	–

Where
A = `YAGS_LTU1_743_OUT_LIMIT_POSITION`,
B = `YAGS_LTU1_743_IN_LIMIT_POSITION`

25 Ignored when TD11 Is In, YAG01 Is In, or YAG02 Is In

25.1 BLM/PIC Watchdog BSY0/BSYA

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Faulted	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Ok	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `MPS_BSY0_1_PICBLM_WD_STATUS`

25.2 BLM/PIC Watchdog LI24

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Faulted	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Ok	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `MPS_LI24_1_PICBLM_WD_STATUS`

25.3 BLM/PIC Watchdog LI30

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Faulted	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Ok	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `MPS_LI30_1_PICBLM_WD_STATUS`

25.4 Bunch Length Monitor BL21 Position

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Moving	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Out	F	T	120 Hz	120 Hz	120 Hz	–	–	–	–
In	T	F	120 Hz	120 Hz	120 Hz	–	–	–	–
Broken	T	T	0 Hz	0 Hz	0 Hz	–	–	–	–

Where
A = BL22_OUT_STATE,
B = BL22_IN_STATE

25.5 Dump LI28 5879 Flowswitch

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
No Flow	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Flow OK	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = DUMP_5879_FLOW_SW_STATE

25.6 Dump LI28 5879 Klixon

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not OK	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = DUMP_5879_KLIXON_OK_STATE

25.7 Flowswitch: BSY RAD LCW Slit 10/30

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Fault	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Ok	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = HTEXCH2_STATE

25.8 Flowswitch: CE21

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Fault	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `COL_805_FLOSW_STATE`

25.9 Flowswitch: COLL BSYH 479, 487, 495, 503 (PCAPM1-4)

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
FAULT	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `COLL_BSYH_479_PCAPM_FLOW_SW_STATE`

25.10 Flowswitch: COLL LI28-9

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
No Flow	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Flow OK	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `FLOW_SW_28_9_STATE`

25.11 Flowswitch: COLL LI29-1

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
No Flow	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Flow OK	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `FLOW_SW_29_1_STATE`

25.12 Flowswitch: COLL LI29-4

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
No Flow	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Flow OK	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = FLOW_SW_29_4_STATE

25.13 Flowswitch: COLL LI29-5

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
No Flow	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Flow OK	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = FLOW_SW_29_5_STATE

25.14 Flowswitch: COLL LI29-9

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
No Flow	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Flow OK	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = FLOW_SW_29_9_STATE

25.15 Flowswitch: COLL LI30-1

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
No Flow	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Flow OK	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = FLOW_SW_30_1_STATE

25.16 Flowswitch: COLL LI30-4

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
No Flow	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Flow OK	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `FLOW_SW_30_4_STATE`

25.17 Flowswitch: COLL LI30-5

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
No Flow	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Flow OK	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `FLOW_SW_30_5_STATE`

25.18 Hydrogen Recombiner For BSY 1 Collimator

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Fault	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Ok	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `HYDRECM1_STATE`

25.19 Hydrogen Recombiner For BSY 2 Slit 10/30

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Fault	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Ok	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `HYDRECM2_STATE`

25.20 KICK BSYH 475 PM1 State (A-Line Kicker)

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Inconsistent	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Is_OFF	F	T	120 Hz	120 Hz	120 Hz	–	–	–	–
Is_ON	T	F	120 Hz	120 Hz	120 Hz	–	–	–	–
Inconsistent	T	T	0 Hz	0 Hz	0 Hz	–	–	–	–

Where
A = KICK_BSY0_66_PM1_OFF_STATUS,
B = KICK_BSY0_66_PM1_ON_STATUS

25.21 KICK BSYH 475 PM1 Trigger State (A-Line Kicker)

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Inconsistent	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Is_Triggered	F	T	120 Hz	120 Hz	120 Hz	–	–	–	–
Is_Trig_Disabled	T	F	120 Hz	120 Hz	120 Hz	–	–	–	–
Inconsistent	T	T	0 Hz	0 Hz	0 Hz	–	–	–	–

Where
A = KICK_BSY0_66_PM1_TRIG_ENB_STATUS,
B = KICK_BSY0_66_PM1_TRIG_LOCK_STATUS

25.22 KICK BSYH 491 PM3 State (A-Line Kicker)

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Inconsistent	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Is_OFF	F	T	120 Hz	120 Hz	120 Hz	–	–	–	–
Is_ON	T	F	120 Hz	120 Hz	120 Hz	–	–	–	–
Inconsistent	T	T	0 Hz	0 Hz	0 Hz	–	–	–	–

Where
A = KICK_BSY0_66_PM2_OFF_STATUS,
B = KICK_BSY0_66_PM2_ON_STATUS

25.23 KICK BSYH 491 PM3 Trigger State (A-Line Kicker)

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Inconsistent	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Is_Triggered	F	T	120 Hz	120 Hz	120 Hz	–	–	–	–
Is_Trig_Disabled	T	F	120 Hz	120 Hz	120 Hz	–	–	–	–
Inconsistent	T	T	0 Hz	0 Hz	0 Hz	–	–	–	–

Where
A = KICK_BSY0_66_PM2_TRIG_ENB_STATUS,
B = KICK_BSY0_66_PM2_TRIG_LOCK_STATUS

25.24 Main Manifold Gauge: LI22 Station 5

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not OK	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = MPS_MM_GAUGE_OK_LI22_STATE

25.25 Main Manifold Gauge: LI23 Station 5

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not OK	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = MPS_MM_GAUGE_OK_LI23_STATE

25.26 Main Manifold Gauge: LI24 Station 5

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not OK	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = MPS_MM_GAUGE_OK_LI24_STATE

25.27 Main Manifold Gauge: LI25 Station 5

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not OK	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `MPS_MM_GAUGE_OK_LI25_STATE`

25.28 Main Manifold Gauge: LI26 Station 5

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not OK	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `MPS_MM_GAUGE_OK_LI26_STATE`

25.29 Main Manifold Gauge: LI27 Station 5

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not OK	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `MPS_MM_GAUGE_OK_LI27_STATE`

25.30 Main Manifold Gauge: LI28 Station 5

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not OK	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `MPS_MM_GAUGE_OK_LI28_STATE`

25.31 Main Manifold Gauge: LI29 Station 5

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not OK	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `MPS_MM_GAUGE_OK_STATE`

25.32 Main Manifold Gauge: LI30 Station 5

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not OK	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `MPS_MM_GAUGE_30_5_OK_STATE`

25.33 OTR LI25 920 Position

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Moving	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Out	F	T	120 Hz	120 Hz	120 Hz	–	–	–	–
In	T	F	10 Hz	10 Hz	10 Hz	–	–	–	–
Broken	T	T	0 Hz	0 Hz	0 Hz	–	–	–	–

Where
A = `OTR_TCAV_OUT_STATE`,
B = `OTR_TCAV_IN_STATE`

25.34 OTR21 Position

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Moving	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Out	F	T	120 Hz	120 Hz	120 Hz	–	–	–	–
In	T	F	10 Hz	10 Hz	10 Hz	–	–	–	–
Broken	T	T	0 Hz	0 Hz	0 Hz	–	–	–	–

Where
A = OTRS_LI24_807_OUT_LMTSW_STATE,
B = OTRS_LI24_807_IN_LMTSW_STATE

25.35 PIC Gas Pressure LI24

Name	A	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Fault	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = PIC_GAS_PRESS_STATE

25.36 PIC HVPS BSY 1 - Location B005-3921

Name	A	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not On	F	0 Hz	0 Hz	0 Hz	–	–	–	–
On	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = PICM_BSY0_1_HV_PWR_STATE

25.37 PIC HVPS BSY 2 - Location B005-3921

Name	A	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not On	F	0 Hz	0 Hz	0 Hz	–	–	–	–
On	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = PICM_BSY0_2_HV_PWR_STATE

25.38 PIC HVPS BSY 3 - Location B005-3921

Name	A	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not On	F	0 Hz	0 Hz	0 Hz	–	–	–	–
On	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = PICM_BSY0_3_HV_PWR_STATE

25.39 PIC HVPS BSY 4 - Location B005-3918

Name	A	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not On	F	0 Hz	0 Hz	0 Hz	–	–	–	–
On	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = PICM_BSY0_4_HV_PWR_STATE

25.40 PIC HVPS BSY 5 - Location B005-3918

Name	A	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not On	F	0 Hz	0 Hz	0 Hz	–	–	–	–
On	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = PICM_BSY0_5_HV_PWR_STATE

25.41 PIC HVPS BSY 6 - Location B005-3918

Name	A	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not On	F	0 Hz	0 Hz	0 Hz	–	–	–	–
On	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = PICM_BSY0_6_HV_PWR_STATE

25.42 PIC HVPS LI24 - Location LKF24-0235

Name	A	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not On	F	0 Hz	0 Hz	0 Hz	–	–	–	–
On	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = PICM_LI24_1_HV_PWR_STATE

25.43 PIC HVPS LI30 - KG30-C1322

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not On	F	0 Hz	0 Hz	0 Hz	–	–	–	–
On	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = PICM_LI30_1_HV_PWR_STATE

25.44 PIC Raw Charge Thresholds: BSYH 479 (PCAPM1)

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = PICM_BSYH_479_LOSSL_THRESHOLD,
B = PICM_BSYH_479_LOSSH_THRESHOLD

25.45 PIC Raw Charge Thresholds: BSYH 487 (PCAPM2)

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = PICM_BSYH_487_LOSSL_THRESHOLD,
B = PICM_BSYH_487_LOSSH_THRESHOLD

25.46 PIC Raw Charge Thresholds: BSYH 495 (PCAPM3)

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `PICM_BSYH_495_LOSSL_THRESHOLD`,
B = `PICM_BSYH_495_LOSSH_THRESHOLD`

25.47 PIC Raw Charge Thresholds: BSYH 503 (PCAPM4)

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `PICM_BSYH_503_LOSSL_THRESHOLD`,
B = `PICM_BSYH_503_LOSSH_THRESHOLD`

25.48 PIC Raw Charge Thresholds: BSYH 762 (PC90)

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `PICM_BSYH_762_LOSSL_THRESHOLD`,
B = `PICM_BSYH_762_LOSSH_THRESHOLD`

25.49 PIC Raw Charge Thresholds: BSYH 836 (PC119)

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `PICM_BSYH_836_LOSSL_THRESHOLD`,
B = `PICM_BSYH_836_LOSSH_THRESHOLD`

25.50 PIC Raw Charge Thresholds: LI24 791

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `PICM_LI24_791_LOSSL_THRESHOLD`,
B = `PICM_LI24_791_LOSSH_THRESHOLD`

25.51 PIC Raw Charge Thresholds: LI24 811

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `PICM_LI24_811_LOSSL_THRESHOLD`,
B = `PICM_LI24_811_LOSSH_THRESHOLD`

25.52 PIC Raw Charge Thresholds: LI28 916

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `PICM_LI28_916_LOSSL_THRESHOLD`,
B = `PICM_LI28_916_LOSSH_THRESHOLD`

25.53 PIC Raw Charge Thresholds: LI29 146

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `PICM_LI29_146_LOSSL_THRESHOLD`,
B = `PICM_LI29_146_LOSSH_THRESHOLD`

25.54 PIC Raw Charge Thresholds: LI29 446

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `PICM_LI29_446_LOSSL_THRESHOLD`,
B = `PICM_LI29_446_LOSSH_THRESHOLD`

25.55 PIC Raw Charge Thresholds: LI29 546

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = PICM_LI29_546_LOSSL_THRESHOLD,
B = PICM_LI29_546_LOSSH_THRESHOLD

25.56 PIC Raw Charge Thresholds: LI29 801

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = PICM_LI29_801_LOSSL_THRESHOLD,
B = PICM_LI29_801_LOSSH_THRESHOLD

25.57 PIC Raw Charge Thresholds: LI29 956

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = PICM_LI29_956_LOSSL_THRESHOLD,
B = PICM_LI29_956_LOSSH_THRESHOLD

25.58 PIC Raw Charge Thresholds: LI30 146

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = PICM_LI30_146_LOSSL_THRESHOLD,
B = PICM_LI30_146_LOSSH_THRESHOLD

25.59 PIC Raw Charge Thresholds: LI30 446

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = PICM_LI30_446_LOSSL_THRESHOLD,
B = PICM_LI30_446_LOSSH_THRESHOLD

25.60 PIC Raw Charge Thresholds: LI30 546

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = PICM_LI30_546_LOSSL_THRESHOLD,
B = PICM_LI30_546_LOSSH_THRESHOLD

25.61 PIC Raw Charge Thresholds: LI30 801

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = PICM_LI30_801_LOSSL_THRESHOLD,
B = PICM_LI30_801_LOSSH_THRESHOLD

25.62 PIC Trigger Missed (LN16)

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Missed	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = PICM_LI24_791_NO_TRIG_MISSED

25.63 PIC Trigger Missed (LN22)

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Missed	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = PICM_LI28_916_NO_TRIG_MISSED

25.64 PIC Trigger Missed (LN25)

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Missed	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = PICM_BSY0_16_NO_TRIG_MISSED

25.65 Scraper Water LI21-9 (Station 22-1)

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not OK	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `MPS_SCRAPPER_FLOW_OK_LI22_STATE`

25.66 Scraper Water LI22-9 (Station 23-1)

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not OK	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `MPS_SCRAPPER_FLOW_OK_LI23_STATE`

25.67 Scraper Water LI23-9 (Station 24-1)

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not OK	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `MPS_SCRAPPER_FLOW_OK_LI24_STATE`

25.68 Scraper Water LI24-9 (Station 25-1)

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not OK	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `MPS_SCRAPPER_FLOW_OK_LI25_STATE`

25.69 Scraper Water LI25-9 (Station 26-1)

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not OK	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `MPS_SCRAPPER_FLOW_OK_LI26_STATE`

25.70 Scraper Water LI26-9 (Station 27-1)

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not OK	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `MPS_SCRAPPER_FLOW_OK_LI27_STATE`

25.71 Scraper Water LI27-9 (Station 28-1)

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not OK	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `MPS_SCRAPPER_FLOW_OK_LI28_STATE`

25.72 Scraper Water LI28-9 (Station 29-1)

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not OK	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `MPS_SCRAPPER_FLOW_OK_LI29_STATE`

25.73 Scraper Water LI29-9 (Station 30-1)

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not OK	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `MPS_SCRAPPER_FLOW_OK_LI30_STATE`

25.74 Stopper LI28 950 and 960 Position

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not Out	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Out	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `BASII_STOPPER_OUT_STATE`

25.75 Stopper: BSY D2, 60, 61 DM60 Summary

The following code assigns the truth table's state number to the `unsigned int` variable `state`.

```
/*
 * state = 0 : full rate (120 Hz) beam allowed, ALL OUT
 * state = 1 : full rate (120 Hz) beam allowed, ALL IN
 * state = 2 : do not allow beam, Moving or Inconsistant
*/

/* Initialize to a guard value */
state = (unsigned int) -1;

/*
 * Stopper: BSY D2, 60, 61 DM60 Summary
 * Status given from PPS Stopper chassis very close to limit switches
    and CNTRL and passed to MPS via
 * opto's to insure fasts possible response. BTM60 has been documented
    to move at 200 msec from OUT to IN
 * Allow beam if ALL OUT
 * Allow beam if ALL IN
 * Otherwise, do not allow beam, Moving or Inconsistant
 */
```

```
/* Input Descriptions
*    INPUT_NAME                                                    ,
   FAULT_NAME (low)       , OK_NAME            , DESC
*       STPR_BSY0_89_IN_LIMSW_A_POSITION          , "IS_NOT_IN"
              , "IS_IN"       , "ST60 IN LIMSW CHAN A"
*       STPR_BSY0_89_IN_LIMSW_B_POSITION          , "IS_NOT_IN"
              , "IS_IN"       , "ST60 IN LIMSW CHAN B"
*       STPR_BSY0_89_OUT_LIMSW_A_POSITION         , "IS_NOT_OUT"
             , "IS_OUT"      , "ST60 OUT LIMSW CHAN A"
*       STPR_BSY0_89_OUT_LIMSW_B_POSITION         , "IS_NOT_OUT"
             , "IS_OUT"      , "ST60 OUT LIMSW CHAN B"
*       STPR_BSY0_90_IN_LIMSW_A_POSITION          , "IS_NOT_IN"
              , "IS_IN"       , "ST61 IN LIMSW CHAN A"
*       STPR_BSY0_90_IN_LIMSW_B_POSITION          , "IS_NOT_IN"
              , "IS_IN"       , "ST61 IN LIMSW CHAN B"
*       STPR_BSY0_90_OUT_LIMSW_A_POSITION         , "IS_NOT_OUT"
             , "IS_OUT"      , "ST61 OUT LIMSW CHAN A"
*       STPR_BSY0_90_OUT_LIMSW_B_POSITION         , "IS_NOT_OUT"
             , "IS_OUT"      , "ST61 OUT LIMSW CHAN B"
*       STPR_BSY0_88_IN_LIMSW_A_POSITION          , "IS_NOT_IN"
              , "IS_IN"       , "D2 IN LIMSW CHAN A"
*       STPR_BSY0_88_IN_LIMSW_B_POSITION          , "IS_NOT_IN"
              , "IS_IN"       , "D2 IN LIMSW CHAN B"
*       STPR_BSY0_88_OUT_LIMSW_A_POSITION         , "IS_NOT_OUT"
             , "IS_OUT"      , "D2 OUT LIMSW CHAN A"
*       BTM_BSY0_89_IN_LIMSW_A_POSITION           , "IS_NOT_IN"
              , "IS_IN"       , "BTM60 IN LIMSW CHAN A"
*       BTM_BSY0_89_IN_LIMSW_B_POSITION       , "IS_NOT_IN"          , "
   IS_IN"       , "BTM60 IN LIMSW CHAN B"
*       BTM_BSY0_89_OUT_LIMSW_A_POSITION          , "IS_NOT_OUT"
             , "IS_OUT"      , "BTM60 OUT LIMSW CHAN A"
*       BTM_BSY0_89_OUT_CNTRL_A_PPS_CNTRL         , "IS_NOT_OUT_RQ"
          , "IS_OUT_RQ" , "BTM60 OUT SOLN CNTRL CHAN A"
*       BTM_BSY0_89_OUT_CNTRL_B_PPS_CNTRL         , "IS_NOT_OUT_RQ"
          , "IS_OUT_RQ" , "BTM60 OUT SOLN CNTRL CHAN B2"
*
*/

if ( STPR_BSY0_89_OUT_LIMSW_A_POSITION &&
   STPR_BSY0_89_OUT_LIMSW_B_POSITION &&
            STPR_BSY0_90_OUT_LIMSW_A_POSITION &&
                STPR_BSY0_90_OUT_LIMSW_B_POSITION &&
            STPR_BSY0_88_OUT_LIMSW_A_POSITION &&
```

```
                BTM_BSY0_89_OUT_LIMSW_A_POSITION &&
            BTM_BSY0_89_OUT_CNTRL_A_PPS_CNTRL &&
                BTM_BSY0_89_OUT_CNTRL_B_PPS_CNTRL &&
            !( STPR_BSY0_89_IN_LIMSW_A_POSITION ||
                STPR_BSY0_89_IN_LIMSW_B_POSITION ||
                STPR_BSY0_90_IN_LIMSW_A_POSITION ||
                    STPR_BSY0_90_IN_LIMSW_B_POSITION ||
                STPR_BSY0_88_IN_LIMSW_A_POSITION ||
                    STPR_BSY0_88_IN_LIMSW_B_POSITION ||
                BTM_BSY0_89_IN_LIMSW_A_POSITION ||
                    BTM_BSY0_89_IN_LIMSW_B_POSITION ) )
{
    state = 0; /* ALL OUT, and NOT IN, okay to run beam */
}

else if ( STPR_BSY0_89_IN_LIMSW_A_POSITION &&
   STPR_BSY0_89_IN_LIMSW_B_POSITION &&
            STPR_BSY0_90_IN_LIMSW_A_POSITION &&
                STPR_BSY0_90_IN_LIMSW_B_POSITION &&
            STPR_BSY0_88_IN_LIMSW_A_POSITION &&
                STPR_BSY0_88_IN_LIMSW_B_POSITION &&
            BTM_BSY0_89_IN_LIMSW_A_POSITION &&
                BTM_BSY0_89_IN_LIMSW_B_POSITION &&
            !(STPR_BSY0_89_OUT_LIMSW_A_POSITION ||
                STPR_BSY0_89_OUT_LIMSW_B_POSITION ||
              STPR_BSY0_90_OUT_LIMSW_A_POSITION ||
                  STPR_BSY0_90_OUT_LIMSW_B_POSITION ||
              STPR_BSY0_88_OUT_LIMSW_A_POSITION ||
                  BTM_BSY0_89_OUT_LIMSW_A_POSITION ||
              BTM_BSY0_89_OUT_CNTRL_A_PPS_CNTRL ||
                  BTM_BSY0_89_OUT_CNTRL_B_PPS_CNTRL ) )
{
    state = 1; /* ALL IN and NOT OUT okay to run beam */
}

else
{
    state = 2; /* do not allow beam, Moving or Inconsistent */
}
```

Name	State	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
IS_OUT	0	120 Hz	120 Hz	120 Hz	–	–	–	–
IS_IN	1	120 Hz	120 Hz	120 Hz	–	–	–	–
Moving or Inconsistent	2	0 Hz	0 Hz	0 Hz	–	–	–	–

25.76 Sub-booster Ready: LI22

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not Ready	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Ready	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `MPS_SBST_OK_READY_LI22_STATE`

25.77 Sub-booster Ready: LI25

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not Ready	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Ready	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `MPS_SBST_OK_READY_LI25_STATE`

25.78 Sub-booster Ready: LI26

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not Ready	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Ready	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `MPS_SBST_OK_READY_LI26_STATE`

25.79 Sub-booster Ready: LI27

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not Ready	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Ready	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `MPS_SBST_OK_READY_LI27_STATE`

25.80 Sub-booster Ready: LI28

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not Ready	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Ready	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `MPS_SBST_OK_READY_LI28_STATE`

25.81 Sub-booster Ready: LI29

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not Ready	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Ready	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `MPS_SBST_OK_READY_LI29_STATE`

25.82 Sub-booster Ready: LI30

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not Ready	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Ready	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `MPS_SBST_OK_READY_LI30_STATE`

25.83 Temperature RTD Summary: BSY Common Line

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Faulted	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = RTD_BSY0_16_CLINESUM_STATUS

25.84 Toroid Chassis LI24 IMBC2

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Fault	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = CHASIMB2_STATE

25.85 Toroid Comparator BC2 (IMBC2IN vs IMBC2OUT)

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Downstream > Upstream	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Upstream > Downstream	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = TCBC2L1_STATE,
B = TCBC2L2_STATE

25.86 VVFS CLTH 101 Position

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not Open	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Open	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = VVFS_CLTH_101_OPEN_LIMSW_POSITION

25.87 VVFS LI21-9 Position (Station 22-1)

Name	A	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not Open	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Open	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = FAST_VLV_OPEN_LI22_STATE

25.88 VVFS LI22-9 Position (Station 23-1)

Name	A	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not Open	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Open	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = FAST_VLV_OPEN_LI23_STATE

25.89 VVFS LI23-9 Position (Station 24-1)

Name	A	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not Open	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Open	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = FAST_VLV_OPEN_LI24_STATE

25.90 VVFS LI24-9 Position (Station 25-1)

Name	A	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not Open	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Open	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = FAST_VLV_OPEN_LI25_STATE

25.91 VVFS LI25-9 Position (Station 26-1)

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not Open	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Open	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `FAST_VLV_OPEN_LI26_STATE`

25.92 VVFS LI26-9 Position (Station 27-1)

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not Open	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Open	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `FAST_VLV_OPEN_LI27_STATE`

25.93 VVFS LI27-9 Position (Station 28-1)

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not Open	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Open	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `FAST_VLV_OPEN_LI28_STATE`

25.94 VVFS LI28-9 Position (Station 29-1)

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not Open	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Open	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `FAST_VLV_OPEN_LI29_STATE`

25.95 VVFS LI29-9 Position (Station 30-1)

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not Open	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Open	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `FAST_VLV_OPEN_LI30_STATE`

25.96 VVPG BSYH 470 Position

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not Open	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Open	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `VVPG_BSYH_470_OPEN_LIMSW_POSITION`

25.97 VVPG BSYH 541 Position

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not Open	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Open	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `VVPG_BSYH_541_OPEN_LIMSW_POSITION`

25.98 VVPG BSYH 837 Position

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not Open	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Open	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `VVPG_BSYH_837_OPEN_LIMSW_POSITION`

25.99 VVPG CLTH 178 Position

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not Open	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Open	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `VVPG_CLTH_178_OPEN_LIMSW_POSITION`

25.100 VVPG CLTH 375 Position

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not Open	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Open	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `VVPG_CLTH_375_OPEN_LIMSW_POSITION`

25.101 VVPG LI21-9 Position (Station 22-1)

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not Open	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Open	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `SLOW_VLV_OPEN_LI22_STATE`

25.102 VVPG LI22-9 Position (Station 23-1)

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not Open	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Open	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `SLOW_VLV_OPEN_LI23_STATE`

25.103 VVPG LI23-9 Position (Station 24-1)

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not Open	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Open	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `SLOW_VLV_OPEN_LI24_STATE`

25.104 VVPG LI24 710 Position

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not Out	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Out	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `VV21_STATE`

25.105 VVPG LI24 896 Position

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not Out	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Out	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `VV22_STATE`

25.106 VVPG LI25-9 Position (Station 26-1)

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not Open	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Open	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `SLOW_VLV_OPEN_LI26_STATE`

25.107 VVPG LI26-9 Position (Station 27-1)

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not Open	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Open	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = SLOW_VLV_OPEN_LI27_STATE

25.108 VVPG LI27-9 Position (Station 28-1)

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not Open	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Open	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = SLOW_VLV_OPEN_LI28_STATE

25.109 VVPG LI28-9 Position (Station 29-1)

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not Open	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Open	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = SLOW_VLV_OPEN_LI29_STATE

25.110 VVPG LI29-9 Position (Station 30-1)

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not Open	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Open	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = SLOW_VLV_OPEN_LI30_STATE

25.111 VVPG LI30-9 Position (Station 30-9)

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not Open	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Open	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = SLOW_VLV_30_9_OK_OPEN_STATE

26 Ignored when YAG01 Is In

26.1 BXG Status

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Off	F	T	120 Hz	120 Hz	120 Hz	–	–	–	–
On	T	F	10 Hz	10 Hz	10 Hz	–	–	–	–
Broken	T	T	0 Hz	0 Hz	0 Hz	–	–	–	–

Where
A = `BEND_IN20_231_OFF_STATE`,
B = `BEND_IN20_231_OK_STATE`

26.2 Toroid Peak Current Monitor IM01

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Fault	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `TR_BL215_STATE`

26.3 YAG02 IN20 241 Position

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Moving	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Out	F	T	120 Hz	120 Hz	120 Hz	–	–	–	–
In	T	F	10 Hz	10 Hz	10 Hz	–	–	–	–
Broken	T	T	0 Hz	0 Hz	0 Hz	–	–	–	–

Where
A = `YAGS_IN20_241_OUT_LMTSW_STATE`,
B = `YAGS_IN20_241_IN_LMTSW_STATE`

27 Ignored when YAG01 Is In or YAG02 Is In

27.1 BLM/PIC Watchdog: Upstream of TDUND

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Faulted	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `MPS_MCC0_1_PICBLM_WD_STATUS`

27.2 BX01/BX02 Status

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Off	F	T	120 Hz	120 Hz	120 Hz	–	–	–	–
On	T	F	120 Hz	120 Hz	120 Hz	–	–	–	–
Broken	T	T	0 Hz	0 Hz	0 Hz	–	–	–	–

Where
A = `BEND_IN20_751_OFF_STATE`,
B = `BEND_IN20_751_OK_STATE`

27.3 Flowswitch: CE11

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Fault	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `COLL_LI21_235_OPEN_STATE`

27.4 Flowswitch: TD11

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Fault	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = FS_BL305_STATE

27.5 Main Manifold Gauge: LI21 Station 5

Name	A	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not OK	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = MPS_MM_GAUGE_OK_LI21_STATE

27.6 Mirror BL11 Position

Name	B	A	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Moving	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Out	F	T	120 Hz	120 Hz	120 Hz	–	–	–	–
In	T	F	120 Hz	120 Hz	120 Hz	–	–	–	–
Broken	T	T	0 Hz	0 Hz	0 Hz	–	–	–	–

Where
A = MIR_BL11_OUT_STATE,
B = MIR_BL11_IN_STATE

27.7 OTR01 IN20 541 Position

Name	B	A	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Moving	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Out	F	T	120 Hz	120 Hz	120 Hz	–	–	–	–
In	T	F	10 Hz	10 Hz	10 Hz	–	–	–	–
Broken	T	T	0 Hz	0 Hz	0 Hz	–	–	–	–

Where
A = OTRS_IN20_541_OUT_LMTSW_STATE,
B = OTRS_IN20_541_IN_LMTSW_STATE

27.8 OTR02 IN20 571 Position

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Moving	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Out	F	T	120 Hz	120 Hz	120 Hz	–	–	–	–
In	T	F	10 Hz	10 Hz	10 Hz	–	–	–	–
Broken	T	T	0 Hz	0 Hz	0 Hz	–	–	–	–

Where
A = `OTRS_IN20_571_OUT_LMTSW_STATE`,
B = `OTRS_IN20_571_IN_LMTSW_STATE`

27.9 OTR03 IN20 621 Position

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Moving	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Out	F	T	120 Hz	120 Hz	120 Hz	–	–	–	–
In	T	F	10 Hz	10 Hz	10 Hz	–	–	–	–
Broken	T	T	0 Hz	0 Hz	0 Hz	–	–	–	–

Where
A = `OTRS_IN20_621_OUT_LMTSW_STATE`,
B = `OTRS_IN20_621_IN_LMTSW_STATE`

27.10 OTR04 IN20 711 Position

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Moving	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Out	F	T	120 Hz	120 Hz	120 Hz	–	–	–	–
In	T	F	10 Hz	10 Hz	10 Hz	–	–	–	–
Broken	T	T	0 Hz	0 Hz	0 Hz	–	–	–	–

Where
A = `OTRS_IN20_711_OUT_LMTSW_STATE`,
B = `OTRS_IN20_711_IN_LMTSW_STATE`

27.11 OTR11 LI21 237 Position

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Moving	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Out	F	T	120 Hz	120 Hz	120 Hz	–	–	–	–
In	T	F	10 Hz	10 Hz	10 Hz	–	–	–	–
Broken	T	T	0 Hz	0 Hz	0 Hz	–	–	–	–

Where
A = `OTRS_LI21_237_OUT_LMTSW_STATE`,
B = `OTRS_LI21_237_IN_LMTSW_STATE`

27.12 OTR12 LI21 291 Position

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Moving	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Out	F	T	120 Hz	120 Hz	120 Hz	–	–	–	–
In	T	F	10 Hz	10 Hz	10 Hz	–	–	–	–
Broken	T	T	0 Hz	0 Hz	0 Hz	–	–	–	–

Where
A = `OTRS_LI21_291_OUT_LMTSW_STATE`,
B = `OTRS_LI21_291_IN_LMTSW_STATE`

27.13 OTRH1 Position

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Moving	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Out	F	T	120 Hz	120 Hz	120 Hz	–	–	–	–
In	T	F	10 Hz	10 Hz	10 Hz	–	–	–	–
Broken	T	T	0 Hz	0 Hz	0 Hz	–	–	–	–

Where
A = `OTRH1_OUT_LIMIT_STATE`,
B = `OTRH1_IN_LIMIT_STATE`

27.14 OTRH2 Position

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Moving	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Out	F	T	120 Hz	120 Hz	120 Hz	–	–	–	–
In	T	F	10 Hz	10 Hz	10 Hz	–	–	–	–
Broken	T	T	0 Hz	0 Hz	0 Hz	–	–	–	–

Where
A = `OTRH2_OUT_LIMIT_STATE`,
B = `OTRH2_IN_LIMIT_STATE`

27.15 Sub-booster Ready: LI21

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not Ready	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Ready	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `MPS_SBST_OK_READY_LI21_STATE`

27.16 TD11 Position

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Moving	F	F	0 Hz	0 Hz	–	–	–	–	–
Out	F	T	120 Hz	120 Hz	–	–	–	–	–
In	T	F	120 Hz	120 Hz	–	–	–	–	–
Broken	T	T	0 Hz	0 Hz	–	–	–	–	–

Where
A = `TD11_OUT_LIMIT_STATE`,
B = `TD11_IN_LIMIT_STATE`

27.17 Toroid Chassis IN20 IM11

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Fault	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = CHASIM11_STATE

27.18 Toroid Chassis IN20 IM12

Name	A	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Fault	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = CHASIM12_STATE

27.19 Toroid Comparator BC1 (IMBC1IN vs IMBC1OUT)

Name	B	A	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Downstream - Upstream > 50 pC	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Upstream - Downstream > 200 pC	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = TCBC1L1_STATE,
B = TCBC1L2_STATE

27.20 VVFV IN20 785 Position

Name	A	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not Out	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Out	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = VVFV_IN20_785_OPEN_LMTSW_POSITION

27.21 VVMG LI21 195 Position

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not Out	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Out	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `VV_BL195_STATE`

27.22 VVPG IN20 435 Position

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not Out	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Out	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `VV_BL435_STATE`

27.23 VVPG IN20 545 Position

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not Out	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Out	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `VV_BL545_STATE`

27.24 VVPG IN20 635 Position

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not Out	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Out	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `VV_BL635_STATE`

27.25 VVPG IN20 915 Position

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not Out	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Out	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = VV_IS915_STATE

27.26 VVS Circuit Breaker: LI22

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not On	F	0 Hz	0 Hz	0 Hz	–	–	–	–
On	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = VVS_BRKR_OK_READY_LI22_STATE

27.27 VVS Circuit Breaker: LI24

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not On	F	0 Hz	0 Hz	0 Hz	–	–	–	–
On	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = VVS_BRKR_OK_READY_LI24_STATE

27.28 VVS Circuit Breaker: LI26

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not On	F	0 Hz	0 Hz	0 Hz	–	–	–	–
On	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = VVS_BRKR_OK_READY_LI26_STATE

27.29 VVS Circuit Breaker: LI28

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not On	F	0 Hz	0 Hz	0 Hz	–	–	–	–
On	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `VVS_BRKR_OK_READY_LI28_STATE`

27.30 VVS Circuit Breaker: LI30

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not On	F	0 Hz	0 Hz	0 Hz	–	–	–	–
On	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `VVS_BRKR_OK_READY_LI30_STATE`

27.31 YAG03 IN20 351 Position

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Moving	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Out	F	T	120 Hz	120 Hz	120 Hz	–	–	–	–
In	T	F	10 Hz	10 Hz	10 Hz	–	–	–	–
Broken	T	T	0 Hz	0 Hz	0 Hz	–	–	–	–

Where
A = `YAGS_IN20_351_OUT_LMTSW_STATE`,
B = `YAGS_IN20_351_IN_LMTSW_STATE`

27.32 YAGS1 IN20 921 Position

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Moving	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Out	F	T	120 Hz	120 Hz	120 Hz	–	–	–	–
In	T	F	10 Hz	10 Hz	10 Hz	–	–	–	–
Broken	T	T	0 Hz	0 Hz	0 Hz	–	–	–	–

Where
A = YAGS_IN20_921_OUT_LMTSW_STATE,
B = YAGS_IN20_921_IN_LMTSW_STATE

27.33 YAGS2 LI21 995 Position

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Moving	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Out	F	T	120 Hz	120 Hz	120 Hz	–	–	–	–
In	T	F	10 Hz	10 Hz	10 Hz	–	–	–	–
Broken	T	T	0 Hz	0 Hz	0 Hz	–	–	–	–

Where
A = YAGS_LI21_995_OUT_LMTSW_STATE,
B = YAGS_LI21_995_IN_LMTSW_STATE

28 Always Evaluated

28.1 Backward Beam Stopper (RST1)

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not Out	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Out	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `ST_BL551_STATE`

28.2 Beam Destination: HXR

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not True	F	–	–	–	–	–	–	–
True	T	–	–	–	–	–	–	–

Where
A = `LP_DESTINATION_HXR`

28.3 Beam Destination: SXR

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not True	F	–	–	–	–	–	–	–
True	T	–	–	–	–	–	–	–

Where
A = `LP_DESTINATION_SXR`

28.4 BLM/PIC Watchdog: IN20

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Faulted	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `MPS_IN20_1_PICBLM_WD_STATUS`

28.5 Bypass Recover

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Recovering	F	0 Hz	0 Hz	0 Hz	0 Hz	–	–	–
OK	T	120 Hz	120 Hz	120 Hz	120 Hz	–	–	–

Where
A = LP_BYPASS_RECOVER

28.6 Gun RF Peak Power 20-6

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
OK	F	120 Hz	120 Hz	120 Hz	–	–	–	–
Fault	T	0 Hz	0 Hz	0 Hz	–	–	–	–

Where
A = FLT_20_6_TRP_STATE

28.7 Gun Waveguide Vacuum Summary

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not Out	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Out	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = WGVACGUN_STATE

28.8 IOC-IN20-MP01 MPS Support IOC Heartbeat

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Fault	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = MN_HEART_STATE

28.9 Laser Heater Attenuator Position

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Moving	F	F	–	–	–	0 Hz	–	–	–
Out	F	T	–	–	–	–	–	–	–
In	T	F	–	–	–	–	–	–	–
Broken	T	T	–	–	–	0 Hz	–	–	–

Where
A = LHATTEN_OUT_LIMIT_STATE,
B = LHATTEN_IN_LIMIT_STATE

28.10 MCC Emergency Radiation Stopper

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not OK	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = EMG_RAD_STOP_STATE

28.11 Mechanical Shutter Position

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Moving	F	F	0 Hz	–	0 Hz	–	–	–	–
Out	F	T	–	–	–	–	–	–	–
In	T	F	–	–	–	–	–	–	–
Broken	T	T	0 Hz	–	0 Hz	–	–	–	–

Where
A = MPS_IN20_200_MSHT1_OUT_FAULT,
B = MPS_IN20_200_MSHT1_IN_FAULT

28.12 Mirror AM01 Position

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not Out	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Out	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = MR_BL191_STATE

28.13 MPS Beam Permit: BYKIK

Name	A	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not Permitted	F	–	–	0 Hz	–	–	–	–
Permitted	T	–	–	120 Hz	–	–	–	–

Where
A = LP_ALLOWS_BEAM_BYKIK

28.14 MPS Beam Permit: BYKIKS

Name	A	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not Permitted	F	–	–	–	–	–	–	0 Hz
Permitted	T	–	–	–	–	–	–	120 Hz

Where
A = LP_ALLOWS_BEAM_BYKIKS

28.15 MPS Beam Permit: Gun RF

Name	A	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not Permitted	F	0 Hz	–	–	–	–	–	–
Permitted	T	120 Hz	–	–	–	–	–	–

Where
A = LP_ALLOWS_BEAM_POCKELS_CELL

28.16 MPS Beam Permit: Gun RF HXR

Name	A	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not Permitted	F	–	–	–	–	0 Hz	–	–
Permitted	T	–	–	–	–	120 Hz	–	–

Where
A = LP_ALLOWS_BEAM_GUN_HXR

28.17 MPS Beam Permit: Gun RF SXR

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not Permitted	F	–	–	–	–	–	0 Hz	–
Permitted	T	–	–	–	–	–	120 Hz	–

Where
A = LP_ALLOWS_BEAM_GUN_SXR

28.18 MPS Beam Permit: Heater Shutter

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not Permitted	F	–	–	–	0 Hz	–	–	–
Permitted	T	–	–	–	120 Hz	–	–	–

Where
A = LP_ALLOWS_BEAM_LH_SHUT

28.19 MPS Beam Permit: Mechanical Shutter

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not Permitted	F	–	0 Hz	–	–	–	–	–
Permitted	T	–	120 Hz	–	–	–	–	–

Where
A = LP_ALLOWS_BEAM_MECH_SHUT

28.20 MPS Mechanical Shutter Position

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
OK	F	120 Hz	120 Hz	120 Hz	–	–	–	–
Readback Does Not Match	T	0 Hz	0 Hz	0 Hz	–	–	–	–

Where
A = SHFLT_STATE

28.21 PIC HVPS LI20 - Location LKG-1535

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not On	F	0 Hz	0 Hz	0 Hz	–	–	–	–
On	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = PICM_LI20_1_HV_PWR_STATE

28.22 PIC Raw Charge Thresholds: IN20 185

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = PICM_IN20_185_LOSSL_THRESHOLD,
B = PICM_IN20_185_LOSSH_THRESHOLD

28.23 PIC Raw Charge Thresholds: IN20 232

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = PICM_IN20_232_LOSSL_THRESHOLD,
B = PICM_IN20_232_LOSSH_THRESHOLD

28.24 PIC Raw Charge Thresholds: IN20 245

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `PICM_IN20_245_LOSSL_THRESHOLD`,
B = `PICM_IN20_245_LOSSH_THRESHOLD`

28.25 PIC Raw Charge Thresholds: IN20 665

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `PICM_IN20_665_LOSSL_THRESHOLD`,
B = `PICM_IN20_665_LOSSH_THRESHOLD`

28.26 PIC Raw Charge Thresholds: IN20 775

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `PICM_IN20_775_LOSSL_THRESHOLD`,
B = `PICM_IN20_775_LOSSH_THRESHOLD`

28.27 PIC Raw Charge Thresholds: IN20 933

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Broken	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Over High Threshold	F	T	0 Hz	0 Hz	0 Hz	–	–	–	–
Under Low Threshold	T	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = PICM_IN20_933_LOSSL_THRESHOLD,
B = PICM_IN20_933_LOSSH_THRESHOLD

28.28 PIC Trigger Missed (LN11)

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Missed	F	0 Hz	0 Hz	0 Hz	–	–	–	–
OK	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = PICM_IN20_665_NO_TRIG_MISSED

28.29 Pockels Cell AND Gate 100

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Bypassed	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Active	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = MPS_IN20_100_ANDALLACTV_STATE

28.30 Pockels Cell AND Gate 200

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Bypassed	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Active	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = MPS_IN20_200_ANDALLACTV_STATE

28.31 Rate Request: BYKIK 1 Hz

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not Requested	F	–	–	120 Hz	–	–	–	–
Requested	T	–	–	1 Hz	–	–	–	–

Where
A = `LP_MAX_RATE_BYKIK_1_HZ`

28.32 Rate Request: BYKIK 10 Hz

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not Requested	F	–	–	120 Hz	–	–	–	–
Requested	T	–	–	10 Hz	–	–	–	–

Where
A = `LP_MAX_RATE_BYKIK_10_HZ`

28.33 Rate Request: BYKIK 30 Hz

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not Requested	F	–	–	120 Hz	–	–	–	–
Requested	T	–	–	30 Hz	–	–	–	–

Where
A = `LP_MAX_RATE_BYKIK_30_HZ`

28.34 Rate Request: BYKIK 60 Hz

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not Requested	F	–	–	120 Hz	–	–	–	–
Requested	T	–	–	60 Hz	–	–	–	–

Where
A = `LP_MAX_RATE_BYKIK_60_HZ`

28.35 Rate Request: BYKIK Burst

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not Requested	F	–	–	120 Hz	–	–	–	–
Requested	T	–	–	Burst Mode	–	–	–	–

Where
A = LP_MAX_RATE_BYKIK_BURST

28.36 Rate Request: BYKIK Single Shot

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not Requested	F	–	–	120 Hz	–	–	–	–
Requested	T	–	–	Single Shot	–	–	–	–

Where
A = LP_MAX_RATE_BYKIK_SINGLE_SHOT

28.37 Rate Request: BYKIKS 1 Hz

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not Requested	F	–	–	–	–	–	–	120 Hz
Requested	T	–	–	–	–	–	–	1 Hz

Where
A = LP_MAX_RATE_BYKIKS_1_HZ

28.38 Rate Request: BYKIKS 10 Hz

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not Requested	F	–	–	–	–	–	–	120 Hz
Requested	T	–	–	–	–	–	–	10 Hz

Where
A = LP_MAX_RATE_BYKIKS_10_HZ

28.39 Rate Request: BYKIKS 30 Hz

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not Requested	F	–	–	–	–	–	–	120 Hz
Requested	T	–	–	–	–	–	–	30 Hz

Where
A = `LP_MAX_RATE_BYKIKS_30_HZ`

28.40 Rate Request: BYKIKS 60 Hz

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not Requested	F	–	–	–	–	–	–	120 Hz
Requested	T	–	–	–	–	–	–	60 Hz

Where
A = `LP_MAX_RATE_BYKIKS_60_HZ`

28.41 Rate Request: BYKIKS Burst

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not Requested	F	–	–	–	–	–	–	120 Hz
Requested	T	–	–	–	–	–	–	Burst Mode

Where
A = `LP_MAX_RATE_BYKIKS_BURST`

28.42 Rate Request: BYKIKS Single Shot

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not Requested	F	–	–	–	–	–	–	120 Hz
Requested	T	–	–	–	–	–	–	Single Shot

Where
A = `LP_MAX_RATE_BYKIKS_SINGLE_SHOT`

28.43 Rate Request: Gun RF HXR 1 Hz

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not Requested	F	–	–	–	–	120 Hz	–	–
Requested	T	–	–	–	–	1 Hz	–	–

Where
A = LP_MAX_RATE_GUN_HXR_1_HZ

28.44 Rate Request: Gun RF HXR 10 Hz

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not Requested	F	–	–	–	–	120 Hz	–	–
Requested	T	–	–	–	–	10 Hz	–	–

Where
A = LP_MAX_RATE_GUN_HXR_10_HZ

28.45 Rate Request: Gun RF HXR 30 Hz

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not Requested	F	–	–	–	–	120 Hz	–	–
Requested	T	–	–	–	–	30 Hz	–	–

Where
A = LP_MAX_RATE_GUN_HXR_30_HZ

28.46 Rate Request: Gun RF HXR 60 Hz

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not Requested	F	–	–	–	–	120 Hz	–	–
Requested	T	–	–	–	–	60 Hz	–	–

Where
A = LP_MAX_RATE_GUN_HXR_60_HZ

28.47 Rate Request: Gun RF HXR Burst

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not Requested	F	–	–	–	–	120 Hz	–	–
Requested	T	–	–	–	–	Burst Mode	–	–

Where
A = LP_MAX_RATE_GUN_HXR_BURST

28.48 Rate Request: Gun RF HXR Single Shot

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not Requested	F	–	–	–	–	120 Hz	–	–
Requested	T	–	–	–	–	Single Shot	–	–

Where
A = LP_MAX_RATE_GUN_HXR_SINGLE_SHOT

28.49 Rate Request: Gun RF SXR 1 Hz

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not Requested	F	–	–	–	–	–	120 Hz	–
Requested	T	–	–	–	–	–	1 Hz	–

Where
A = LP_MAX_RATE_GUN_SXR_1_HZ

28.50 Rate Request: Gun RF SXR 10 Hz

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not Requested	F	–	–	–	–	–	120 Hz	–
Requested	T	–	–	–	–	–	10 Hz	–

Where
A = LP_MAX_RATE_GUN_SXR_10_HZ

28.51 Rate Request: Gun RF SXR 30 Hz

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not Requested	F	–	–	–	–	–	120 Hz	–
Requested	T	–	–	–	–	–	30 Hz	–

Where
A = LP_MAX_RATE_GUN_SXR_30_HZ

28.52 Rate Request: Gun RF SXR 60 Hz

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not Requested	F	–	–	–	–	–	120 Hz	–
Requested	T	–	–	–	–	–	60 Hz	–

Where
A = LP_MAX_RATE_GUN_SXR_60_HZ

28.53 Rate Request: Gun RF SXR Burst

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not Requested	F	–	–	–	–	–	120 Hz	–
Requested	T	–	–	–	–	–	Burst Mode	–

Where
A = LP_MAX_RATE_GUN_SXR_BURST

28.54 Rate Request: Gun RF SXR Single Shot

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not Requested	F	–	–	–	–	–	120 Hz	–
Requested	T	–	–	–	–	–	Single Shot	–

Where
A = LP_MAX_RATE_GUN_SXR_SINGLE_SHOT

28.55 Rate Request: Pockels Cell 1 Hz

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not Requested	F	120 Hz	–	–	–	–	–	–
Requested	T	1 Hz	–	–	–	–	–	–

Where
A = LP_MAX_RATE_PC_1_HZ

28.56 Rate Request: Pockels Cell 10 Hz

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not Requested	F	120 Hz	–	–	–	–	–	–
Requested	T	10 Hz	–	–	–	–	–	–

Where
A = LP_MAX_RATE_PC_10_HZ

28.57 Rate Request: Pockels Cell 30 Hz

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not Requested	F	120 Hz	–	–	–	–	–	–
Requested	T	30 Hz	–	–	–	–	–	–

Where
A = LP_MAX_RATE_PC_30_HZ

28.58 Rate Request: Pockels Cell 60 Hz

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not Requested	F	120 Hz	–	–	–	–	–	–
Requested	T	60 Hz	–	–	–	–	–	–

Where
A = LP_MAX_RATE_PC_60_HZ

28.59 Rate Request: Pockels Cell Burst

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not Requested	F	120 Hz	–	–	–	–	–	–
Requested	T	Burst Mode	–	–	–	–	–	–

Where
A = `LP_MAX_RATE_PC_BURST`

28.60 Rate Request: Pockels Cell Single Shot

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not Requested	F	120 Hz	–	–	–	–	–	–
Requested	T	Single Shot	–	–	–	–	–	–

Where
A = `LP_MAX_RATE_PC_SINGLE_SHOT`

28.61 VVMG IN20 175 Position

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not Out	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Out	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `VV_BL175_STATE`

28.62 VVPG IN20 155 Position

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not Out	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Out	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `VV_BL155_STATE`

28.63 VVS Circuit Breaker: LI20

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not On	F	0 Hz	0 Hz	0 Hz	–	–	–	–
On	T	120 Hz	120 Hz	120 Hz	–	–	–	–

Where
A = `VVS_BRKR_OK_READY_LI20_STATE`

28.64 YAG01 IN20 211 Position

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Moving	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Out	F	T	120 Hz	120 Hz	120 Hz	–	–	–	–
In	T	F	10 Hz	10 Hz	10 Hz	–	–	–	–
Broken	T	T	0 Hz	0 Hz	0 Hz	–	–	–	–

Where
A = `YAGS_IN20_211_OUT_LMTSW_STATE`,
B = `YAGS_IN20_211_IN_LMTSW_STATE`

28.65 YAGG1 IN20 841 Position

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Moving	F	F	0 Hz	0 Hz	0 Hz	–	–	–	–
Out	F	T	120 Hz	120 Hz	120 Hz	–	–	–	–
In	T	F	10 Hz	10 Hz	10 Hz	–	–	–	–
Broken	T	T	0 Hz	0 Hz	0 Hz	–	–	–	–

Where
A = `YAGS_IN20_841_OUT_LMTSW_STATE`,
B = `YAGS_IN20_841_IN_LMTSW_STATE`

29 Ignore Logic

29.1 A-Line Kicker Is Not Enabled

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Is Not Enabled	F	F	–	–	–	–	–	–	–

Where
A = KICK_BSY0_66_PM1_TRIG_ENB_STATUS,
B = KICK_BSY0_66_PM2_TRIG_ENB_STATUS

29.2 A-Line SL10 Is Closed

Name	*D*	*C*	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Closed	T	T	T	T	–	–	–	–	–	–	–

Where
A = SLIT_BSYA_2010_SL10_FB_IN_STATE,
B = SLIT_BSYA_2010_SL10_FT_IN_STATE,
C = SLIT_BSYA_2010_SL10_RB_IN_STATE,
D = SLIT_BSYA_2010_SL10_RT_IN_STATE

29.3 BX01/BX02 Is Off

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Off	F	T	–	–	–	–	–	–	–

Where
A = BEND_IN20_751_OFF_STATE,
B = BEND_IN20_751_OK_STATE

29.4 BX01/BX02 Is On

Name	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
On	T	F	–	–	–	–	–	–	–

Where
A = BEND_IN20_751_OFF_STATE,
B = BEND_IN20_751_OK_STATE

29.5 BXG Is Off

Name	B	A	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Off	F	T	–	–	–	–	–	–	–

Where
A = BEND_IN20_231_OFF_STATE,
B = BEND_IN20_231_OK_STATE

29.6 BXG Is On

Name	B	A	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
On	T	F	–	–	–	–	–	–	–

Where
A = BEND_IN20_231_OFF_STATE,
B = BEND_IN20_231_OK_STATE

29.7 Diag Stopper HFX DG2 Is In

Name	A	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
In	T	–	–	–	–	–	–	–

Where
A = HFX_DG2_STP_01_IN_DI_POSITION

29.8 Diag Stopper HFX UM6 Is In

Name	A	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
In	T	–	–	–	–	–	–	–

Where
A = HFX_UM6_STP_01_IN_DI_POSITION

29.9 Diag Stopper XCS SB1 Is In

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
In	T	–	–	–	–	–	–	–

Where
A = XCS_SB1_STP_01_CLS_DI_POSITION

29.10 Laser Heater Attenuator Is In

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
In	T	–	–	–	–	–	–	–

Where
A = LHATTEN_IN_LIMIT_STATE

29.11 LTU Dechirper Is Out

Name	*D*	*C*	*B*	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Out	T	T	T	T	–	–	–	–	–	–	–

Where
A = DCHP_LTU1_545_OUT_LIMSW_NEGY_POSITION,
B = DCHP_LTU1_545_OUT_LIMSW_POSY_POSITION,
C = DCHP_LTU1_555_OUT_LIMSW_NEGX_POSITION,
D = DCHP_LTU1_555_OUT_LIMSW_POSX_POSITION

29.12 Stopper MFX S4.5 Is In

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Is In	T	–	–	–	–	–	–	–

Where
A = STPR_XRT_1_S45IN_STATE

29.13 Stopper S1 Is In

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Is In	T	–	–	–	–	–	–	–

Where
A = STPR_FEE1_1_S1IN_POSITION

29.14 Stopper S2 Is In

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
In	T	–	–	–	–	–	–	–

Where
A = STPR_FEE1_1_S2IN_STATE

29.15 Stopper S2B Is In

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
In	T	–	–	–	–	–	–	–

Where
A = STPR_FEE1_1_S2BIN_STATE

29.16 Stopper S5B Is In

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
In	T	–	–	–	–	–	–	–

Where
A = STPR_FEH1_5_S5BIN_POSITION

29.17 Stopper SH1 Is In

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
In	T	–	–	–	–	–	–	–

Where
A = STPR_FEE1_1_SH1IN_STATE

29.18 Stopper SH2 Is In

Name	B	A	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
In	T	F	–	–	–	–	–	–	–

Where
A = STPR_XRT1_1_SH2OUT_STATE,
B = STPR_XRT1_1_SH2IN_STATE

29.19 Stopper XRT S5 Is In

Name	A	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
In	T	–	–	–	–	–	–	–

Where
A = STPR_XRT1_1_S5IN_POSITION

29.20 Stopper XRT S6 Is In

Name	A	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
In	T	–	–	–	–	–	–	–

Where
A = STPR_XRT1_1_S6IN_POSITION

29.21 Stopper: BSY D2 Summary Is In

Name	B	A	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
In	T	T	–	–	–	–	–	–	–

Where
A = STPR_BSY0_88_IN_LIMSW_A_POSITION,
B = STPR_BSY0_88_IN_LIMSW_B_POSITION

29.22 TD11 Is In

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
In	T	–	–	–	–	–	–	–

Where
A = `TD11_IN_LIMIT_STATE`

29.23 TDUND Is In

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
In	T	–	–	–	–	–	–	–

Where
A = `DUMP_LTU1_970_TDUND_IN_POSITION`

29.24 XPP-NH3-POS-00 Beamline Is In

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
In	T	–	–	–	–	–	–	–

Where
A = `XPP_NH3_POS_00_IN_STATE`

29.25 XPP-NH3-POS-00 Beamline Is Not In

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
Not_IN	F	–	–	–	–	–	–	–

Where
A = `XPP_NH3_POS_00_IN_STATE`

29.26 XRT-M2 Mirror Is Out of Beam

Name	*A*	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
IS_OUT	T	–	–	–	–	–	–	–

Where
A = HXX_HXM_MMS_01_B_POSITION

29.27 YAG01 Is In

Name	B	A	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
In	T	F	–	–	–	–	–	–	–

Where
A = YAGS_IN20_211_OUT_LMTSW_STATE,
B = YAGS_IN20_211_IN_LMTSW_STATE

29.28 YAG02 Is In

Name	A	GUNL	MS	BYKIK	LHS	GUNH	GUNS	BYKIKS
In	T	–	–	–	–	–	–	–

Where
A = YAGS_IN20_241_IN_LMTSW_STATE