

StreamDevice: stringout Records

Normal Operation

The variable x stands for the written or read value.

DOUBLE format (e.g. %f):

Not allowed.

LONG format (e.g. %i):

Not allowed.

ENUM format (e.g. %{}):

Not allowed.

STRING format (e.g. %s):

Output: $x=VAL$

Input: $VAL=x$

Initialization

During initialization, the @init handler is executed, if present. All format converters work like in normal operation.

aai aao ai ao bi bo mbbi mbbo mbbiDirect mbboDirect longin longout stringin waveform calcout scalcout

Dirk Zimoch, 2005