

VERS. 2.0 PK 7/17/91

## POSITRON YIELD TUNING PROCEDURES

### I. OVERVIEW

this section summarizes the main things available to look at and tune in the e+ system. A step by step tuning procedure follows in the next section

### 1. CONFIGURATIONS

these are the relevant configs for the e+ system and should always have gold configs loaded.

#### **magnet configurations**

EXTraction line  
EPOSLINE  
CID-01  
SRING

#### **energy configurations**

KEPOS  
KSRING

#### **timing configurations**

TIMEPOS  
TIMSRING

### 2. DIAGNOSTICS AVAILABLE

the following is a summary list of major tools available to look at or "tune on" to bring up the e+ yield

#### **PYIELD display**

tabulates the yield and subyield through out the e+ system

- use this to immediately diagnose where we are losing the most yield

reference values for subyields are listed as a guide

#### **PYIELD correlation plot variables**

- allows you to put the PYIELD display values in a correlation plot to optimize a tuning parameter

From the correlation plot acquisition panel use the button macro "positron yields" to load all the pyield variables

#### **ETA foils and bunch length monitor scope**

indicate the energy, energy spread and amount of charge □ bunch length

#### **BPM Orbits**

indicate whether launch and steering in each subsystem are correct

#### **PROFile monitor screen EP01 185 (upstream of target)**

jitter, tails and energy spread in the scavenger beam are apparent.

## Sector 1 wire scanners

measure the emittance and beta mismatch of positrons at the end of Sector 1

- scans only possible when S1 PLIC is very low

S1 PLIC is optimized by longitudinal phase space tuning and by the optimizing the launch into S1

## SLTR Profile monitor

PROF DR01 175

- at a high dispersion point so energy spread and tails are visible

## PLIC signal scope

WTA-SDR indicates beam losses in S1 as well as SLTR and launch into ring

- see reference PLIC signal map to identify points along the beam line

Positron Return Line PLIC

4 x 6 PLIC

## SDR envelope monitor scope

- shows the actual intensity at a BPM in the ring as a function of turn number in real time.

tells you immediately if the knob you are turning has a strong effect on the SDR intensity, but it is misleading to tune on this only. The shape of the envelope indicates the rate of loss at injection

## SDR synchrotron feedback scope

indicates longitudinal oscillations as beam launched into ring

- large oscillations if energy or phase badly matched
- oscillations grow if loop at fault or beam instability (pi mode)

pi mode instability at present controlled by manual setting cavity tuners

## SDR synchrotron light spot

indicates if ring is coupled

- round spot when emittances equal in each plane indicating tunes are coupled

## Tune measuring spectrum analyzer

measures fractional tune in each plane

- frequency of each peak divided by 8.5 MHz gives fractional tune which should be  $0.17 \pm 0.01$

## Turns monitor

SDR BPM X, Y and TMIT as a function of turn number on a single bunch

- operated via a MATLAB program on a VAX terminal  
still an experimental tool

### 3. SCAVENGER BEAM TUNING

#### scavenger beam steering

Prof EP01 171 shows production and scavenger bunch at Horiz. Lambertson

- check for tails and correct kicker operation
- check extr. line kicker waveform monitor scope
- check kicker time and amplitude jitter

#### scavenger beam energy

set by feedback and feedforward loops  
must match extr line magnets

- assigning knob EXT4\_GEV.mkb displays required scavenger energy in GeV

#### scavenger beam energy spread

influenced by phase ramp setting

- phase ramp usually set to give correct energy spread at the BSY

#### target steering

controlled by the set points of the target steering feedback loop

- optimize PT01 529 yield by scanning setpoints on either side of current settings if yield is more than 2% below 4.0

### 4. LONGITUDINAL PHASE SPACE TUNING TOOLS

#### Sector 20 klystrons

note that these settings are strongly dependant on the beam intensity

#### 20-3 drive amplitude

this is usually set at the maximum value after it was processed and should not be changed during routine tuning

#### 20-4 drive amplitude

- tune to set the *energy* correctly on the ETA foils.
- In principle, it should also maximize Li01 831 yield and minimize S1 PLIC

determines the energy of the e+ and hence how well they are captured in sector 1 rf bucket

#### combined phase shifter

- POS PHASE 34 knob tuned to optimize the *energy spread* on the ETA foils.
- This knob is *frequently* tuned and should also maximize Li01 831 yield and minimize S1 PLIC and minimize energy spread in the SLTR

changes phase of 20-3 and 20-4 in unison and hence also controls the energy and phase of the e+ reaching S1

### 20-3 and 20-4 phases

- in routine operation it is not normal to change the relative phases between the two klystrons

Phase 20-3 is nominally set to maximize acceleration

Phase 20-4 controls energy spread in EP02

### Trombone

- tune to maximize Li01 831 yield and minimize S1 PLIC and minimize energy spread in the SLTR

changing the e+ path length determines their arrival time at S1 and hence their phase w.r.t. S1. The phase in S1 in turn determines energy spread in the SLTR

## Sector 1 klystrons

Klys 1-6 amplitude

- tune to correct energy in SLTR. This is difficult if e- are being co-accelerated in S1 because a simultaneous change must be made to e- energy in Li00

orbit in the SLTR reveals energy offsets at high dispersion points

## SLTR compressor

klystron amplitude set at maximum

klystron phase set to leave the energy of the beam unchanged

- look at a difference orbit in the ring with the compressor on and off

## SDR station phase

set to maximize capture in the ring, rarely needs changing

the phase of the ring rf bucket is changed w.r.t. to the incoming beam phase

## 5. TRANSVERSE PHASE SPACE TUNING

### Launch optimization

scavenger e- onto target

- use feedback setpoints

from PRL into WTA

- feedback correctors at end of PRL should maximize subyield in EP05 and also provide headroom for:

from WTA into S1

- 4 launch knobs (e.g. EP\_X\_MM.MKB etc.) should be used to maximize yield as far as Li01 835 only and should minimize S1 PLIC.

from S1 into SLTR

- 4 launch knobs to maximize yield to end of SLTR only

from SLTR into SDR

- 4 launch knobs to maximize SDR throughput and minimize first turn orbit difference with stored orbit.

### Steering

Center beam in beam pipe. Beam should match gold ref orbit and PLIC minimized

- only attempted after upstream orbit and launch correct

All regions can be auto-steered using the mikado method with minimum corrector action. Consult an e+ physicist if you believe the SDR stored orbit steering is wrong.

Orbit bumps are used in specialized regions to move a short length of the orbit around.

- SDR septum bumps move the stored orbit around the septum blade. The launch and/or extraction orbit needs

reoptimization afterwards. Bifurcated bumps  
(B\_SEPT\_\*.mkb) combine both these actions.

## Beta matching

On the S1 wires the BMAG parameter should be close to 1 when the e+ emittances are measured

- 4 quadrupoles in the WTA are used to control this parameter using the online beta matching package (consult an e+ physicist)

BMAG is a parameter quantifying the mismatch of the transverse beam ellipse compared to the design beam.

## II. A TUNING RECIPE

### Determine where upstream yield is starting to drop

use special PYIELD display and compare subyields to gold subyields at each toroid

### Start with the upstream problems first

### Use a serialized approach to increase yield

only tune the yield up to the point of the next downstream toroid.

DO NOT tune an upstream parameter looking only at the SDR intensity

### Be sure gold configs are loaded and green

DISPLAY RED on the gold config will also tell you if hardware is out of tolerance

## 1. TARGET YIELD PT01 529

### Check profile monitor 185 (near target) for a small round stable spot

otherwise fix scavenger beam parameters first

### Center the scavenger beam on the target

scan the feedback setpoints to either side of current value in steps of 0.2mm

## 2. ETA YIELD EP02 812

### Check the ETA foils scope

CENTER the peak on the middle foil by controlling the energy with klystron drive 20-4

MAXIMIZE the peak making it narrower by optimizing the energy spread with PHASE 30-4

- tune for yield AND stability

Iterate tuning on phase and drive knobs

failure to restore yield may indicate that phases 90-3 and 90-4 are wrong, but be careful.

## 3. PRL YIELD LI19 TO LI04

### Check orbits EP02 through Li01 in the return line

if autosteering is used ensure no bad BPMs are included

## 4. WTA YIELD EP05 3152

## Check launch from PRL into WTA

slow feedback setpoints control launch

- check that correctors used at end of PRL are not at maximum

## 5. YIELD INTO S1 LI01 141

### **4 launch knobs use correctors at exit of the WTA**

knobs can only be coarsely set at this toroid, fine tuning at next step

- S1 toroids don't read out when e- co-accelerated at 60, 120Hz

## 6. S1 YIELD LI01 835

### **Tune to maximize yield and minimize PLIC**

DO NOT change correctors in S1 away from configuration values

the orbit in S1 is a compromise for e+ and e- and will not benefit from further tuning!

### **Optimize launch from WTA**

fine tune launch knobs from previous step

### **Optimize longitudinal tuning**

optimize energy and phase of beam launched into S1

- fine tune energy with drive 20-4 and phase 30-4

- S1 toroids don't read out when e- co-accelerated at 60, 120 Hz

### **Emittance and beta match check**

this is not something to tune on, but a diagnostic if you suspect something is not right with the system

use S1 wires if PLIC low enough

- emittance should be around  $2E-3$  in each plane
- beta mismatch parameter BMAG should be less than 1.10  
an online beta matching package exists, but please consult with a e+ physicist first
- if S1 PLIC too high for clean scans then energy collimate the beam using ETA collimators EP02 740, 741  
move one jaw in until intensity drops ~25% then the other for a further 25% ensuring a symmetric reduction in energy spread

## 7. BEGINNING OF SLTR DR01 241

### **Optimize launch from S1**

use 4 launch knobs

- make sure correctors at end of S1 not near maximum and
- if launch knobs generate S1 PLIC something else is wrong with S1 orbit so back up a step

### **Optimize energy spread**

fine tune trombone

- putting in PROF DR01 175 is the only reliable way of verifying energy spread

## 8. SLTR YIELD DR01 1481

### **Optimize energy**

use drive 1-6 to set energy to center orbit in SLTR

- unfortunately this also changes e- energy at and above 60 Hz
- so change e- energy simultaneously in LiO

### Steer SLTR orbit flat

can be autosteered using mikado method, minimizing corrector strengths

- pay attention to correctors near maximum and fighting each other

loss along SLTR should not be more than 10%

### Check phase of energy compressor

look at a difference orbit in the ring

- no change in orbit when compressor on/off

## 9. SDR THROUGHPUT DR03 71

### Optimize launch

4 launch knobs use correctors at end of SLTR

- maximize ring throughput
- 1st turn difference should then match stored orbit

### Check energy

if correct from previous step should not need changing

- orbit should be symmetric about zero

### Check stored orbit

compare with gold orbit, especially near septa

- scan septa bumps if orbit is suspect using bifurcated closed orbit bumps

closed orbit bumps make only a local bump leaving the rest of the ring undisturbed (check that this is true). To maintain correct launch conditions from the SLTR or a correct orbit into the SRTL we use bifurcated bumps that also use correctors outside of the ring

### Check synchrotron oscillation feedback scope

should show small, damped oscillation

- otherwise check SDR cavity tuning angle
- SDR rf station phase may conceivably be wrong particularly if CID was recently retuned!

### Check synchrotron light spot

spot should be round indicating coupling

- otherwise measure and correct tunes as necessary

a tune knob for each plane controls quadrupoles in the SDR to change each tune by a predetermined amount

### Check tunes

good idea if sync light spot not round or orbit bumps not closing

### Check extraction

beam at PROF DR03 should be stable and not shadowed by septum

SRTL orbit should match gold

the SRTL orbit is crucial to good matching into the linac